

Settings

Ethernet Settings



Use DHCP

Banner Setting

Time Settings

Modbus Settings

Interrupts: rx:50135, tx:0 alloc:1462, total:51597"

Home screen banner or screen title.

Manual Time Settings

Use **Time** screen to use SNTP time synchronization.

Modbus RTU settings

Use **Ethernet Settings** for Modbus TCP/IP.

Statistics for service use