



On **SETUP** screen, touch **DEVICES/MODBUS**.

The **DEVICES/MODBUS** screen defines the Modbus network and device chain as well as set the banner name for the header.



Modbus Device Chain:

Banner Name displayed on top line.

Number of Devices should equal number of devices connected in Monitor's downstream device chain.

Upstream Modbus:

Address of Monitor on upstream side
Baud rate (9600/19200/38400)
Parity (even/odd/none)

Downstream Modbus Network characteristics are fixed and cannot currently be modified.