



Operator controls are all front-accessible.

Front access to monitoring components and to customer network connections are in the central Monitoring Compartment on left PDU door.



Circuit breakers are behind locked viewing panels.

Customer connections (power, monitoring, dry contacts, and networking) and replaceable components are all front-accessible.

