



Neutral wire connection (white)

Hot wire connection (black)

Note for Two-Stage Systems:

If there is no 120V input, installing a jumper from the neutral terminal to the hot terminal will not provide a permanently enabled external permissive signal.