



Atmel ATSAMD21G18A Programming

Notes:

Use Atmel Studio

Select Tools\DeviceProgramming

Device is ATSAMD21G18A

Use the J-Link Control Panel to set Target Power On

Use the Fuses tab to set NVMCTRL_BOOTPROT to 0x07 if required