

RC Precision Chiller



User Manual

1 TABLE OF CONTENTS

2	Introduction	4
2.1	How to Contact ThermoTek Inc.	4
2.2	Explanation of Symbols	4
2.3	EMC Precautions	5
2.4	Warnings: Risk of Electrical Shock.....	5
2.5	Warnings: Risk of Personal Injury	5
2.6	Warnings: Risk of Device Damage.....	6
2.7	Unpacking Instructions	6
3	Setup and Operating the RC System.....	7
3.1	Setting up the RC Temperature Control System.....	7
3.2	Startup Procedure	7
3.3	Run Mode Operating Procedures	8
3.3.1	<i>How to Stop and Start the RC Chiller.....</i>	<i>9</i>
3.3.2	<i>How to Change the Set Temperature.....</i>	<i>9</i>
3.3.3	<i>How to Change the Fan Drive</i>	<i>10</i>
3.3.4	<i>How to Change the Pump Drive (for applicable configurations).....</i>	<i>10</i>
3.3.5	<i>How to Change the User Settable Temperature Alarms</i>	<i>11</i>
3.3.6	<i>How to Change the User Settable Coolant Flow Alarms (for applicable configurations)</i>	<i>11</i>
3.3.7	<i>How to Access the Monitor Screen.....</i>	<i>11</i>
3.4	STANDBY Mode Operating Procedures	12
3.4.1	<i>How to Set the Control Sensor</i>	<i>12</i>
3.4.2	<i>How to Set the COM Port</i>	<i>12</i>
3.4.3	<i>Set START Mode</i>	<i>13</i>
3.4.4	<i>Alarm History</i>	<i>13</i>
3.5	Turning the RC System OFF.....	13
4	Taking Care of Your RC System	14
4.1	Checking the Coolant Level.....	14
4.2	Changing the Coolant Level	14
4.3	Changing the Application Coolant	14
4.4	Cleaning the Exterior of the RC System	15
4.5	Storing the RC System	15
5	Alarm Messages	16
6	Technical Specifications	18
6.1	RC System Technical Specification.....	18
6.2	RC System Performance.....	19
6.3	RC System Wetted Path Materials.....	20
6.4	RC System – Conformance Information.....	20
6.5	RC System – Guidance and Manufacture’s Declaration – Electromagnetic Emissions.....	20
7	Warranty	21

2 INTRODUCTION

Read the entire guide before attempting to connect or operate this product. Keep this guide for future reference.

The RC Precision Rack Chiller is a solid-state thermoelectric heating and cooling system. It is designed to maintain a set temperature of the working fluid that is circulated between the thermal management application and itself.






This guide provides the information required to setup and use the RC precision temperature control system.





2.1 How to Contact ThermoTek Inc.

If you have questions about the RC system, or require service, please contact ThermoTek Inc. at:

1200 Lakeside Parkway, #200
Flower Mound, TX 75028
Tel: (001) 214 – 502 – 8800

2.2 Explanation of Symbols

	IMPORTANT: Read Instructions before Use Before operating the device, please read the entire instruction guide. Keep the guide available for future reference.
	CAUTION. Consult user manual to determine potential hazards prior to operating the device.
	Manufacturer's Part Number
	Device Serial Number
	AC Power
IP20	Ingress Protection Of the Device. Solid Particles > 12.5 mm will be protected from access to hazardous parts. The device does not have any ingress protection against liquids.

	Do NOT Dispose with General Household Waste Please consult local government / city laws on acceptable method of disposal of electro-mechanical systems in compliance with the Waste Electric and Electronic Equipment Directive (WEEE) 2001/96/EC.
	Device Manufacturing location
	Device Manufacture Date Code
	RoHS Compliant

2.3 EMC Precautions

The RC precision temperature control system is an Electrical Equipment that requires installation precautions regarding electromagnetic compatibility (EMC). Installation is to be completed as specified in the Technical Information Section.

2.4 Warnings: Risk of Electrical Shock

- ⚠ Do not attempt open or service the RC system. Such attempts could result in injury and / or damage to the product, and will void any warranty.
- ⚠ Do not spill liquids of any kind on RC system.
- ⚠ Always use the RC system with a grounded power inlet.
- ⚠ Do not use the RC system with power cord that is damaged or has exposed copper wires.
- ⚠ Do not use a power cord with lower electrical rating than 250 VAC, 10A.
- ⚠ Do not limit access to the power cord inlet. Only the removal of the power cord disconnects **ALL** hazards voltages form the device.

2.5 Warnings: Risk of Personal Injury

- ⚠ Use RC system for its intended purpose, as directed in this guide.
- ⚠ Install the RC system as specified in the Technical Information Section.
- ⚠ Do not use the RC with a working fluid temperature of $> 45^{\circ}\text{C}$
- ⚠ Do not use the RC system in the presence of flammable gasses, including flammable anesthetics.
- ⚠ Do not place the product on an unstable cart, stand or table. They product may fall, causing serious damage.
- ⚠ When installing the RC system to a Rack, it is advisable to use slides for mounting the device.

2.6 Warnings: Risk of Device Damage

- ⚠ Never block the ventilation openings on the side of the RC device. Keep the ventilation openings free of debris such as lint and dust.
- ⚠ The device is to be used on a horizontal surface, or mounted to a rack enclosure horizontally, with the reservoir opening at the top of the device. Do not use the device in any other orientation.
- ⚠ Do not install the device such that access to the power switch, power cord inlet and coolant connectors are limited.
- ⚠ Use recommended fluids only.
- ⚠ Do not use deionized water.
- ⚠ Do not use Copper or Brass fittings / cold plates with the RC Chiller.
- ⚠ Never drop or insert any objects into the RC device.
- ⚠ Do not drop or cause impact to the RC device.
- ⚠ Do not operate the RC device if it is damaged or leaking fluids.
- ⚠ Do not operate the RC device beyond its rated capacity.
- ⚠ Do not operate the RC device outdoors
- ⚠ Do not operate the RC device in a sealed environment.
- ⚠ Do not operate the RC device at set points below 5°C without 90% distilled water and 10% inhibited Glycol solution, or 90% distilled water and 10% isopropyl alcohol.

2.7 Unpacking Instructions

When the RC system arrives, it is important that you carefully unpack the contents and ensure that you have all the equipment required for operation.

Included in the box, you should find the following:

- User Guide
- RC Precision Temperature Control system
- Power Cord
- Right Angle RS232 Adaptor (Applicable to certain models)
- Certificate of Conformance

3 SETUP AND OPERATING THE RC SYSTEM

3.1 Setting up the RC Temperature Control System

Follow the steps outlined below:

1. Connect the RC chiller to the application using a fluid transport hoses from ThermoTek or hoses using Colder PLC or PLCD insert fittings, or custom fittings as configured.
2. Keep the chiller horizontal and on a level surface.
3. If the RC chiller is to be installed in a rack, use of slides is recommended for mounting it.
4. Make sure there is a minimum 12" clearance and free path for flow of air entry and exit at the front and rear of the RC chiller, prior to operation.
5. Check to see if the power switch is in the OFF position.
6. Insert the fluid transport hose into the RC Chiller. If the fittings are the standard Colder quick disconnects, hearing a "click" indicates a secure connection. Check the labels next to the ports for coolant flow direction.
7. For rear port RC chillers, the coolant ports are located on the rear panel, adjacent to the power switch. For front port RC chillers, the coolant ports are located left of the display.
8. Remove the reservoir cap and add coolant to the reservoir until the fluid reaches the bottom of the neck. Please refer to the technical information section for recommended coolants.
9. Close the cap securely to the reservoir. Make sure not to overfill the reservoir.
Install the appropriate end of the power cord into the unit. Plug the male end into the AC voltage outlet within the device specified voltage. Please refer to the technical information section for input voltage specifications.

3.2 Startup Procedure

1. Verify that the RC Chiller is plugged into the appropriate AC voltage outlet.
2. Verify the RC Chiller coolant ports are connected to the application.
 - A. It is recommended that insulated tubing, with minimum 3/8" ID, be used when connecting to the application.
 - B. Even if the application flow path is smaller than the recommended ID, it is important to use the recommended ID for the transport hose to minimize system pressure drops.
 - C. Do not use Copper or Brass components in the application-wetted path. This will adversely impact the RC Chiller heat exchanger. See the technical information section for RC Chiller wetted path component list.
3. Turn ON the RC Chiller. The power switch is located on the back of the device, adjacent to the coolant ports.
4. When the unit first powers up a rotating circle will appear on the LCD screen located on the front of the unit.

5. The unit will automatically start and enter the RUN Mode with the fans and pump active and the control system set to control the operating fluid to 20 C or the last set temperature (Figure 1).
6. Open the reservoir and add additional fluid as needed. Close the cap securely to the reservoir.
7. It is possible that the initial startup and fluid transport could generate a “Low Fluid” alarm. Clear the alarm by pressing the “Accept” key. Open the reservoir cap and add fluid. Close the cap and press “Start” to re-start the chiller.

Note: If the application is located above the chiller, there is a potential for the fluid to overflow the reservoir due to gravity, when the cap is opened with the pump stopped. During these cases, it is recommended that the external tubing sections be individually primed by connecting it to the chiller. When all sections are primed, then connect the external tubing to the chiller and the application, and complete the final priming of the application.

8. When the unit is operating and controlling to set temperature, the RUN Mode screen content will be displayed on the LCD screen.

3.3 Run Mode Operating Procedures

When the RC Chiller is operating and providing temperature controlled fluid it is said to be in the RUN Mode. During the RUN Mode the screen content shown in figure 3-1 is displayed. The RUN Mode screen shows the instantaneous fluid temperature, the maximum and minimum temperature stability over the past 60 minutes, the set temperate; the sensor used for control the fluid and if applicable the coolant flow rate.



Figure 3-1: RUN Mode Screen

While in the RUN Mode the following features are accessible:

- Set the device in STANDBY Mode
- Set / Change control temperature
- Set / Change fan speed
- Set / Change pump speed (if applicable)

- Set / Change user specified temperature alarms
- Set / Change user specified coolant flow alarm
- Access the Monitor screen for detailed operational statuses

3.3.1 How to Stop and Start the RC Chiller

1. To stop the RC Chiller, press the “Stop” button. This will place the system in standby mode with the coolant pump and the temperature control subsystem in idle state.
2. The fans will continue to operate of some time to cool the heat sinks. Once the heat sink temperature is near ambient the fans will enter the idle state.
3. To Start the RC Chiller, press the “Start” button. This will display the RUN Mode screen with the chiller controlling the fluid to the previous set temperature.



Figure 3-2: STANDBY Mode Screen

3.3.2 How to Change the Set Temperature

1. From the RUN Mode Screen, press the “SetTemp” button on the screen.
2. This will navigate to the Set temperature screen. This screen will show the current and the new temperature.
3. Press the UP or DOWN arrow to change the temperature to a new setting. The new setting will be shown on the right under “New Temp”.
4. When the arrows buttons are pressed the temperature setting will initially change in 0.1C increments. If the key is held down for more then 5 seconds, the temperature will change in 1.0C increments. To go back to 0.1C steps, let go of the arrow key and re-press it to achieve fine control.
5. Once the correct set temperature is selected, press the “Accept” button to confirm change to the set temperature.
6. If the “Cancel” button is pressed, the new changes are canceled and the previous set temperature will stay active.
7. Pressing the “Accept” or “Cancel” button will return you to the RUN Mode screen.



Figure 3-3: SET TEMP Screen

3.3.3 How to Change the Fan Drive

1. From the RUN Mode screen, press the Next button.
2. On the Selection screen press the Set Fan Drive button.
3. This will navigate to the Set Fan drive screen. The screen will show the current and the new Fan drive.
4. Press the UP or DOWN arrow to change the fan drive to a new setting. The new drive setting will be shown on the right under “New”.
5. Once the correct fan drive is selected, press the “Accept” button to confirm change to the fan drive setting.
6. If the “Cancel” button is pressed, the new changes are canceled and the previous fan drive will stay active.
7. Pressing the “Accept” or “Cancel” button will return you to the RUN Mode screen.

3.3.4 How to Change the Pump Drive (for applicable configurations)

1. Some RC Systems are equipped with a variable speed pump. For these models, the option to customize the system flow is available via the user interface.
2. From the RUN Mode screen, press the Next button.
3. On the Selection screen press the Set Pump Drive button.
4. This will navigate to the Set pump drive screen. The screen will show the current and the new pump drive.
5. Press the UP or DOWN arrow to change the pump drive to a new setting. The new drive setting will be shown on the right under “New”.
6. Once the correct pump drive is selected, press the “Accept” button to confirm change to the set temperature.
7. If the “Cancel” button is pressed, the new changes are canceled and the previous pump drive will stay active.

8. Pressing the “Accept” or “Cancel” button will return you to the RUN Mode screen.

3.3.5 How to Change the User Settable Temperature Alarms

1. From the RUN Mode screen, press the Next button.
2. On the Selection screen press the Set High Temp or Low Temp Alarm button.
3. This will navigate to the Set Temp Alarm screen. The screen will show the current and the new alarm limits.
4. Press the UP or DOWN arrow to change the temperature to a new setting. The new setting will be shown on the right under “New”.
5. Once the correct alarm temperature is selected, press the “Accept” button to confirm change to the alarm setting.
6. If the “Cancel” button is pressed, the new changes are canceled and the previous alarm temperature limits will stay active.
7. Pressing the “Accept” or “Cancel” button will return you to the RUN Mode screen.

3.3.6 How to Change the User Settable Coolant Flow Alarms (for applicable configurations)

1. Some RC models are equipped with a flow meter. For these models, the option to set a min flow alarm is available via the user interface.
2. From the RUN Mode screen, press the Next button.
3. On the Selection screen press the Set Flow Alarm button.
4. This will navigate to the Set Flow Alarm screen. The screen will show the current and the new alarm limits.
5. Press the UP or DOWN arrow to change the flow alarm limit to a new setting. The new setting will be shown on the right under “New”.
6. Once the correct alarm value is selected, press the “Accept” button to confirm change to the alarm setting.
7. If the “Cancel” button is pressed, the new changes are canceled and the previous flow alarm limits will stay active.
8. Pressing the “Accept” or “Cancel” button will return you to the RUN Mode screen.

3.3.7 How to Access the Monitor Screen

1. Press the Next button from the RUN Mode screen
2. On the Selection Screen press the Monitor Button.
3. This will display the monitor screen. The monitor screen shows detailed operational state of the RC system. This is a useful diagnostic tool to verify the operation of the device.
4. Press the Next button to cycle through the available monitor screens.
5. Press the Back button to return to the Selection screen.

6. Press the Home button to return to the RUN Mode screen.

3.4 STANDBY Mode Operating Procedures

3.4.1 How to Set the Control Sensor

1. Some RC Systems are equipped with alternate temp sensors that can be selected as the control sensor. The “supply” sensor is the default selection.
2. Apply power to the chiller.
3. From the STANDBY Mode screen press the Next button.
4. On the following screen press the Set Control Sensor button.
5. This will navigate to the Set Control Sensor screen. The screen will show the current and the other available sensors.
6. Press the UP or DOWN arrow to change the control sensor to a new setting. The new sensor setting will be shown on the right under “New”.
7. Once the correct control sensor is selected, press the “Accept” button to confirm changes to the sensor selection.
8. If the “Cancel” button is pressed, the new changes are canceled and the previous control sensor selection will stay active.
9. Pressing the “Accept” or “Cancel” button will return you to the STANDBY Mode screen

3.4.2 How to Set the COM Port

1. Some RC Systems are equipped with alternate communications port that can be selected for remote monitoring and communication. USB Port is the default selection.
2. Apply power to the chiller.
3. From the STANDBY Mode screen press the Next button.
4. On the following screen press the Set COM Port button.
5. This will navigate to the Set COM Port screen. The screen will show the current and the other available ports.
6. Press the UP or DOWN arrow to change the port to a new setting. The new sensor setting will be shown on the right under “New”.
7. Once the correct com port is selected, press the “Accept” button to confirm changes to the port selection.
8. If the “Cancel” button is pressed, the new changes are canceled and the previous com port selection will stay active.
9. Pressing the “Accept” or “Cancel” button will return you to the STANDBY Mode screen.

3.4.3 Set START Mode

Set START mode defines the startup condition for the chiller after powering up. If Auto start is enabled, the chiller will automatically enter the RUN mode and provide temperature control to the last set temperature.

If Auto start is disabled the chiller will stay in STANDBY mode after a power up event. The user shall initiate temp control via the front screen or remotely via the USB connection.

1. Apply power to the chiller.
2. From the STANDBY Mode screen press the Next button.
3. On the following screen press the Set START Mode button.
4. This will navigate to the Set START Mode screen. The screen will show the current mode and the new mode.
5. If the current mode is “Enabled” that means the auto-start function after a power cycle is active. To disable this function, toggle the “New” state to be “Disabled”.
6. Once the correct mode is selected, press the “Accept” button to confirm changes to the START Mode function.
7. If the “Cancel” button is pressed, the new changes are canceled and the previous START Mode selection will stay active.
8. Pressing the “Accept” or “Cancel” button will return you to the STANDBY Mode screen

3.4.4 Alarm History

The Alarm History selection shows the last ten alarm events detected by the chiller. This is available for diagnosing and problem resolution of the chiller or installation.

1. Apply power to the chiller.
2. From the STANDBY Mode screen press the Next button twice.
3. On the following screen Press the Alarm History button.
4. After reviewing the alarm history press the “Accept” button to return to the Standby Mode screen.

3.5 Turning the RC System OFF

1. If the RC system is operating, press the Stop button to set it in idle mode.
2. Wait 60 seconds and turn the power switch to the OFF position.

4 TAKING CARE OF YOUR RC SYSTEM

4.1 Checking the Coolant Level

1. Once a week, check the coolant level of the RC system
2. Set the system in RUN Mode.
3. Open the reservoir cap and check the fluid level in the reservoir. If the level is below the reservoir neck, add recommended fluid to fill it. Please refer to the technical information section for recommended coolants.
4. Close the cap, finger tight, when complete.

4.2 Changing the Coolant Level

1. Disconnect power to the unit, by turning the power switch to the off position.
2. Disconnect the unit from the application by depressing the CPC fittings thumb tabs and gently remove the hose connectors from the unit connectors. If the connections are other than CPC, please refer to the specific connector manufacture's recommended practice for installation / removal of connectors.
3. Connect the drain hoses (with the CPC male connectors on one side and open tube on the other) to the supply and return ports and drain the fluid into a discard vessel.
4. Turn on the unit and set the unit in Run Mode.
5. Keep adding fresh fluid of, 500 ml, into the reservoir to circulate it through the system and pump it out to the discard vessel.
6. When all the fluid is emptied from the reservoir, the system will issue a "Low Coolant Level" alarm message. Disconnect the drain hoses and reconnect the RC Chiller to the application.
7. Add fluid to the reservoir; press "Accept" to clear the alarm.
8. Start the system and add fluid as required for the fluid level to be at the bottom of the reservoir neck.
9. Once complete, close the cap.
10. It is recommended that a coolant change be implemented at minimum, every six months, to keep the system in working order. Based on your use conditions, you may need to perform this PM more frequently.

4.3 Changing the Application Coolant

1. It is highly recommended the fluid contained within the application also be flushed when the RC Chiller coolant is changed.
2. Follow application guidelines for flushing procedure.

4.4 Cleaning the Exterior of the RC System

Caution: When clearing the RC system, make sure you follow the caution statements:

- Do not submerge the unit
- Do not pour water or cleaning fluid over the unit
- Do not disassemble
- Do not autoclave
- Do not steam sterilize
- Do not EtO sterilize
- Do not rub or get the display window wet
- Do not use abrasive or solvent-based cleaners on the unit

To clean the RC Chiller exterior, follow these steps:

1. Power down the RC system and unplug the AC power cord.
2. Use a damp “static free” cloth and mild household cleaner and wipe all exterior surfaces.
3. Use a dry “static free” cloth to clean the display window.
4. Let the RC system dry completely before powering on the system.

Note: There are no user serviceable internal parts. To avoid possible electric shock, do not remove the cover. The warranty is voided if the tamper seal is removed.

4.5 Storing the RC System

For long-term storage of the RC system, follow these steps:

1. Power down the RC system and unplug the AC power cord.
2. Drain all fluid from the RC system by following section 4.2, steps 1-6.
3. Replace the Reservoir cap.
4. Package the RC system in its original packaging with the power cord for storage.

5 ALARM MESSAGES

ALARM MESSAGE	ALARM DESCRIPTION
LOW COOLANT LEVEL ALARM	<p>If the coolant level in the reservoir drops below the level sensor activation limit for 5 seconds, the device will issue this alarm.</p> <p>When this alarm is active, the device is stopped and will require used intervention to determine and resolve the cause of the alarm, and once cleared, restart the device.</p>
NO PROCESS FLOW	<p>For systems that have the optional flow meter, if flow is not detected for > 5 seconds, the device will issue this alarm.</p> <p>When this alarm is active, the device is stopped and will require used intervention to determine and resolve the cause of the alarm, and once cleared, restart the device.</p> <p>Note: The system allows a 10 second delay when the pump is stated to allow flow to be established, prior to monitoring the flow condition.</p>
HIGH TEMP ALARM – SW DEFAULT	<p>If the supply temperature measures > 53C, for > 2.5 seconds, the device will issue this alarm.</p> <p>When this alarm is active, the device is stopped and will require used intervention to determine and resolve the cause of the alarm, and once cleared, restart the device.</p>
LOW TEMP ALARM – SW DEFAULT	<p>If the supply temperature measures < -8C, for > 2.5 seconds, the device will issue this alarm.</p> <p>When this alarm is active, the device is stopped and will require used intervention to determine and resolve the cause of the alarm, and once cleared, restart the device.</p>
HIGH AMBIENT TEMP ALARM	<p>If the ambient temperature measures > 50C, for > 2.5 seconds, the device will issue this alarm.</p> <p>The system will continue to operate until the fluid temperature reaches the High Temp Alarm – SW Default, at which point the device is stopped.</p>
NO FAN RPM ALARM	<p>If the fan rpm signal is not detected for > 5 seconds, the device will issue this alarm.</p> <p>When this alarm is active, the device is stopped and will require used intervention to determine and resolve the cause of the alarm, and once cleared, restart the device.</p> <p>Check to make sure the required 12” clearance in the front and rear of the chiller is maintained. Check for any air blockages that may cause the fan to not operate. Once these are have been address and</p>

	<p>the fan alarm is still present, please contact ThermoTek customer service for further assistance.</p> <p>Note: The system allows a 15 second delay when the system is started to allow flow to be established, prior to monitoring the flow condition.</p>
SYS ERR: SUPPLY SENSOR	<p>If the supply temperature measurement is outside the acceptable operational limits for > 5 seconds, the device will issue this alarm.</p> <p>When this alarm is active, the device is stopped. This alarm indicates there is a potential failure of the supply temp sensor.</p> <p>Turn off power to the device for 60 seconds. Power up the device and if the alarm re-appears contact ThermoTek customer service for further assistance.</p>

6 TECHNICAL SPECIFICATIONS



6.1 RC System Technical Specification

Device Dimensions:	Option 1: 485W x 615D x 132H Option 2: 485W x 381D x 132H
Device Weight:	10 - 24 kg
Device Port Type:	Colder PLC Coupling Inserts (std)
Device Input Voltage:	100-240 VAC
Device Input Frequency:	50/60 Hz
Device Input Current:	2.5 to 10.0 Amps
Device Operating Temperature Limits:	10C to 40C (Indoor Use Only)
Device Operating Humidity Limits:	15% to 80% Non-Condensing
Device Operating Atmospheric Pressure Limits:	85 – 101 kPa
Device Operating Altitude:	0 – 2,000 meters
Device Transport and Storage Limits:	-40C to 70C 10% to 95% Non-Condensing
Device Control Temperature Range:	5C to 45C with Coolant Option 1 and 2 -5C to 45C with Coolant Option 3
Device Cooling Capacity:	250 - 725 Watts with control set point at ambient temperature
Device Pumping Capacity:	Pump Option 1: 3.5 LPM Open Flow / 15 psi Max Pressure @ 0 Flow Pump Option 2: 4 LPM Open Flow / 45 psi @ 0 flow
Temperature Stability:	+/- 0.1C @ >2 LPM flow, constant load at a constant ambient (not to exceed system capacity)
Heating/Cooling Function:	Yes
Communication Interface:	USB (std), RS232 (optional)
Communication Protocol:	ThermoTek TTK Communication Protocol
Recommended Coolants:	Option 1: Distilled Water Option 2: 95% distilled water and 5% isopropyl alcohol mixture prevents bio growth Option 3: 80% distilled water and 20% inhibited Glycol mixture for set temperatures below 5C

Note:

1. The performance of the chiller is based on recirculating water with ≥ 2.0 LPM flow.
2. Individual applications may affect chiller performance. Consult ThermoTek for application assistance.
3. Specification subject to change without notice.

6.2 RC System Performance



Note:

1. The performance stated in the above chart has a performance tolerance of $\pm 10\%$.
2. The thermal performance stated above is based on recirculating water with ≥ 2.0 LPM flow.
3. The thermal performance stated above is with the fan speed set to 100%.
4. The flow performance was recorded with the coolant fluid controlled to 20°C and altitude < 500 meters.
5. Individual applications may affect chiller performance. Consult ThermoTek for application assistance.
6. Specification subject to change without notice.

6.3 RC System Wetted Path Materials

Heat Transfer Manifold	Aluminum with Electro less-Nickel plating
Tubing 1. Pre formed metal tubing 2. Flexible Hose Tubing	304 Stainless Steel Synthetic rubber with fiber braid reinforcement
Temperature Sensor	316 Stainless Steel
Colder CPC Connectors	1. Acetal body and valves, and 316 Stainless Steel springs and Buna O-ring 2. Chrome plated brass body, Acetal Valve, 316 Stainless Steel springs and Buna O-ring
Coolant Reservoir	HDPE with Silicon O-ring
Level Switch	PVC with Buna O-ring

6.4 RC System – Conformance Information

Electrical Safety:	IEC 61010-1 3 rd Ed
Electromagnetic Compatibility (EMC):	IEC 61326-1 2 nd Ed
Waste Electrical & Electronic Equipment (WEEE):	Directive 2002/96/EC
Restriction of Hazardous Substance (RoHS):	Directive 2002/95/EC

6.5 RC System – Guidance and Manufacture’s Declaration – Electromagnetic Emissions

This device has been tested and found to comply with the limits for Electrical equipment for measurement, control and laboratory use, per IEC 61326-1. These limits are designed to provide reasonable protection against harmful interference in typical installation for the stated use.

This equipment generates and radiates radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to other devices in the vicinity.

There is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to other devices, which can be determined by turning the equipment off and on, the user can try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving device.
- Increase the physical separation between the equipment and other device(s).
- Connect the equipment into an outlet or circuit different from the one where the other device(s) are connected.
- Connect an external 20 AWG ground wire from the eqi-potential ground tab on the back of the chiller to earth ground.

7 WARRANTY

Limited Warranty Terms: ThermoTek, Inc. (“ThermoTek”) warrants to the immediate purchaser from ThermoTek or an immediate purchaser of an unused unit from an authorized distributor of ThermoTek products, that any RC system will be free from defects in workmanship and material under normal use for one year after the date of purchase. ThermoTek warrants to the immediate purchaser from ThermoTek, or an immediate purchaser of an unused wrap from an authorized distributor of ThermoTek products, that ThermoTek single patient use wraps will be free from defects in workmanship and material under normal use for only the first use of the wrap.

This Limited Warranty covers only defects in material or workmanship. Therefore, it does not cover any other claim, service, defect, condition, or damage, including: installation, set-up, or instructions or recommendations on use; accidents, tampering, improper product selection, misuse, neglect, or abnormal use; use of parts, accessories or fluids that are incompatible or adversely affect operation, performance, or durability; unauthorized service, repair or alteration; excessive moisture or humidity; normal wear and tear; cleaning or any condition caused by any dirt or foreign substance on or in the product; or damages resulting from shipping. **Installation or use of the product or any portion thereof in a manner that does not comply with the Operating Instructions voids the warranty. Any alteration or modification that changes the product’s effectiveness or intended use voids the warranty.**

ThermoTek will, at its option, repair or replace within a reasonable time any product that is found to have a defect in material or workmanship under normal use during the applicable warranty period. This is the immediate purchaser’s sole remedy. Any warranty on a repair or replacement expires at the same time as the warranty expires or would have expired on the original product. The product must be returned at the immediate purchaser’s expense to an authorized ThermoTek Service Center for warranty service. ThermoTek will pay for the expense of returning the product receiving warranted service to the immediate purchaser. The immediate purchaser is responsible for and will be assessed a fee for test and calibration if no defects are found with the product.

Because ThermoTek updates and advances its products and technology, ThermoTek reserves the right to modify or improve the design of any product without assuming any obligation to modify any product previously manufactured.

Any product returned for warranty must have a Returned Materials Authorization (“RMA”) number on the outside of the container or package. Please call ThermoTek Customer Service at 877-242-3232 for an RMA number. A ThermoTek unit must be drained of all fluids before return. Returned products must be in the ThermoTek approved box and packing material to ensure safe transport. To quickly process your warranty repair request, please have the following product information, which is located on the serial plate located on the back side of ThermoTek products, available: (1) Model Number, (2) Serial Number, (3) Description of Problem, and (4) Contact Name and Telephone Number.

DISCLAIMER OF WARRANTIES: THERMOTЕК DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THE PRODUCT IS SOLD “AS IS” AND NO WARRANTY OR AFFIRMATION OF FACT, OTHER THAN AS SET FORTH IN THE LIMITED WARRANTY ABOVE, IS MADE OR AUTHORIZED BY THERMOTЕК (WHETHER IN THE PAST OR FUTURE). THERMOTЕК HAS NOT MADE ANY AFFIRMATION OF FACT OR PROMISE RELATING TO THE PRODUCT BEING SOLD THAT HAS BEEN RELIED UPON OR BECOME THE BASIS OF A BARGAIN. THIS LIMITED WARRANTY IS NOT TRANSFERABLE OR MADE TO ANY PERSON OTHER THAN THE ORIGINAL PURCHASER OF THE PRODUCT FROM THERMOTЕК OR THE ORIGINAL PURCHASER OF THE PRODUCT FROM AN AUTHORIZED DISTRIBUTOR OF THERMOTЕК. TO THE EXTENT ANY DISCLAIMER IS NOT PERMITTED BY APPLICABLE LAW, ANY WARRANTY SHALL EXPIRE UPON THE EXPIRATION OF THE LIMITED WARRANTY PROVIDED ABOVE, AND RECOURSE IS LIMITED TO REPAIR OR REPLACEMENT AS PROVIDED ABOVE.

DISCLAIMER AND LIMITATION OF LIABILITY: THE FOREGOING SETS FORTH THERMOTEK'S ONLY OBLIGATIONS AND THE EXCLUSIVE CLAIM AND REMEDY AGAINST THERMOTEK, REGARDLESS OF WHETHER SUCH CLAIMS ARE BASED ON WARRANTY, CONTRACT, TORT OR ANY OTHER THEORY. THERMOTEK DISCLAIMS AND IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR OTHER DAMAGES, COSTS OR LOSS. THERMOTEK'S LIABILITY IS LIMITED TO REPAIR OR REPLACEMENT AS PROVIDED ABOVE. IN THE EVENT THE REPAIR OR REPLACEMENT WARRANTY ABOVE IS DETERMINED TO FAIL OF ITS ESSENTIAL PURPOSE, THE FOREGOING TERMS AND PROVISIONS APPLY EXCEPT THAT, INSTEAD OF REPAIR OR REPLACEMENT, THE EXCLUSIVE REMEDY IS THERMOTEK'S REPAYMENT OF THE PURCHASE PRICE LESS AN AMOUNT EQUAL TO EIGHT PERCENT OF THE PRODUCT'S PURCHASE PRICE MULTIPLIED BY THE NUMBER OF MONTHS THAT THE PRODUCT WAS AVAILABLE TO OR IN USE BY THE PURCHASER.

Other Limitations: ThermoTek assumes no responsibility for the accuracy or completeness of the information presented, which is subject to change without notice. Any mention of non-ThermoTek products or services is for informational purposes only and is not an endorsement, recommendation or representation. If any provision of this Limited Warranty is held to be invalid or unenforceable, such provision shall be fully severable and the remaining portions of the Limited Warranty shall remain in full force and effect.

This page intentionally left blank

PN: OP1DRC3MEN Rev: A [03/2019]



1200 Lakeside Parkway, #200
Flower Mound, TX 75028
Website: www.thermotekusa.com
Tel: (001) 972-874-4949