

How to reboot the 2245 sound level meter, should it become un-responsive

If you, during test and development, experience that the SLM becomes un-responsive, then you may have to reboot it, as described below:



1. Remove all external connections from the SLM, including charger and docking station.
2. Press and hold the center button until the SLM reboots (approximately 40 seconds).
3. Make sure to release the button as soon as the SLM shuts down.
4. Wait for the SLM to start up again.