

## 247 Single-Pole Voltage Tester



**Application:** Voltage Testing  
**Standard:** ISO 57680/6 and VDE 0680/6, for 150-250 V

Code	mm	mm	mm	mm	mm	mm	mm
05005655008	0.5	3.0	70	3.0	1/8"	2 3/4"	5

## 160 i/6 Rack Screwdriver Set Kraftform Plus Series 100 + Rack



**Application:** Kraftform: The Safety Screwdriver. With Lasertip blade + voltage tester + rack  
**Content:** For slotted and Phillips screws  
 6 pieces set in display carton + rack

Code				
05006145006	160 i VDE	1 x 0.4x2.5x80 <sup>1)</sup> ; 1 x 0.5x3.0x100 <sup>1)</sup> ; 1 x 0.8x4.0x100; 1 x 1.0x5.5x125		1
	162 i PH VDE	1 x PH 1x80; 1 x PH 2x100		

<sup>1)</sup> without Lasertip



## How can I prevent the screwdriver from slipping out of the screw?



Screwdrivers can easily slip out of the screw, sometimes damaging expensive or important surfaces. The tip of Wera Lasertip screwdrivers has been microscopically roughened by a laser. This rough surface literally "bites" into the head of the screw. Accidental slipping becomes a thing of the past.

## 160 i/162 i/168 i/7 Rack Screwdriver Set Kraftform Plus Series 100 + Voltage Tester+ Rack



**Application:** Kraftform: The Safety Screwdriver.  
 With Lasertip blade + voltage tester + Rack  
**Content:** For slotted and Phillips screws  
 7 pieces set in display carton + rack

Code				
05346279001	160 i VDE	1 x 0.8x4.0x100; 1 x 1.2x6.5x150		1
	162 i PH VDE	1 x PH 1x80; 1 x PH 2x100		
	168 i VDE	1 x # 2x100		
	170	1 x 0.8x5.0x150		
	4115	1 x 0.5x3.0x65		

## 160 i/168 i/6 Rack Screwdriver Set Kraftform Plus Series 100 + Rack



**Application:** Kraftform: The Safety Screwdriver. With Lasertip blade + rack  
**Content:** For slotted, Phillips, and square socket screws  
 6 pieces set in display carton + rack

Code				
05347777001	160 i VDE	1 x 0.6x3.5x100; 1 x 1.0x5.5x125		1
	162 i PH VDE	1 x PH 1x80; 1 x PH 2x100		
	168 i VDE	1 x # 1x80; 1 x # 2x100		