

SECTION INDEX

Section L: Electrical System

Wiring diagram	L 1
Description of the Electrical System	L 3
Instruments and Controls	L 7
Fuses and Light Bulbs	L 9

Generator

Description and Function	L 11
Operations: 1 LI Replacing Generator Indicator Bulb	L 17
2 LI Testing Current	L 17
3 LI Testing Generator and No-Load Voltage	L 18
4 LI Testing Voltage	L 19
5 LI Testing Regulator Cut Out Switch	L 20
6 LI Removing and Installing Regulator	L 20
7 LI Checking Brushes and Commutator	L 21
8 LI Removing and Installing Generator	L 21
9 LI Disassembling and Assembling Generator	L 22
10 LI Testing Armature	L 22
11 LI Testing Field Coil	L 23
Service Diagnosis	L 25

Starter

Description and Function	L 27
Operations: 12 LI Removing and Installing Starter	L 31
13 LI Removing and Installing Solenoid Switch	L 31
14 LI Testing Brushes and Commutator	L 32
15 LI Disassembling and Assembling Starter	L 33
16 LI Testing Armature	L 35
17 LI Testing Field Coils	L 36
Service Diagnosis	L 37

Battery

Description and Function	L 39
Maintenance	L 40
Operations: 18 LI Charging New Batteries	L 43

Ignition System

Description and Function	L 45
Distributor, Description and Function	L 46
Operations: 19 LI Ignition System Failure	L 48
20 LI Adjusting Breaker Points	L 49
21 LI Installing Breaker Points	L 50
22 LI Adjusting Ignition Timing	L 51
Automatic Ignition Advance	L 52

23 LI	Testing Automatic Advance Mechanism	L 52
	Automatic Advance Curve	L 54
24 LI	Testing Condenser	L 55
25 LI	Removing and Installing Distributor	L 56
	Spark Plug Description and Function	L 57

Lighting System

Headlights, Description and Function	L 59
Operations: 26 LI Replacing Headlights	L 61
27 LI Replacing Headlight Lens	L 61
28 LI Aiming Headlights	L 62
29 LI Testing Headlight Voltage	L 64
Signal System and Dimmer Switch	L 64
Operations: 30 LI Removing and Installing BAL Switch	L 65
31 LI Replacing Parking and Turn Signal Bulbs	L 66
32 LI Replacing Brake, Turn Signal, and Tail Light Bulbs	L 67
33 LI Replacing Back-up and Licence Plate Light Bulbs	L 67
34 LI Replacing Interior Light Bulbs	L 68
35 LI Replacing Instrument Light Bulbs	L 69
36 LI Replacing Back-up Light Switch	L 69
37 LI Replacing Door Contact Switches	L 70

Accessories

Windshield Wipers, Description and Function	L 71
Operations: 38 LI Removing and Installing Wiper Motor	L 71
Horn, Description and Function	L 71
Operations: 39 LI Removing and Installing Horns	L 72
40 LI Tuning Horns	L 72
Horn Button, Light Signal	L 72
41 LI Replacing Fuses	L 73
Service Diagnosis for Windshield Wiper Motor	L 75

Instruments

Speedometer, Description and Function	L 77
Operations: 42 LI Removing and Installing Speedometer	L 78
43 LI Removing and Installing Speedometer Drive Shaft	L 78
44 LI Removing and Installing Tachometer Drive Shaft	L 79
45 LI Removing and Installing Combination Instrument	L 80
46 LI Removing and Installing Fuel Gauge	L 80
47 LI Removing and Installing Oil Pressure Switch	L 80
Oil Pressure Warning Light	L 81
Windshield Washer System	L 81
Radio	L 83
Electrical Data and Specifications	L 85