

SECTION INDEX

Section B: Body

| | |
|--|------|
| Body Construction | B 1 |
| Front and Rear Hoods | |
| Operations: 1 BO Removing and Installing Front Hood | B 3 |
| 2 BO Removing and Installing Hinges for Front Hood | B 4 |
| 3 BO Removing and Installing Front Hood Lock | B 6 |
| 4 BO Removing and Installing Rear Hood | B 7 |
| 5 BO Removing and Installing Hinges for Rear Hood | B 8 |
| 6 BO Removing and Installing Rear Hood Lock | B 8 |
| Function of the Hood Latch | B 4 |
| Emergency Access to Front Hood | B 7 |
| Emergency Access to Rear Hood | B 9 |
| Bumpers | |
| Operations: 7 BO Removing and Installing Front Bumper | B 10 |
| 8 BO Removing and Installing Rear Bumper | B 11 |
| Doors and Windows | |
| Operations: 9 BO Removing and Installing Doors | B 13 |
| 10 BO Removing and Installing Door Panels | B 15 |
| 11 BO Removing and Installing Door Windows | |
| Coupe | B 16 |
| Cabriolet/Hardtop | B 17 |
| Roadster | B 18 |
| 12 BO Removing and Installing Vent Windows | B 20 |
| 13 BO Removing and Installing Door Window Frame | |
| Coupe | B 20 |
| Cabriolet/Hardtop | B 22 |
| Roadster | B 23 |
| 14 BO Removing and Installing Door Lock | B 25 |
| 15 BO Removing and Installing Windshield | |
| Coupe, Cabriolet/Hardtop | B 26 |
| Roadster | B 28 |
| 16 BO Removing and Installing Rear Window | B 31 |
| 17 BO Removing and Installing Side Window | B 31 |
| Door Weather Strip | B 14 |
| Function of the Door Lock | B 24 |
| Seats | |
| Operations: 18 BO Removing and Installing Front Seats | B 33 |
| 19 BO Removing and Installing Folding Back Rests | B 34 |
| Fittings | |
| Operations: 20 BO Removing and Installing Door Handles | B 35 |
| 21 BO Removing and Installing Mouldings | B 36 |
| 22 BO Removing and Installing Grills Hood Ornament, and Porsche Name Plate | B 36 |
| Porsche Name Plate | B 36 |