

Assembly and Installation

The assembly and installation are accomplished in the reverse order of disassembly and removal respectively, observing the following points:

1. Inspect all rubber gaskets and weather strips replacing them where necessary.
2. Check seating of the rubber parts and that the window opens and closes properly.
3. Dust rubber parts with talcum powder.