

Trouble	Cause	Cure
Brakes are squealing	a) Brake surfaces oxidized or very dirty (brake dust) b) Brake shoe surface burnt	a) Clean brake linings and drum b) Replace brake shoes
Brakes are rattling	a) Brake surface has uneven contact, only contact on outer ends b) Brake shoes are not parallel to brake surface. Brake back plate bent c) Poor tires, tend to rattling noises d) Brake drums out-of-true e) Excessive play in wheel suspension or back plate, or loose	a) Adapt brake shoe radius to brake drum radius. Check whether surface appearance print is correct b) Replace brake back plate c) Replace poor tires by new ones d) Machine brake drums or replace e) Adjust bearing play or collar pin play. Replace worn parts. Tighten loose bolts
Stop light does not go out	a) No play at foot brake pedal, brake system	a) Bypass port covered, adjust play on brake pedal