



| No. | Item | Remark |
|------|--|--------------------|
| 1 | Starter | |
| 2 | Generator | |
| 3 | Regulator | |
| 4 | Distributor | |
| 6 | Ignition coil | |
| 8 | Spark plug | |
| 9 | Spark plug socket | |
| 13 | Battery | |
| 15 | Headlight | |
| 15 a | Sealed Beam | with parking light |
| 16 | Signal light | U. S. A. -Export |
| 18 | Brake tail light | |
| 19 | License plate light | |
| 21 | Back up light | |
| 22 | Interior light, Coupé 2 ea., Cabriolet, Hardtop 1 ea. | |
| 23 | Fog lights | optinal |
| 27 | Oil pressure warning light | Combination inst. |
| 28 | Generator warning light | Combination inst. |
| 29 | Turn signal indicator light | on tachometer |
| 30 | High beam indicator light | on tachometer |
| 31 | Parking light indicator light | on tachometer |
| 37 | Ignition-starter switch | |
| 39 | Head light switch | |
| 41 | Brake light switch | |
| 42 | Back-up light switch | |
| 43 | Oil pressure switch | |
| 44 | Signal dimmer switch | |
| 45 | Door contact switches | |
| 46 | Fog light switch | optinal |
| 48 | Horn button | |
| 50 | Windshield wiper switch | |
| 52 | Horn relay | |
| 53 | Light signal relay | |
| 55 | Turn signal interrupter | |
| 56 | Fog light relay | optinal |
| 60 | Accessory socket | |
| 61 | Fuse box | |
| 63 | Forward wire loom | |
| 64 | Battery ground strap | |
| 65 | Instrument wire loom | |
| 66 | Rear wire loom | |
| 67 | Ignition cables | |
| 69 | Plug connector | |
| 76 | Two tone horn | |
| 80 | Windshield wiper | |
| 82 | Cigarette lighter | |
| 83 | Tachometer | |
| 89 | Speedometer | |
| 90 | Combination instrument | |
| 92 | Electric clock | |
| 93 | Fuel gauge sender | |
| 94 | Oil thermometer sender | |