

23 LI	Testing Automatic Advance Mechanism	L 52
	Automatic Advance Curve	L 54
24 LI	Testing Condenser	L 55
25 LI	Removing and Installing Distributor	L 56
	Spark Plug Description and Function	L 57

Lighting System

Headlights, Description and Function	L 59
Operations: 26 LI Replacing Headlights	L 61
27 LI Replacing Headlight Lens	L 61
28 LI Aiming Headlights	L 62
29 LI Testing Headlight Voltage	L 64
Signal System and Dimmer Switch	L 64
Operations: 30 LI Removing and Installing BAL Switch	L 65
31 LI Replacing Parking and Turn Signal Bulbs	L 66
32 LI Replacing Brake, Turn Signal, and Tail Light Bulbs	L 67
33 LI Replacing Back-up and Licence Plate Light Bulbs	L 67
34 LI Replacing Interior Light Bulbs	L 68
35 LI Replacing Instrument Light Bulbs	L 69
36 LI Replacing Back-up Light Switch	L 69
37 LI Replacing Door Contact Switches	L 70

Accessories

Windshield Wipers, Description and Function	L 71
Operations: 38 LI Removing and Installing Wiper Motor	L 71
Horn, Description and Function	L 71
Operations: 39 LI Removing and Installing Horns	L 72
40 LI Tuning Horns	L 72
Horn Button, Light Signal	L 72
41 LI Replacing Fuses	L 73
Service Diagnosis for Windshield Wiper Motor	L 75

Instruments

Speedometer, Description and Function	L 77
Operations: 42 LI Removing and Installing Speedometer	L 78
43 LI Removing and Installing Speedometer Drive Shaft	L 78
44 LI Removing and Installing Tachometer Drive Shaft	L 79
45 LI Removing and Installing Combination Instrument	L 80
46 LI Removing and Installing Fuel Gauge	L 80
47 LI Removing and Installing Oil Pressure Switch	L 80
Oil Pressure Warning Light	L 81
Windshield Washer System	L 81
Radio	L 83
Electrical Data and Specifications	L 85