



Fig. 67

- ① Steering box, complete
- ② Steering drop arm
- ③ Steering box cover
- ④ Adjusting screw
- ⑤ Lock nut for adjusting screw
- ⑥ Oil filler plug
- ⑦ Rocker shaft
- ⑧ Thrust pin
- ⑨ Steering peg roller bearing
- ⑩ Thrust washer
- ⑪ Compression spring
- ⑫ Thrust washers
- ⑬ Castle nut
- ⑭ Radial oil seal

- ⑮ Steering box
- ⑯ Dowel pin
- ⑰ Clamp
- ⑱ Lock plate
- ⑲ Seal
- ⑳ Bearing bushing
- ㉑ Ball race, top
- ㉒ Ball cage
- ㉓ Steering worm
- ㉔ Ball cage
- ㉕ Ball race, bottom
- ㉖ Spacer
- ㉗ Adjusting washer
- ㉘ End plate