

SECTION INDEX

Group R: Rear Axle and Transmission

Description of Rear Axle and Transmission	R 1
Components of the Synchronizing Mechanism	R 5
Porsche Synchronized Transmission — Rear Axle (Section View)	R 7
Transmission Diagram 356 B/1600 Coupe, Cabriolet/Hardtop, Roadster	R 9
Transmission Diagram 356 B/1600 S Coupe, Cabriolet/Hardtop, Roadster	R 11
Transmission Diagram 356 B/1600 S—90 Coupe, Cabriolet/Hardtop, Roadster	R 13
Transmission Diagram 356 B/1600 GS—Carrera GT (Gran Turismo), Europe	R 15
Transmission Diagram 356 B/1600 GS—Carrera GT (Gran Turismo), Special Ratio for Airport Races ..	R 17
Transmission Diagram 356 B/1600 GS—Carrera GT (Gran Turismo), USA	R 19
Transmission with Rear Axle and Rear Suspension without Compensating Spring	R 21
Transmission with Rear Axle and Rear Suspension with Compensating Spring	R 22
Transmission and Rear Axle Installed, Bottom View	R 23

Operations:

1 RA Removing and Installing Rear Axle	R 24
2 RA Disassembling and Assembling Transmission	R 28
Arrangement of Gear Locks	R 33
3 RA Disassembling Pinion Shaft	R 36
4 RA Determining Shims	R 37
5 RA Assembling Synchronizing Mechanism	R 38
6 RA Assembling Pinion Shaft	R 40
7 RA Reconditioning Main Shaft	R 43
8 RA Reconditioning Differential	R 47
9 RA Disassembling and Assembling Intermediate Plate	R 51
10 RA Adjusting Ring and Pinion Gears	R 54
11 RA Adjusting Ring Gear	R 56
12 RA Computing Spacers for Differential	R 57
13 RA Adjusting Pinion Gear	R 59
14 RA Verifying Adjustment of Ring Gear	R 60
15 RA Removing and Installing Transmission Cover	R 61
16 RA Replacing Rear Wheel Bearings and Seals	R 62
17 RA Removing and Installing Rear Axle Tubes	R 65
18 RA Removing and Installing Transmission Carrier and Rubber Mounts	R 66
19 RA Installing Main Shaft Seal	R 67
20 RA Removing and Installing Clutch Pivot Shaft	R 68
21 RA Removing and Installing Gear Shift Linkage	R 69

Rear Wheel Suspension

22 RA Removing and Installing Torsion Bars	R 72
23 RA Adjusting Rear Wheel Suspension	R 74
24 RA Removing and Installing Shock Absorbers	R 75
Summary of Tolerances for Group R	R 76
Torque Values for Transmission Housing	R 83

Special Tools for Rear Axle and Transmission	R 85
--	------