

Seats

Removing and Installing Front Seats

18 B0

Removal

1. Remove rubber floor mat in front of the seat.
2. Press seat catch lever and move seat fully forward.
3. Remove seat.



Installation

Before installing the seat, grease the rails and inspect the surfaces of the sliding parts.

Fig. 88