

REMOVING AND INSTALLING FUEL SELECTOR VALVE

Installation

Install the valve by reversing the removal procedure and observing the following points:

The fuel selector valve has to be removed when cleaning the tank or the tank wire screen.

Removal

1. Remove tank and drain gasoline.
2. Remove nut which holds fuel selector valve, withdraw valve from tank.
3. Blow out wire screen with compressed air.
1. Thoroughly clean fuel tank.
2. Install new gaskets which seal wire screen flange (one gasket on each side of the flange).
3. Make certain that fuel valve stub lines up with selector lever; if necessary, loosen fuel valve retaining nut and slightly turn the fuel valve to proper position.
4. Check all connections for possible leaks.