

## Cylinders and Pistons

Operations:	32 EN	Removing and Installing Cylinders .....	E 51
	33 EN	Checking Cylinders .....	E 52
	34 EN	Removing and Installing Pistons .....	E 54
	35 EN	Checking Pistons .....	E 57
Pistons Dimensions and Types .....			E 58

## Crankcase

Operations:	36 EN	Disassembling and Assembling Crankcase .....	E 59
	37 EN	Removing and Installing Distributor Drive Shaft .....	E 62
	38 EN	Removing and Installing No. 4 Bearing Oil Seal .....	E 64
	39 EN	Removing and Installing No. 4 Bearing .....	E 64
	40 EN	Removing and Installing Timing Case Cover .....	E 66
	41 EN	Removing and Installing Flywheel .....	E 67
	42 EN	Removing and Installing V-belt Pulley .....	E 69
	43 EN	Removing and Installing Crankshaft Oil Seal at Flywheel .....	E 69
	44 EN	Removing and Installing Camshaft .....	E 70
	45 EN	Removing and Installing Crankshaft and Connecting Rods .....	E 71
	46 EN	Removing and Installing Connecting Rods .....	E 72
	47 EN	Replacing Piston Pin Bushings .....	E 74
	48 EN	Measuring and Aligning Connecting Rods .....	E 74

## Crankshaft

Operations:	49 EN	Disassembling and Assembling Crankshaft .....	E 77
	50 EN	Measuring Adjusting Crankshaft End Play .....	E 79
	51 EN	Grinding Crankshafts .....	E 80
Crankshaft and Bearing Dimensions .....			E 81

## Breaking-in Acceptance Standards

Operations:	52 EN	Breaking-in and Testing Engines .....	E 83
	53 EN	Rebuilt Engines .....	E 83
	54 EN	Testing During Break-in .....	E 84
	55 EN	Final Inspection .....	E 85
	56 EN	Testing Partly Rebuilt Engines .....	E 85
		Performance and Fuel Consumption 1600 Engine .....	E 87
		Performance and Fuel Consumption 1600 S Engine .....	E 89

## Clutch

Description .....			E 91
Operations:	57 EN	Removing and Installing Clutch .....	E 92
	58 EN	Disassembling Clutch .....	E 93
	59 EN	Pressure Plate Inspection .....	E 94
	60 EN	Assembling Clutch .....	E 95
	61 EN	Clutch Plate Inspection .....	E 97
	62 EN	Removing and Installing Clutch Release Bearing .....	E 98
	63 EN	Removing and Installing Clutch Cable .....	E 99
	64 EN	Clutch Adjustment .....	E 100
	65 EN	Testing and Adjusting Clutch Pedal Travel .....	E 101
Service Diagnosis .....			E 103
Torque Values for Cap Screws and Nuts of 1600 and 1600 S Engines .....			E 105
Tolerances and Wear Limits .....			E 107
Special Tools and their Use .....			E 117