

## 5 Ti

### Reconditioning Wheel Brake Cylinder

#### Disassembly

1. Remove boots.
2. Take out plungers, pistons, piston cups, spring seats and stop spring.
3. Unscrew bleeder valve.
1. Use only spirit or brake fluid to clean all parts.
2. Check all parts for wear and damage. Replace worn parts.
3. The cleaned and dried pistons must move easily in the wheel brake cylinder in both directions. (Clearance between cylinder bore and piston max. .0102" = 0.26 mm.)

#### Assembly

The wheel brake cylinder is installed in reverse order, observing the following points:

4. Prior to assembly, the pistons, cylinder wall and piston cup should be coated with a very thin film of genuine Ate brake cylinder paste.