

RECONDITIONING PINION SHAFT

3 RA

Disassembling Pinion Shaft

Special Tools:

- | | | | |
|-------|--|--------|---|
| P 31 | Holder for pinion shaft while tightening castle nut | P 67 | Press guide for removing roller bearing from pinion shaft |
| P 31a | Guide ring used with tool P 31 to tighten castle nut of pinion shaft | VW 400 | Hydraulic press |
| P 39 | Pinion shaft collar | VW 401 | Plate for various press operations |
| P 41 | Assembly ring for roller bearings on pinion shaft | VW 409 | Arbor, general application |
| P 42 | Torque wrench | VW 410 | Arbor, general application |
| P 46 | Socket used with P 42 to tighten castle nut on pinion shaft | VW 412 | Arbor, general application |
| | | VW 421 | Tube, 28 mm dia. 100 mm long, general application |

Disassembly

1. Disassemble transmission (2 RA).
2. Press pinion shaft out of complete gear train using tools VW 400, VW 401 and VW 410.
3. Remove spacer 4 mm and washer 2 mm from 4th gear with needle bearing and bushing.
4. Remove sliding sleeve and spider.
5. Remove third gear with needle bearing and bearing sleeve.
6. Remove washer between 2nd and 3rd gear.
7. Remove 2nd gear, rollers, cage and bearing sleeve.
8. Remove sliding sleeve and spider.
9. Remove 1st gear, rollers, and cage.
10. Press bearing sleeve, thrust washer, and roller bearing from pinion shaft using tools P 67, VW 400, VW 401, and VW 402.
11. Note the number and thickness of spacers between roller bearing and thrust washer.




Fig. 50




Fig. 51