

SECTION INDEX

Group T: Brakes, Wheels and Tires

Description of the Hydraulic Brakes	T 1
Master Cylinder:	
General, Description	T 3
Procedures: 1 Ti Removing and installing master cylinder	T 6
2 Ti Reconditioning master cylinder	T 7
Wheel Brake Cylinder:	
General	T 9
Procedures: 3 Ti Removing and installing front wheel brake cylinder	T 10
4 Ti Removing and installing rear wheel brake cylinder	T 11
5 Ti Reconditioning wheel brake cylinder	T 12
Hydraulic System:	
Brake Hoses, General	T 13
Procedure: 6 Ti Exchanging brake hose	T 13
Tubing	T 14
Wheel Brake:	
General	T 15
Procedures: 7 Ti Replacing front brake shoes	T 16
8 Ti Replacing rear brake shoes	T 16
Special Notes on Repair Work on the Brake System	T 17
Procedures: 9 Ti Removing and installing front brake back plates	T 17
10 Ti Removing and installing rear brake back plates	T 18
11 Ti Removing and installing parking brake cables	T 19
12 Ti Overhauling brake drum	T 21
Filling, Bleeding and Adjusting Brake:	
General	T 22
Procedures: 13 Ti Bleeding system without bleeding and refilling device	T 22
14 Ti Bleeding system using bleeding and refilling device	T 22
15 Ti Flushing the system	T 24
16 Ti Adjusting wheel brakes	T 24
17 Ti Readjusting parking brake	T 25
18 Ti Adjusting parking brake	T 25
Hydraulic brake troubles and their cure	T 26
Wheels:	
General	T 29
Procedures: 19 Ti Changing wheels	T 29
20 Ti Replacing broken spring clamps	T 30
Damaged rims	T 30
Tires:	
General	T 31
Procedures: 21 Ti Mounting and dismounting tires and tubes	T 31
22 Ti Mounting retaining spring for tube valve	T 32
23 Ti Checking tires	T 33
24 Ti Balancing wheels	T 34
Special tools to Group T	T 39
Summary of tolerances to Group T	T 45