

SECTIONAL INDEX

Section S: Steering Gear and Front Axle

	Page
Description of Front Axle	S 1
Front Axle, complete, Sectional View	S 3
Procedures: 1 ST Disassembling and Assembling Front Axle	S 5
2 ST Removing and Installing Front Wheel Brake Drum	S 6

Front Wheel Bearing

Procedures: 3 ST Removing and Installing Front Wheel Bearings	S 9
4 ST Adjusting Front Wheel Bearings	S 11

Front Wheel Suspension

Procedures: 5 ST Adjusting Suspension Arm Link Pins	S 13
6 ST Removing and Installing Suspension Arm Link with Stub Axle	S 14
7 ST Removing and Installing Suspension Arm Link Pin Bushings	S 16
8 ST Removing and Installing Stub Axle	S 17
9 ST Removing and Installing King Pin Bushings	S 19

Front Wheel Springing

Procedures: 10 ST Removing and Installing Suspension Arms	S 21
11 ST Replacing Shock Absorber Mounting Stud on Suspension Arm	S 23
12 ST Removing and Installing Torsion Bars	S 23
13 ST Checking and Adjusting Angular Position of Torsion Bars	S 25

Suspension Arm Bearing

Procedures: 14 ST Removing and Installing Plastic Bushing and Bushing for Needle Bearing	S 27
15 ST Checking Front Axle Tube	S 28

Shock Absorber and Anti-Roll Bar

General Information, Inspection and Maintenance	S 29
Procedures: 16 ST Removing and Installing Shock Absorber	S 29
17 ST Adjusting KONI Shock Absorbers	S 30
18 ST Removing and Installing Rubber Bushing for Shock Absorber	S 31
19 ST Removing and Installing Anti-Roll Bar	S 31

Steering

Description of ZF Single-Peg Steering, General Information, Lubrication, Maintenance	S 33
Explosion View of Steering Gear	S 34
Procedures: 20 ST Removing and Installing Tie Rods	S 35
21 ST Removing and Installing Steering Damper	S 36
22 ST Removing and Installing Steering Wheel	S 36
23 ST Removing and Installing Steering Column	S 37
24 ST Removing and Installing Steering Column Tube	S 38
25 ST Removing and Installing Steering Gear	S 39
26 ST Disassembling and Assembling Steering Gear	S 39
27 ST Position of Pressure Point	S 42
28 ST Adjusting Pressure Point	S 42
29 ST Removing and Installing Steering Peg (Mounted in Roller Bearings)	S 43
Steering Troubles and Their Cure	S 45
Special Tools to Group „Front Axle“	S 47
Summary of Tolerances and Wear Limits to Group ST (Front Axle and Steering)	S 51