

## Replacing Fuses

41 LI

The fuse box is centrally located under the instrument panel and contains all the fuses for the electrical equipment.

Fuses may be removed by pushing downward and pulling out.

In the event that a fuse burns out it is of primary importance to locate the cause before installing a

new fuse. The fuses serve to prevent serious damage to the wiring and accessories and can therefore indicate possibly dangerous damage which must be corrected before replacing the fuse. Never use fuses of greater capacity, pieces of metal foil, or wires. It is advisable to carry a few spare 8/15 ampere and 25/40 ampere fuses.