



Elektrobit

EB tresos[®] AutoCore Generic 8 DLT documentation

product release 8.8.0



Elektrobit Automotive GmbH
Am Wolfsmantel 46
91058 Erlangen, Germany
Phone: +49 9131 7701 0
Fax: +49 9131 7701 6333
Email: info.automotive@elektrobit.com

Technical support

<https://www.elektrobit.com/support>

Legal disclaimer

Confidential information.

ALL RIGHTS RESERVED. No part of this publication may be copied in any form, by photocopy, microfilm, retrieval system, or by any other means now known or hereafter invented without the prior written permission of Elektrobit Automotive GmbH.

All brand names, trademarks, and registered trademarks are property of their rightful owners and are used only for description.

Copyright 2020, Elektrobit Automotive GmbH.

Table of Contents

1. Overview of EB tresos AutoCore Generic 8 DLT documentation	12
2. Supported features	13
2.1. Supported Dlt (Base) features	13
2.2. Supported Dlt (feature package 1) features	14
3. ACG8 DLT release notes	16
3.1. Overview	16
3.2. Scope of the release	16
3.2.1. Configuration tool	16
3.2.2. AUTOSAR modules	16
3.2.3. EB (Elektrobit) modules	16
3.2.4. MCAL modules and EB tresos AutoCore OS	17
3.3. Module release notes	17
3.3.1. Dlt module release notes	17
3.3.1.1. Change log	17
3.3.1.2. New features	23
3.3.1.3. EB-specific enhancements	23
3.3.1.4. Deviations	25
3.3.1.5. Limitations	45
3.3.1.6. Open-source software	49
4. ACG8 DLT user guide	50
4.1. Overview	50
4.2. Background Information	50
4.2.1. Dlt core functions	50
4.2.1.1. Generic creation of log and trace messages	50
4.2.1.2. Generic reception of log and trace messages	50
4.2.1.3. Buffering and filtering management	51
4.2.1.4. Message filtering based on log level and trace status	51
4.2.1.5. Generic handling of control requests	52
4.2.1.6. Parallel transmission of multiple frames within one PDU	52
4.2.1.7. Handling of log channels	52
4.2.2. Dlt service interface according to AUTOSAR 4.2.1 and AUTOSAR 4.3.1	53
4.2.2.1. AUTOSAR 4.2.1/4.2.2	53
4.2.2.2. AUTOSAR 4.3.1	53
4.2.2.3. Available APIs	55
4.2.2.4. Endianness of Appld, ContextId and log channel name	57
4.2.2.5. Multiple instances of Appld/ContextId tuples	58
4.2.2.6. Registering software components and contexts using Dlt_RegisterContext()	58
4.2.2.7. Unregistering software components and contexts using Dlt_UnregisterContext() (only for AUTOSAR 4.3.1)	58

4.2.2.8. Sending log and trace messages from SWCs using Dlt_SendLogMessage() and Dlt_SendTraceMessage()	59
4.2.2.9. Notifying SWCs about log level and trace status changes	59
4.2.2.10. Dlt control by SWCs at run-time (only for AUTOSAR 4.3.1)	59
4.2.3. Virtual function bus tracing	60
4.2.3.1. Interface for VFB trace	60
4.2.3.2. Support for generating and implementing RTE hook functions	61
4.2.4. Persistent storage of configuration	61
4.2.4.1. Storing the run-time configuration in non-volatile (NV) memory	61
4.2.4.1.1. Length of NvM blocks	64
4.2.4.1.2. Number of NvM blocks	65
4.2.4.1.3. Dlt_ApplGetConfigFactoryDefault() call-out	65
4.2.5. Dlt assistant (tooling)	66
4.2.5.1. Support for generating Dlt ports according to service needs	66
4.2.6. Message transmission	66
4.2.6.1. Data transmission via a network-specific communication channel	66
4.2.6.2. Segmentation/adaptation of log or trace messages	66
4.2.6.3. Delay of message transmission	67
4.2.7. Verbose mode	67
4.2.7.1. Transmitting messages in verbose mode	67
4.2.7.2. Support of a configuration switch to enable/disable verbose mode	67
4.2.7.3. Building Dlt messages with extended headers [SWS_Dlt_00457]	67
4.2.8. Control messages	68
4.2.8.1. Controlling the Dlt via one communication channel by means of control messages	68
4.2.8.1.1. Dlt control messages via C APIs	68
4.2.8.1.1.1. Dlt_GetSoftwareVersion() call-out	70
4.2.8.1.1.2. Dlt_AppGetEcudAddress() call-out	70
4.2.8.1.1.3. Dlt_GetLogInfo() buffer size	71
4.2.8.1.2. Dlt control messages via communication services	72
4.2.9. Support for synchronized time-base	72
4.2.9.1. Support of synchronized time stamps/chronological order of log and trace data	72
4.2.10. Support for BSW distribution	73
4.2.10.1. Supported APIs	73
4.2.10.2. BSW distribution initialization	75
4.2.11. Traffic shaper	75
4.2.11.1. Support of bandwidth management	75
4.2.11.2. Configurable bandwidth limits per communication channel	76
4.2.11.3. Delaying of message transmission if bandwidth is exhausted	76
4.3. Configuring the Dlt module	76
4.3.1. Configuring the Rte for AUTOSAR 4.2.1 and 4.2.2	76

4.3.2. Configuring Dlt for AUTOSAR 4.3.1	78
4.3.2.1. Configuring Dlt functionalities	79
4.3.2.1.1. Configuring the log channels	79
4.3.2.1.2. Configuring the trace status	80
4.3.2.1.3. Configuring the log level	80
4.3.3. Configuring the Dlt service needs	81
4.3.4. Configuring VFB tracing	81
4.3.5. Configuring BSW distribution	82
4.3.5.1. Configuring the Rte for Dlt BSW distribution	83
4.3.6. Configuring the Dlt main function	83
5. ACG8 DLT module references	85
5.1. Overview	85
5.1.1. Notation in EB module references	85
5.1.1.1. Default value of configuration parameters	85
5.1.1.2. Range information of configuration parameters	85
5.2. Dlt	86
5.2.1. Configuration parameters	86
5.2.1.1. CommonPublishedInformation	87
5.2.1.2. DltGeneral	90
5.2.1.3. DltDemEventParameterRefs	98
5.2.1.4. ReportToDem	98
5.2.1.5. DltMemory	100
5.2.1.6. DltVfbTrace	102
5.2.1.7. DltConfigSet	103
5.2.1.8. DltLogOutput	103
5.2.1.9. DltLogChannel	104
5.2.1.10. DltTxPdu	107
5.2.1.11. DltLogChannelAssignment	108
5.2.1.12. DltLogLevelSetting	108
5.2.1.13. DltLogLevelThreshold	109
5.2.1.14. DltTraceStatusSetting	110
5.2.1.15. DltTraceStatusAssignment	111
5.2.1.16. DltMultipleConfigurationContainer	111
5.2.1.17. DltBandwidth	113
5.2.1.18. DltMessageFiltering	114
5.2.1.19. DltBswDistribution	116
5.2.1.20. DltSatelliteCore	118
5.2.1.21. DltPduConfig	118
5.2.1.22. DltServiceAPI	120
5.2.1.23. DltProtocol	121
5.2.1.24. DltDefensiveProgramming	124
5.2.1.25. DltSwc	127

5.2.1.26. DltSwcContext	130
5.2.1.27. PublishedInformation	131
5.2.2. Application programming interface (API)	132
5.2.2.1. Type definitions	132
5.2.2.1.1. Dlt_ApplicationIDType	132
5.2.2.1.2. Dlt_AssignmentOperation	132
5.2.2.1.3. Dlt_AssignmentOperationType	132
5.2.2.1.4. Dlt_ContextIDType	132
5.2.2.1.5. Dlt_CtrlReturnType	133
5.2.2.1.6. Dlt_FilterMessagesType	133
5.2.2.1.7. Dlt_GlobalLogStatusType	133
5.2.2.1.8. Dlt_Internal_ApplicationIDType	133
5.2.2.1.9. Dlt_Internal_ContextIDType	133
5.2.2.1.10. Dlt_MessageArgumentCountType	133
5.2.2.1.11. Dlt_MessageCommonInfoType	133
5.2.2.1.12. Dlt_MessageControlInfoType	134
5.2.2.1.13. Dlt_MessageIDType	134
5.2.2.1.14. Dlt_MessageLogInfoType	134
5.2.2.1.15. Dlt_MessageLogLevelType	134
5.2.2.1.16. Dlt_MessageLogTraceType	135
5.2.2.1.17. Dlt_MessageNetworkTraceInfoType	135
5.2.2.1.18. Dlt_MessageOptionsType	135
5.2.2.1.19. Dlt_MessageTraceInfoType	135
5.2.2.1.20. Dlt_MessageTraceStatusType	135
5.2.2.1.21. Dlt_MessageTraceType	135
5.2.2.1.22. Dlt_MessageTypeType	136
5.2.2.1.23. Dlt_MsgLengthType	136
5.2.2.1.24. Dlt_ReturnType	136
5.2.2.1.25. Dlt_SessionIDType	136
5.2.2.1.26. Dlt_TxConnectionType	136
5.2.2.2. Macro constants	137
5.2.2.2.1. DLT_AR_RELEASE_MAJOR_VERSION	137
5.2.2.2.2. DLT_AR_RELEASE_MINOR_VERSION	137
5.2.2.2.3. DLT_AR_RELEASE_REVISION_VERSION	137
5.2.2.2.4. DLT_ASSIGN_ADD	137
5.2.2.2.5. DLT_ASSIGN_REMOVE	137
5.2.2.2.6. DLT_CONTROL_REQUEST	138
5.2.2.2.7. DLT_CONTROL_RESPONSE	138
5.2.2.2.8. DLT_CTRL_ERROR	138
5.2.2.2.9. DLT_CTRL_NOT_SUPPORTED	138
5.2.2.2.10. DLT_CTRL_OK	138
5.2.2.2.11. DLT_E_COM_FAILURE	138

5.2.2.2.12. DLT_E_CONTEXT_ALREADY_REG	138
5.2.2.2.13. DLT_E_CORE_SYNC_FAILED	139
5.2.2.2.14. DLT_E_ERROR_IN_PROV_SERVICE	139
5.2.2.2.15. DLT_E_ERROR_TO_MANY_CONTEXT	139
5.2.2.2.16. DLT_E_ERROR_UNKNOWN	139
5.2.2.2.17. DLT_E_IF_BUSY	139
5.2.2.2.18. DLT_E_IF_NOT_AVAILABLE	139
5.2.2.2.19. DLT_E_MSG_LOOSE	140
5.2.2.2.20. DLT_E_MSG_TOO_LARGE	140
5.2.2.2.21. DLT_E_NOT_INITIALIZED	140
5.2.2.2.22. DLT_E_NOT_INITIALIZED_PERSISTENT	140
5.2.2.2.23. DLT_E_NOT_IN_VERBOSE_MODE	140
5.2.2.2.24. DLT_E_NOT_SUPPORTED	140
5.2.2.2.25. DLT_E_OK	140
5.2.2.2.26. DLT_E_PARAM_POINTER	141
5.2.2.2.27. DLT_E_PENDING	141
5.2.2.2.28. DLT_E_REQUEST_NOT_ACCEPTED	141
5.2.2.2.29. DLT_E_UNKNOWN_SESSION_ID	141
5.2.2.2.30. DLT_E_WRONG_PARAMETERS	141
5.2.2.2.31. DLT_FILTER_MESSAGES_OFF	141
5.2.2.2.32. DLT_FILTER_MESSAGES_ON	142
5.2.2.2.33. DLT_GETLOGININFO_OPTIONS_NO_DESC	142
5.2.2.2.34. DLT_GETLOGININFO_OPTIONS_WITH_DESC	142
5.2.2.2.35. DLT_LOGGING_DISABLED	142
5.2.2.2.36. DLT_LOGGING_ENABLED	142
5.2.2.2.37. DLT_LOG_DEBUG	142
5.2.2.2.38. DLT_LOG_DEFAULT	142
5.2.2.2.39. DLT_LOG_ERROR	143
5.2.2.2.40. DLT_LOG_FATAL	143
5.2.2.2.41. DLT_LOG_INFO	143
5.2.2.2.42. DLT_LOG_OFF	143
5.2.2.2.43. DLT_LOG_VERBOSE	143
5.2.2.2.44. DLT_LOG_WARN	143
5.2.2.2.45. DLT_MODULE_ID	144
5.2.2.2.46. DLT_NW_TRACE_CAN	144
5.2.2.2.47. DLT_NW_TRACE_FLEXRAY	144
5.2.2.2.48. DLT_NW_TRACE_IPC	144
5.2.2.2.49. DLT_NW_TRACE_MOST	144
5.2.2.2.50. DLT_SID_ComCopyRxData	144
5.2.2.2.51. DLT_SID_ComCopyTxData	144
5.2.2.2.52. DLT_SID_ComRxIndication	145
5.2.2.2.53. DLT_SID_ComStartOfReception	145

5.2.2.2.54. DLT_SID_GetComInterfaceMaxBandwidth	145
5.2.2.2.55. DLT_SID_GetDefaultLogLevel	145
5.2.2.2.56. DLT_SID_GetDefaultTraceStatus	145
5.2.2.2.57. DLT_SID_GetEcuidAddress	145
5.2.2.2.58. DLT_SID_GetGlobalLogging	146
5.2.2.2.59. DLT_SID_GetLogChannelNames	146
5.2.2.2.60. DLT_SID_GetLogChannelThreshold	146
5.2.2.2.61. DLT_SID_GetLogInfo	146
5.2.2.2.62. DLT_SID_GetLogLevel	146
5.2.2.2.63. DLT_SID_GetMessageFilteringStatus	146
5.2.2.2.64. DLT_SID_GetTraceStatus	146
5.2.2.2.65. DLT_SID_GetUseECUID	147
5.2.2.2.66. DLT_SID_GetUseExtendedHeader	147
5.2.2.2.67. DLT_SID_GetUseSessionID	147
5.2.2.2.68. DLT_SID_GetVerboseModeStatus	147
5.2.2.2.69. DLT_SID_GetVersionInfo	147
5.2.2.2.70. DLT_SID_Init	147
5.2.2.2.71. DLT_SID_InternalReadFromDataSetApild	148
5.2.2.2.72. DLT_SID_InternalReadFromNativeApild	148
5.2.2.2.73. DLT_SID_InternalRegisterContext	148
5.2.2.2.74. DLT_SID_InternalWriteToDataSetApild	148
5.2.2.2.75. DLT_SID_InternalWriteToNativeApild	148
5.2.2.2.76. DLT_SID_NvMSingleBlockCallbackNative	148
5.2.2.2.77. DLT_SID_RegisterContext	148
5.2.2.2.78. DLT_SID_ResetToFactoryDefault	149
5.2.2.2.79. DLT_SID_SendLogMessage	149
5.2.2.2.80. DLT_SID_SendTraceMessage	149
5.2.2.2.81. DLT_SID_SetComInterfaceMaxBandwidth	149
5.2.2.2.82. DLT_SID_SetDefaultLogLevel	149
5.2.2.2.83. DLT_SID_SetDefaultTraceStatus	149
5.2.2.2.84. DLT_SID_SetGlobalLogging	150
5.2.2.2.85. DLT_SID_SetLogChannelAssignment	150
5.2.2.2.86. DLT_SID_SetLogChannelThreshold	150
5.2.2.2.87. DLT_SID_SetLogLevel	150
5.2.2.2.88. DLT_SID_SetMessageFiltering	150
5.2.2.2.89. DLT_SID_SetTraceStatus	150
5.2.2.2.90. DLT_SID_SetUseECUID	150
5.2.2.2.91. DLT_SID_SetUseExtendedHeader	151
5.2.2.2.92. DLT_SID_SetUseSessionID	151
5.2.2.2.93. DLT_SID_SetVerboseMode	151
5.2.2.2.94. DLT_SID_SingleBlockCallbackDataSet	151
5.2.2.2.95. DLT_SID_StoreConfiguration	151

5.2.2.2.96. DLT_SID_StorePersistent	151
5.2.2.2.97. DLT_SID_TriggerTransmit	152
5.2.2.2.98. DLT_SID_UnregisterContext	152
5.2.2.2.99. DLT_SW_MAJOR_VERSION	152
5.2.2.2.100. DLT_SW_MINOR_VERSION	152
5.2.2.2.101. DLT_SW_PATCH_VERSION	152
5.2.2.2.102. DLT_TRACE_FUNCTION_IN	152
5.2.2.2.103. DLT_TRACE_FUNCTION_OUT	152
5.2.2.2.104. DLT_TRACE_STATE	153
5.2.2.2.105. DLT_TRACE_STATUS_DEFAULT	153
5.2.2.2.106. DLT_TRACE_STATUS_OFF	153
5.2.2.2.107. DLT_TRACE_STATUS_ON	153
5.2.2.2.108. DLT_TRACE_VARIABLE	153
5.2.2.2.109. DLT_TRACE_VFB	153
5.2.2.2.110. DLT_TYPE_APP_TRACE	154
5.2.2.2.111. DLT_TYPE_CONTROL	154
5.2.2.2.112. DLT_TYPE_LOG	154
5.2.2.2.113. DLT_TYPE_NW_TRACE	154
5.2.2.2.114. DLT_VENDOR_ID	154
5.2.2.2.115. Dlt_GetDefaultLogLevel	154
5.2.2.2.116. Dlt_GetDefaultTraceStatus	154
5.2.2.2.117. Dlt_GetLogChannelNames	155
5.2.2.2.118. Dlt_GetLogChannelThreshold	155
5.2.2.2.119. Dlt_GetLogInfo	155
5.2.2.2.120. Dlt_GetTraceStatus	155
5.2.2.2.121. Dlt_NW_TRACE_ETHERNET	155
5.2.2.2.122. Dlt_NW_TRACE_SOMEIP	155
5.2.2.2.123. Dlt_RegisterContext	156
5.2.2.2.124. Dlt_ResetToFactoryDefault	156
5.2.2.2.125. Dlt_SendLogMessage	156
5.2.2.2.126. Dlt_SendTraceMessage	156
5.2.2.2.127. Dlt_SetDefaultLogLevel	156
5.2.2.2.128. Dlt_SetDefaultTraceStatus	156
5.2.2.2.129. Dlt_SetLogChannelAssignment	156
5.2.2.2.130. Dlt_SetLogChannelThreshold	157
5.2.2.2.131. Dlt_SetLogLevel	157
5.2.2.2.132. Dlt_SetMessageFiltering	157
5.2.2.2.133. Dlt_SetTraceStatus	157
5.2.2.2.134. Dlt_StoreConfiguration	157
5.2.2.2.135. Dlt_UnregisterContext	157
5.2.2.3. Functions	158
5.2.2.3.1. Dlt_ASR42_GetDefaultLogLevel	158

5.2.2.3.2. Dlt_ASR42_GetDefaultTraceStatus	158
5.2.2.3.3. Dlt_ASR42_GetTraceStatus	158
5.2.2.3.4. Dlt_ASR42_SetDefaultLogLevel	159
5.2.2.3.5. Dlt_ASR42_SetDefaultTraceStatus	159
5.2.2.3.6. Dlt_ASR42_SetLogLevel	160
5.2.2.3.7. Dlt_ASR42_SetMessageFiltering	160
5.2.2.3.8. Dlt_ASR42_SetTraceStatus	161
5.2.2.3.9. Dlt_ASR43_GetDefaultLogLevel	162
5.2.2.3.10. Dlt_ASR43_GetDefaultTraceStatus	162
5.2.2.3.11. Dlt_ASR43_GetLogChannelNames	162
5.2.2.3.12. Dlt_ASR43_GetLogChannelThreshold	163
5.2.2.3.13. Dlt_ASR43_GetLogInfo	163
5.2.2.3.14. Dlt_ASR43_GetTraceStatus	164
5.2.2.3.15. Dlt_ASR43_RegisterContext	165
5.2.2.3.16. Dlt_ASR43_ResetToFactoryDefault	166
5.2.2.3.17. Dlt_ASR43_SendLogMessage	166
5.2.2.3.18. Dlt_ASR43_SendTraceMessage	167
5.2.2.3.19. Dlt_ASR43_SetDefaultLogLevel	168
5.2.2.3.20. Dlt_ASR43_SetDefaultTraceStatus	169
5.2.2.3.21. Dlt_ASR43_SetLogChannelAssignment	169
5.2.2.3.22. Dlt_ASR43_SetLogChannelThreshold	170
5.2.2.3.23. Dlt_ASR43_SetLogLevel	170
5.2.2.3.24. Dlt_ASR43_SetMessageFiltering	171
5.2.2.3.25. Dlt_ASR43_SetTraceStatus	171
5.2.2.3.26. Dlt_ASR43_StoreConfiguration	172
5.2.2.3.27. Dlt_ASR43_UnregisterContext	172
5.2.2.3.28. Dlt_ComCopyRxData	173
5.2.2.3.29. Dlt_ComCopyTxData	174
5.2.2.3.30. Dlt_ComRxIndication	175
5.2.2.3.31. Dlt_ComStartOfReception	175
5.2.2.3.32. Dlt_ComTxConfirmation	176
5.2.2.3.33. Dlt_GetComInterfaceMaxBandwidth	176
5.2.2.3.34. Dlt_GetGlobalLogging	177
5.2.2.3.35. Dlt_GetLogInfoInternal	177
5.2.2.3.36. Dlt_GetLogLevel	178
5.2.2.3.37. Dlt_GetMessageFilteringStatus	178
5.2.2.3.38. Dlt_GetUseECUID	179
5.2.2.3.39. Dlt_GetUseExtendedHeader	179
5.2.2.3.40. Dlt_GetUseSessionID	180
5.2.2.3.41. Dlt_GetVerboseModeStatus	180
5.2.2.3.42. Dlt_GetVersionInfo	181
5.2.2.3.43. Dlt_Init	181

5.2.2.3.44. Dlt_MainFunction	182
5.2.2.3.45. Dlt_NvMInitDataSetBlockCbK	182
5.2.2.3.46. Dlt_NvMInitNativeBlockCbK	182
5.2.2.3.47. Dlt_NvMReadRamBlockFromNvMDataSetCbK	183
5.2.2.3.48. Dlt_NvMReadRamBlockFromNvMNativeCbK	183
5.2.2.3.49. Dlt_NvMSingleBlockCallbackDataSet	184
5.2.2.3.50. Dlt_NvMSingleBlockCallbackNative	184
5.2.2.3.51. Dlt_NvMWriteRamBlockToNvMDataSetCbK	184
5.2.2.3.52. Dlt_NvMWriteRamBlockToNvMNativeCbK	185
5.2.2.3.53. Dlt_SetComInterfaceMaxBandwidth	185
5.2.2.3.54. Dlt_SetGlobalLogging	186
5.2.2.3.55. Dlt_SetUseECUID	186
5.2.2.3.56. Dlt_SetUseExtendedHeader	187
5.2.2.3.57. Dlt_SetUseSessionID	187
5.2.2.3.58. Dlt_SetVerboseMode	188
5.2.3. Integration notes	189
5.2.3.1. Exclusive areas	189
5.2.3.1.1. SCHM_DLT_EXCLUSIVE_AREA_MASTER	189
5.2.3.1.2. SCHM_DLT_EXCLUSIVE_AREA_SlaveIndex	189
5.2.3.2. Production errors	189
5.2.3.3. Memory mapping	189
5.2.3.4. Integration requirements	190
5.2.3.4.1. intgr.Dlt.PDAV	190
5.2.3.4.2. intgr.Dlt.NvMBlockLength	191
5.2.3.4.3. intgr.Dlt.UniqueAppldContextId	191
5.2.3.4.4. intgr.Dlt.TrafficShaping.MinimumThroughput	191
5.2.3.4.5. intgr.Dlt.Multicore.CoreInitialization	192
5.2.3.4.6. intgr.Dlt.Multicore.Limits	192
5.2.3.4.7. intgr.Dlt.Multicore.APIRestriction	192
5.2.3.4.8. intgr.Dlt.Multicore.CallingContext.MasterCoreOnly	192
5.2.3.4.9. intgr.Dlt.ParameterDescription	193
5.2.3.4.10. intgr.Dlt.TaskMapping.LogTraceStatusChangedNotification	193
5.2.3.4.11. intgr.Dlt.SingleTuple.LogChannelTotalNumberLimitation	193
5.2.3.4.12. intgr.Dlt.Multicore.ContextRegistration	194
5.2.3.4.13. intgr.Dlt.RtePrototypes.ArrayBaseType	194
5.2.3.4.14. intgr.Dlt.Multicore.ContextUnregister	194

1. Overview of EB tresos AutoCore Generic 8 DLT documentation

Welcome to the EB tresos AutoCore Generic 8 DLT (ACG8 DLT) product documentation.

This document provides:

- ▶ [Chapter 2, “Supported features”](#): list of features supported by ACG8 DLT
- ▶ [Chapter 3, “ACG8 DLT release notes”](#): release notes for the ACG8 DLT module
- ▶ [Chapter 4, “ACG8 DLT user guide”](#): background information and instructions
- ▶ [Chapter 5, “ACG8 DLT module references”](#): configuration parameters and the application programming interface

2. Supported features

The ACG8 DLT product implements the AUTOSAR module `Dlt` based on AUTOSAR 4.2.1, with AUTOSAR 4.3.1 features and EB-specific enhancements that are compatible with the AUTOSAR standard.

2.1. Supported Dlt (Base) features

The following features are part of the basic feature set and are available when ACG8 DLT (Base) is licensed:

- ▶ **Dlt core functions:**
 - ▶ Generic creation of log and trace messages
 - ▶ Generic reception of log and trace messages
 - ▶ Buffering and filtering management
 - ▶ Message filtering based on log level and trace status
 - ▶ Generic handling of control requests
 - ▶ Parallel transmission of multiple frames within one PDU
 - ▶ Handling of log channels
- ▶ **Dlt service interface according to AUTOSAR 4.2.1 and AUTOSAR 4.3.1:**
 - ▶ Registering software components and contexts using `Dlt_RegisterContext()`
 - ▶ Un-registering software components and contexts using `Dlt_UnregisterContext()` (only for AUTOSAR 4.3.1)
 - ▶ Sending log and trace messages from SWCs using `Dlt_SendLogMessage()` and `Dlt_SendTraceMessage()`
 - ▶ Notifying SWCs about log level and trace status changes
 - ▶ Control behavior of Dlt at run-time from SWCs (only for AUTOSAR 4.3.1)
- ▶ **Virtual function bus tracing:**
 - ▶ Interface for VFB trace
 - ▶ Support for generating and implementing RTE hook functions
- ▶ **Persistent storage of configuration:**
 - ▶ Storing the run-time configuration in non-volatile (NV) memory
- ▶ **Dlt assistant (tooling):**
 - ▶ Support for generating Dlt ports according to service needs
- ▶ **Message transmission:**

- ▶ Transmitting communication data via a specific communication channel of a specific network (PDU-based, e.g. CAN, FlexRay) using underlying communication layers
- ▶ Adapting/segmenting a log or trace message according to the needs of the communication channel
- ▶ Support for delaying the transmission of Dlt messages after start-up for a configurable time
- ▶ **Verbose mode:**
 - ▶ Transmitting messages in verbose mode
 - ▶ Support of a configuration switch to enable/disable verbose mode
 - ▶ Building Dlt messages with extended headers [SWS_Dlt_00457]
- ▶ **Control messages:**
 - ▶ Controlling the Dlt via one communication channel by means of control messages, i.e. messages received on the bus from an external client
- ▶ **Support for synchronized time base:**
 - ▶ Support of synchronized time stamps/chronological order of log and trace data

2.2. Supported Dlt (feature package 1) features

The following features provide run-time optimizations for multi-core architectures and must be licensed in addition to the ACG8 DLT (Base) product with the ACG8 DLT (Feature Package 1) product:

▶ **Support for BSW distribution:**

The BSW distribution support for Dlt permits the distribution of selected components of the Dlt in order to provide enhanced run-time performance. For multi-core architectures, the following Dlt operations/APIs are distributed to satellite cores:

- ▶ C/S interface DltService operation `SendLogMessage`
- ▶ C/S interface DltService operation `SendTraceMessage`
- ▶ VFB tracing via internal representation of `Dlt_SendTraceMessage`

With BSW distribution for Dlt, the operations and functions above are partially executed on the calling core via a satellite implementation. In case of `SendLogMessage`, the message filtering functionality is executed completely on the calling core. This reduces the inter-core communication and provides enhanced run-time performance.

The BSW distribution for Dlt requires an EB run-time environment with BSW distribution support.

▶ **Traffic shaper:**

- ▶ Support of bandwidth management



- ▶ Configurable bandwidth limits per communication channel
- ▶ Delaying of message transmission if bandwidth is exhausted

3. ACG8 DLT release notes

3.1. Overview

This chapter provides the ACG8 DLT product specific release notes. General release notes that are applicable to all products are provided in the EB tresos AutoCore Generic documentation. Refer to the general release notes in addition to the product release notes documented here.

3.2. Scope of the release

3.2.1. Configuration tool

Your release of EB tresos AutoCore is compatible with the release of the EB tresos Studio configuration tool:

- ▶ EB tresos Studio: 27.1.0 b200625-0900

3.2.2. AUTOSAR modules

The following table lists the AUTOSAR modules that are part of this ACG8 DLT release.

Module name	AUTOSAR version and revision	SWS version and revision	Module version	Supplier
Dlt	4.2.1 []	4.2.1 [0000]	1.8.3	Elektrobit Automotive GmbH

Table 3.1. Hardware-Independent Modules specified by the AUTOSAR standard

3.2.3. EB (Elektrobit) modules

The following table lists all modules which are part of this release but are not specified by the AUTOSAR standard. These modules include tooling developed by EB or they may hold files shared by all other modules.

Module name	Module version	Supplier
No EB modules available		

Table 3.2. Modules not specified by the AUTOSAR standard

3.2.4. MCAL modules and EB tresos AutoCore OS

For information about MCAL modules and OS, refer to the respective documentation, which is available as PDF at `$TRESOS_BASE/doc/3.0_EB_tresos_AutoCore_OS` and `$TRESOS_BASE/doc/5.0_MCAL_modules`¹. It is also available in the online help in EB tresos Studio. Browse to the folders `EB tresos AutoCore OS` and `MCAL modules`.

3.3. Module release notes

3.3.1. Dlt module release notes

- ▶ AUTOSAR R4.2 Rev 1
- ▶ AUTOSAR SWS document version: 4.2.1
- ▶ Module version: 1.8.3.B337087
- ▶ Supplier: Elektrobit Automotive GmbH

3.3.1.1. Change log

This chapter lists the changes between different versions.

Module version 1.8.3

2020-06-19

- ▶ ASCDLT-796 Fixed known issue: Structure of the Register/UnregisterContext notification is wrong
- ▶ Implemented support for retrieving Ecudl for DLT at runtime.
- ▶ ASCDLT-815 Fixed known issue: Dlt generation fails for `DltVfbTracePayloadMaxSize` when `DltImplementationVfbTrace` is disabled

Module version 1.8.2

2020-02-21

¹`$TRESOS_BASE` is the location at which you installed EB tresos Studio.

- ▶ Added support for Dlt VFB tracing with arguments of the hook functions.
- ▶ ASCDLT-773 Fixed known issue: Dlt_SendTraceMessage() returns a wrong return value if Det is disabled.
- ▶ ASCDLT-780 Fixed known issue: Dlt behaves unexpectedly if message transmission is interrupted by a send log/trace request
- ▶ Added checks for valid SessionId in Dlt_SendLogMessage() and Dlt_SendTraceMessage() even if message filtering is OFF
- ▶ Changed the byte order handling of log channel names to be based on DltTupleEndianness' set value

Module version 1.8.1

2019-10-11

- ▶ ASCDLT-669 Fixed known issue: The Dlt does not take into consideration the platform's endianness when receiving ApplId, ContextId and LogChannelName as control message payload
- ▶ ASCDLT-679 Fixed known issue: The GetVerboseModeStatus control message wrongly extracts the ApplId/ContextId from the extended header
- ▶ ASCDLT-685 Fixed known issue: Dlt does not compile if DltGeneralStartupDelayTimer is enabled and DltEnableTrafficShaper is disabled
- ▶ ASCDLT-686 Fixed known issue: The configured VFB traces use the wrong ApplId when DltServiceAPI is set to AUTOSAR_431
- ▶ Implemented configurable behavior in case PduR_DltTransmit returns E_NOT_OK
- ▶ ASCDLT-699 Fixed known issue: GetLogInfo's LEN field is incorrect when the message is sent from the register/unregister context notification
- ▶ ASCDLT-698 Fixed known issue: Dlt could use wrong API identifiers when reporting errors to the Det.
- ▶ ASCDLT-702 Fixed known issue: When you unregister an invalid tuple, a critical section is closed before it opens
- ▶ Updated handling of ApplicationId-ContextId tuples that are identical for multiple instances of the same SW-C
- ▶ ASCDLT-708 Fixed known issue: A ResetToFactoryDefault call does not erase the Dlt native block due to incorrect writing priority
- ▶ ASCDLT-704 Fixed known issue: Dlt can send unexpected log messages and/or trace messages due to wrong filtering of unregistered tuples
- ▶ ASCDLT-710 Fixed known issue: Dlt log and/or trace messages requested on satellite cores are sent on the default log channel regardless of configuration
- ▶ Implemented the GetSoftwareVersion control message.
- ▶ ASCDLT-726 Fixed known issue: Dlt uses wrong identifier for the StbM timebase when fetching the synchronized timebase

Module version 1.8.0

2019-06-14

- ▶ Implemented Logchannel concept from SWS 4.3.1
- ▶ Implemented AUTOSAR 4.3.1 APIs, control messages and operations.
- ▶ ASCDLT-569 Fixed known issue: Dlt_Rte_hook.c does not compile when trace functions are configured and DltEnableBswDistribution is enabled
- ▶ ASCDLT-560 Fixed known issue: VFB traces are not sent when there is no explicit setting of trace status via the Dlt command SetTraceStatus()
- ▶ ASCDLT-559 Fixed known issue: Trace/log messages sent by satellite cores are not filtered correctly when the log/trace settings are changed via Dlt commands using wildcards
- ▶ ASCDLT-584 Fixed known issue: Control messages that receive ApplicationId and ContextId parameters, wrongly respond with DLT_CTRL_ERROR and fail, if header endianness is LSB
- ▶ Implemented startup delay timer as specified by AUTOSAR 4.3.1.
- ▶ ASCDLT-568 Fixed known issue: SWCs are not notified when log level/trace status/verbose mode settings are changed via Dlt commands using wildcards
- ▶ ASCDLT-585 Fixed known issue: DltMaxCountContextIds is not allowed to have a value smaller than the product of DltMaxCountApplIds and DltMaxCountContextIdsPerApplId
- ▶ ASCDLT-587 Fixed known issue: Message filtering uses only the first found ContextId as input, when the same ContextId exists for multiple ApplicationIDs
- ▶ ASCDLT-615 Fixed known issue: Reception of a DLT message can fail when the message is received in multiple packages
- ▶ Updated types used for keeping information regarding the message length

Module version 1.7.1

2019-02-15

- ▶ ASCDLT-503 Fixed known issue: A store request interrupted by another store request corrupts the Dlt internal buffer

Module version 1.7.0

2018-10-26

- ▶ ASCDLT-447 Fixed known issue: Data related to context registration and log level could be out of sync on satellite cores in case of multi-core setup
- ▶ Implemented support for timestamps provided by the StbM module

- ▶ ASCDLT-452 Fixed known issue: Wrong check in control message validation can lead to out-of-bounds access
- ▶ ASCDLT-501 Fixed known issue: Dlt generates incorrectly the function pointers to RTE calls for the application notification callbacks

Module version 1.6.0

2018-06-22

- ▶ ASCDLT-351 Fixed known issue: Missing memory sections in the Dlt software component description cause uncompileable code
- ▶ Implemented verbose mode. Note: NvM layout has changed, NvM block size of NVM_BLOCK_DLT_DATASET was increased by 1.
- ▶ Changed the data types Dlt_MessageLogInfoType and Dlt_MessageTraceInfoType to comply with the SWS. Note: External APIs (Dlt_SendLogMessage, Dlt_SendTraceMessage) are affected.
- ▶ The Dlt_RegisterContext, Dlt_SendLogMessage and Dlt_SendTraceMessage interfaces are now exposed in the new Dlt_BSW.h header file.
- ▶ ASCDLT-393 Fixed known issue: The error code assigned to DLT_E_NOT_IN_VERBOSE_MODE is wrong in Dlt_swc_interface.arxml
- ▶ Memory sections have been updated; deprecated sections have been removed.
- ▶ ASCDLT-423 Fixed known issue: Wrong Dlt instance ID is reported to Det when using multicore configuration
- ▶ ASCDLT-424 Fixed known issue: Certain control API functions that manipulate the Dlt packet header are not working if their corresponding configuration parameter is initialized to FALSE
- ▶ Implemented reception of Control Messages.

Module version 1.5.0

2018-02-23

- ▶ ASCDLT-331 Fixed known issue: Registration information is not loaded from NvM for SWCs
- ▶ Implemented compliance to MISRA-C:2012
- ▶ ASCDLT-329 Fixed known issue: Compile error occurs when Dlt is used with a non-EB NvM module
- ▶ Update according to the latest Tresos Studio

Module version 1.4.2

2017-10-09

- ▶ ASCDLT-285 Fixed known issue: Initialization process for both slave cores and master core is not correctly done
- ▶ ASCDLT-289 Fixed known issue: Buffer overflow can occur if messages from SWC are sent with ap-
pld/contextId registered from a BSWC
- ▶ ASCDLT-288 Fixed known issue: DLT reports unnecessary DET error when all datasets have been
processed
- ▶ ASCDLT-316 Fixed known issue: Corruption of Dlt table data during NvM restore defaults functionality
- ▶ ASCDLT-318 Fixed known issue: Incorrect behavior for NULL values of parameters Application_ID and
Context_ID in Dlt_SetLogLevel and Dlt_SetTraceStatus APIs
- ▶ Improved the usage of NvM: NvMInit callbacks made optional, NvM retry mechanism was removed
- ▶ Implemented new configuration option for configurable queue size of server ports created by the DLT
assistant

Module version 1.4.1

2017-03-21

- ▶ ASCDLT-268 Fixed known issue: Restoring of the runtime data from NvM fails if a SWC already called
Dlt_RegisterContext
- ▶ ASCDLT-273 Fixed known issue: Out of bounds array access happens if DltMaxCountApplds is less than
DltMaxCountContextIdsPerAppld

Module version 1.4.0

2016-12-19

- ▶ ASCDLT-215 Fixed known issue: DLT message transmission stops
- ▶ ASCDLT-223 Fixed known issue: Dlt_SendLog/TraceMessage() is not reentrant
- ▶ ASCDLT-235 Fixed known issue: Out of bound access in Dlt_AppToContextIdTable table when Dlt_Reg-
isterContext() is called more than DltMaxCountContextIdsPerAppld times
- ▶ ASCDLT-236 Fixed known issue: DLT stops sending log Messages after restore from NVM

Module version 1.3.0

2016-11-04

- ▶ ASCDLT-206 Fixed known issue: The Message Counter (MCNT) is wrongfully reset
- ▶ ASCDLT-207 Fixed known issue: Messages in transmission might be corrupted
- ▶ ASCDLT-214 Fixed known issue: Dlt runtime variables reset to configuration values after restore from
NvRAM is successful

- ▶ ASCDLT-208 Fixed known issue: Incompatible design between Dlt persistent storage functionality and NvM

Module version 1.2.2

2016-10-07

- ▶ Improved validation of the Dlt Assistant

Module version 1.2.1

2016-09-09

- ▶ ASCDLT-149 Fixed known issue: Dlt buffer indexes point to incorrect location in message buffer
- ▶ ASCDLT-144 Fixed known issue: Transmission of DLT Log messages stops after some time
- ▶ ASCDLT-156 Fixed known issue: Incompatibile code is generated due to the definition of implementation data types
- ▶ ASCDLT-150 Fixed known issue: The implementation for Rte VFB tracing functions is always generated
- ▶ ASCDLT-164 Fixed known issue: Warnings during importer run after enabling DLT BSW dsitribution
- ▶ ASCDLT-189 Fixed known issue: Det.h is always included by Dlt_Int.h

Module version 1.2.0

2016-05-25

- ▶ Implement Dlt_MainFunction()
- ▶ ASCDLT-96 Fixed known issue: Dlt_ComCopyTxData returns a wrong type if SDU length is 0
- ▶ ASCDLT-99 Fixed known issue: Dlt does not unlock the transmit buffer after it has received a negative Tx confirmation
- ▶ BSW Distribution - implementation
- ▶ Added possibility to transmit multiple Dlt frames in one Pdu

Module version 1.1.0

2015-11-25

- ▶ Implement DLT Persistency Configuration
- ▶ Implement RTE / VFB Tracing
- ▶ Implement SW-C Informer
- ▶ Implement Dlt Assistant

Module version 1.0.0

2015-07-08

- ▶ Initial version

3.3.1.2. New features

- ▶ Implemented support for retrieving Eculd for DLT at runtime.

Description:

Support for getting the Ecu Id at runtime is provided via the `Dlt_AppGetEculdAddress()` user-defined call-out.

3.3.1.3. EB-specific enhancements

This chapter lists the enhancements provided by the module.

- ▶ New traffic shaper configuration option

Description:

The configuration parameter `DltEnableTrafficShaper` has been introduced in order to enable/disable the traffic shaper functionality. An `EB_DLT_MC_OPT` license must be available. Otherwise this parameter is not visible.

The following configuration parameters are editable if `DltEnableTrafficShaper` is enabled:

- ▶ `DltBandwidthForComModule`
- ▶ `DltTimePeriodTrafficShaping`
- ▶ New PDAV configuration option

Description:

The configuration parameter `DltCSPortsQueueLength` has been introduced in order to provide a customizable queue length for the server ports created by the Dlt.

The value of `DltCSPortsQueueLength` controls the following behavior:

Value of <code>DltCSPortsQueueLength</code>	Description
0	No SERVER-COM-SPECs are created. The queue length is calculated by Rte based on the number of connected ports.

Value of <code>DltCSPortsQueueLength</code>	Description
Any other value	Defines the queue size of the SERVER-COM-SPECs created by the DLT to be the configured value.

Table 3.3. Values of `DltCSPortsQueueLength`

- ▶ The `Dlt_MessageLogInfoType` and `Dlt_MessageTraceInfoType` types are now AUTOSAR compliant.
- ▶ Published interfaces for BSW usage

Description:

The `Dlt_RegisterContext`, `Dlt_SendLogMessage` and `Dlt_SendTraceMessage` interfaces are now published for BSW usage, and are located in the new `Dlt_BSW.h` header file, if the `DltRteUsage` configuration parameter is set to false.

- ▶ Different `Dlt_ReturnType` values based on the AUTOSAR SWS version

Description:

`Dlt_ReturnType` is defined differently in the 4.2.1 and 4.2.2 AUTOSAR SWS. Based on the new configuration parameter, `DltDefaultAutosarReturnValues`, the customer can select with what AUTOSAR SWS (4.2.1/4.2.2) should the DLT module comply, regarding `Dlt_ReturnType`'s definition.

- ▶ Implemented control message service requests are also available as C-APIs

Description:

Control service request	C-API
<code>Set_LogLevel</code>	<code>Dlt_SetLogLevel</code>
<code>Set_DefaultLogLevel</code>	<code>Dlt_SetDefaultLogLevel</code>
<code>Set_TraceStatus</code>	<code>Dlt_SetTraceStatus</code>
<code>Set_DefaultTraceStatus</code>	<code>Dlt_SetDefaultTraceStatus</code>
<code>Get_LogInfo</code> , option 4	<code>Dlt_GetLogLevel</code> , used for one specific tuple at a time
<code>Get_LogInfo</code> , option 5	<code>Dlt_GetTraceStatus</code> , used for one specific tuple at a time
<code>Get_DefaultLogLevel</code>	<code>Dlt_GetDefaultLogLevel</code>
<code>Get_DefaultTraceStatus</code>	<code>Dlt_GetDefaultTraceStatus</code>
<code>Store_Config</code>	<code>Dlt_StorePersistent</code>
<code>SetComInterfaceMaxBandwidth</code>	<code>Dlt_SetComInterfaceMaxBandwidth</code>
<code>GetComInterfaceMaxBandwidth</code>	<code>Dlt_GetComInterfaceMaxBandwidth</code>

Control service request	C-API
SetVerboseMode	Dlt_SetVerboseMode
GetVerboseModeStatus	Dlt_GetVerboseModeStatus
SetMessageFiltering	Dlt_SetMessageFiltering
GetMessageFilteringStatus	Dlt_GetMessageFilteringStatus
SetUseECUID	Dlt_SetUseECUID
GetUseECUID	Dlt_GetUseECUID
SetUseSessionID	Dlt_SetUseSessionID
GetUseSessionID	Dlt_GetUseSessionID
UseTimestamp	Dlt_SetUseTimestamp
GetUseTimestamp	Dlt_GetUseTimestamp
UseExtendedHeader	Dlt_SetUseExtendedHeader
GetUseExtendedHeader	Dlt_GetUseExtendedHeader

Table 3.4. Control service requests and C-APIs

- Additional control APIs for global logging

Description:

API	Description
Dlt_SetGlobalLogging	When message logging is disabled, all messages are discarded by the Dlt, regardless of log level or trace status settings
Dlt_GetGlobalLogging	Retrieves the current message logging status

Table 3.5. Additional control APIs for global logging

- The transmission of sync data between master and slave cores is done using a one to one sender-receiver channel with a configurable queue size.

3.3.1.4. Deviations

This chapter lists the deviations of the module from the AUTOSAR standard.

- No support for Dem interface

Affected AUTOSAR releases:

- R4.2 rev 1

Description:

Interface to Dem is currently not supported.

Rationale:

Not planned for the current release.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00474, SWS_Dlt_00475, SWS_Dlt_00476, SWS_Dlt_00377, SWS_Dlt_00477, SWS_Dlt_00478, SWS_Dlt_00479, SWS_Dlt_00470 AUTOSAR 4.3.1: SWS_Dlt_00474, SWS_Dlt_00475, SWS_Dlt_00377, SWS_Dlt_00477, SWS_Dlt_00478, SWS_Dlt_00270, SWS_Dlt_00479, SWS_Dlt_00274, SWS_Dlt_00031, SWS_Dlt_00781

- ▶ No support for Det interface

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

Interface to Det is currently not supported.

Rationale:

Not planned for the current release.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00430, SWS_Dlt_00431, SWS_Dlt_00376, SWS_Dlt_00480, SWS_Dlt_00432 AUTOSAR 4.3.1: SWS_Dlt_00430, SWS_Dlt_00376, SWS_Dlt_00031, SWS_Dlt_00432

- ▶ No support for response on event

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

Response on event is currently not supported.

Rationale:

Not planned for the current release.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00339, SWS_Dlt_00037, SWS_Dlt_00340, SWS_Dlt_00039

- ▶ No support for ApplicationID and ContextID description

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

ApplicationID and ContextID description are not stored in NvM.

Rationale:

ApplicationID and ContextID description are not stored when calling Dlt_RegisterContext

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00064, ECUC_Dlt_00815

- ▶ No support for SWC injection

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

Injecting data to SWC is currently not supported.

Rationale:

Not planned for the current release.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00017, SWS_Dlt_00018, SWS_Dlt_00019, SWS_Dlt_00259, SWS_Dlt_00260, SWS_Dlt_00498, ECUC_Dlt_00819
AUTOSAR 4.3.1: SWS_Dlt_00259, SWS_Dlt_00498, SWS_Dlt_00778, ECUC_Dlt_00847

- ▶ No support for timing messages

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

Timing messages are currently not supported.

Rationale:

Not planned for the current release.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00221, SWS_Dlt_00222

- ▶ No support DLT communication module

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

The DLT module does not provide a separate communication module. The mechanism of the PduR is used instead.

Rationale:

Data transfer via UDP is provided by the AUTOSAR communication stack.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00040, SWS_Dlt_00042, SWS_Dlt_00043, SWS_Dlt_00461, SWS_Dlt_00463, SWS_Dlt_00263, SWS_Dlt_00264, SWS_Dlt_00485, SWS_Dlt_00265

- ▶ No support for DltVfbTraceLogLevel configuration parameter

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

The DltVfbTraceLogLevel configuration parameter is not supported.

Rationale:

The parameter is of no use. VFB messages are "trace" messages, not "log" messages, thus there is no "log level" which can be assigned to them.

Requirements:

AUTOSAR 4.2.1: ECUC_Dlt_00839

- ▶ DltSwcApplicationId configuration parameter is not of type string

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

DltSwcApplicationId configuration parameter is of type integer instead of type string.

Requirements:

AUTOSAR 4.3.1: ECUC_Dlt_00858

- ▶ DltSwcContextId configuration parameter is not of type string

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

DltSwcContextId configuration parameter is of type integer instead of type string.

Requirements:

AUTOSAR 4.3.1: ECUC_Dlt_00859

- ▶ DltLogChannelMaxNumOfRetries not used

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

Implementation for DltLogChannelMaxNumOfRetries is not supported

Requirements:

AUTOSAR 4.3.1: ECUC_Dlt_00884, SWS_Dlt_00761 Dlt.ASR431.Ref_SWS_Dlt_00697_NegativeTx-Confirmation_LogChannelMaxNumOfRetries

- ▶ DltLogChannelTransmitCycle not used

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

Implementation for DltLogChannelTransmitCycle is not supported

Requirements:

AUTOSAR 4.3.1: ECUC_Dlt_00885

- ▶ DltTxPduUsesTp not used

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

Implementation for DltTxPduUsesTp is not supported

Requirements:

AUTOSAR 4.3.1: ECUC_Dlt_00913

- ▶ API Gpt_GetTimeElapsed() for timestamp is not used

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

No support from API Gpt_GetTimeElapsed() in getting message timestamp .

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00654

- ▶ The message buffer size must not be zero

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

The message buffer size must always be at least as large as DltMaxMessageLength. It is not possible to configure a message buffer size of length zero in order to force an immediate transmission of messages.

Rationale:

There must always be at least a small buffer in which the message and its header fields can be assembled. The DLT uses the ring buffer for this. A configuration check assures that the ring buffer is large enough for the largest possible message. When the message has been assembled, the PduR is triggered. Thus, if a "connection less interface" is connected to the PduR, the data is sent immediately and this requirement is thus implicitly fulfilled.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00493

- ▶ Scheduled function

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

The DLT module provides a scheduled function `Dlt_MainFunction()` which must be called periodically by the BSW scheduler.

Rationale:

This is required for a proper implementation of the traffic shaper feature.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00468

- ▶ Different time base

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

The Dlt module does not use the Gpt module for the timestamp functionality. Instead, the timestamp is provided by:

- ▶ the Os, through the usage of the `Os_GetTimeStamp` API (if configured to be used)
- ▶ the StbM, through the usage of the `StbM_GetCurrentTime` API (if configured to be used)

Rationale:

- ▶ Less configuration effort necessary
- ▶ Higher performance
- ▶ The OS provides proper functions for calculations involving the counter values, which automatically handle counter overflows

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00481 AUTOSAR 4.2.1: ECUC_Dlt_00905

- ▶ Traffic shaping

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

The DLT module does not have the functionality for the diagnostic module DCM.

Requirements:

Dlt.TrafficShaping.DiagInterfaces, Dlt.TrafficShaping.DiagChannel

- Store persistent

Affected AUTOSAR releases:

- R4.2 rev 1

Description:

The Dlt module shall let the user configure the restore value for the trace status belonging to a tuple of ApplId and ContextId via the callout Dlt_ApplGetConfigFactoryDefault().

Rationale:

- The information provided by the AUTOSAR SWS 2.1. regarding this parameter is not specific enough.

Requirements:

SWS_Dlt_00288, SWS_Dlt_00348

- VFB Trace message type and message info

Affected AUTOSAR releases:

- R4.2 rev 1

Description:

In VFB tracing messages, the Message Type (MSTP) header field is set to DLT_TYPE_APP_TRACE. The Message Trace Info (MSIN) header field is set to DLT_TRACE_VFB.

Rationale:

- Requirements SWS_Dlt_00120, SWS_Dlt_00484 and SWS_00123 contradict each other. Requirements SWS_Dlt_00120 and SWS_Dlt_00123 provide the better fitting values.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00484

- Dlt_MessageTypeType

Affected AUTOSAR releases:

- R4.2 rev 1

Description:

The Dlt_MessageType enum values start from 0, not from 1.

Rationale:

- Requirements SWS_Dlt_00120 and SWS_00224 contradict each other. The values mentioned in SWS_Dlt_00120 have been chosen, since enums naturally start with 0 in C.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00224

- VFB Trace Network Trace Info Type

Affected AUTOSAR releases:

- R4.2 rev 1

Description:

The Dlt_MessageNetworkTraceInfoType provides an additional DLT_NW_TRACE_MOST element.

Rationale:

- Requirements SWS_Dlt_00125 and SWS_00233 contradict each other. The additional DLT_NW_TRACE_MOST value specified by SWS_Dlt_00125 is provided to assure compatibility and avoid compilation errors.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00233

- No support for some control messages.

Affected AUTOSAR releases:

- R4.2 rev 1

Description:

The following Control messages to DLT are currently not supported: - 0x03: Get_LogInfo, Options: 3 - 0x07: SetComInterfaceStatus - 0x0B: SetTimingPackets - 0x0C: GetLocalTime - 0x14: MessageBufferOverflow - 0x16: GetComInterfaceStatus - 0x17: GetComInterfaceNames - 0xFFFF ... 0xFFFFFFFF: Cal-ISW-CInjection

Rationale:

Not planned for the current release.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00465, SWS_Dlt_00290, SWS_Dlt_00048, SWS_Dlt_00049, SWS_Dlt_00050, SWS_Dlt_00051, SWS_Dlt_00201, SWS_Dlt_00501, SWS_Dlt_00197, SWS_Dlt_00502, SWS_Dlt_00489, SWS_Dlt_00207, SWS_Dlt_00208, SWS_Dlt_00217, SWS_Dlt_00218, SWS_Dlt_00219, SWS_Dlt_00220, SWS_Dlt_00487, SWS_Dlt_00488, SWS_Dlt_00247, SWS_Dlt_00248, SWS_Dlt_00249, SWS_Dlt_00428, Dlt.GetLogInfo.Option3.NoLogLevelNoTraceStatus, Dlt.GetLogInfo.ComInterface

► Prioritization of Dlt Control Messages responses

Affected AUTOSAR releases:

► R4.2 rev 1

Description:

Dlt does not prioritize Control Messages responses over normal log or trace messages.

Rationale:

Not planned for the current release.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00490

► Accept new control messages

Affected AUTOSAR releases:

► R4.2 rev 1

Description:

Dlt does not reject new Control Messages while an old one is not finished.

Rationale:

Adapted due to a popular Dlt external viewer that sends Control Messages without waiting for a response for each one before sending the new requests.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00417

► Several imported types are not in use

Affected AUTOSAR releases:

- ▶ R4.2 rev 1
- ▶ R4.3 rev 1

Description:

The Dlt module does not use the following imported types:

- ▶ Dem_DTCTFormatType, Dem_EventIdType, Dem_UdsStatusByteType
- ▶ Gpt_ChannelType, Gpt_ValueType
- ▶ NvM_BlockIdType
- ▶ StbM_SynchronizedTimeBaseType, StbM_TimeStampExtendedType

Rationale:

- ▶ The Dem types are not used because the Dem interface is not supported
- ▶ The Gpt types are not used because the Dlt uses the Os/StbM instead, for timestamp purposes
- ▶ The NvM type is not used because the Dlt does not require it
- ▶ The StbM types are not used because the Dlt does not require them

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00729

- ▶ Several optional interfaces are not in use

Affected AUTOSAR releases:

- ▶ R4.2 rev 1
- ▶ R4.3 rev 1

Description:

The Dlt module does not use the following optional interfaces:

- ▶ Dem_DltGetAllExtendedDataRecords, Dem_DltGetMostRecentFreezeFrameRecordData, Dem_GetDTCTOfEvent
- ▶ Gpt_EnableNotification, Gpt_StartTimer
- ▶ NvM_EraseNvBlock
- ▶ StbM_GetCurrentTimeExtended

Rationale:

- ▶ The Dem optional interfaces are not used because the Dem interface is not supported

- ▶ The Gpt optional interfaces are not used because the Dlt uses the Os/StbM instead, for timestamp purposes
- ▶ The NvM optional interface is not used because the Dlt does not require it
- ▶ The StbM optional interface is not used because the standard timestamp format is sufficient for the Dlt

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00763

- ▶ The timestamp resolution is platform-dependent

Affected AUTOSAR releases:

- ▶ R4.2 rev 1
- ▶ R4.3 rev 1

Description:

The Dlt module cannot always provide 0.1 milliseconds resolution for the timestamps.

Rationale:

The requirement implies the usage of the Gpt module for the timestamp functionality. The Gpt can provide resolutions down to 1 microseconds, hence the requirement specifies a resolution that can be provided by the Gpt. The currently implemented timestamp providers (Os/StbM) are highly platform-dependent and offer different resolutions, as a consequence.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00309 AUTOSAR 4.3.1: PRS_Dlt_00309

- ▶ Information about enabled/disabled interfaces is not stored persistently

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

When the persistent storage mechanism is enabled, the Dlt module does not persistently store any information related to the enabled or disabled state of its interfaces.

Rationale:

The functionality to enable/disable interfaces is not implemented.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00074

- ▶ Dlt command "BufferOverflowNotification" is not available

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

The AUTOSAR Dlt module does not support the following Dlt Command identified by the following Services

ID: -----	Service ID	Dlt Com-
mand Name	Description	-----
0x23	BufferOverflowNotification	Indication of a buffer overflow within the DLT module

Rationale:

The mentioned command is not currently implemented.

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00643, SWS_Dlt_00670, SWS_Dlt_00776, SWS_Dlt_00777, SWS_Dlt_00760

- ▶ Dlt_GetLogInfo's "logInfo" is now a pointer to uint8

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

- ▶ R4.3 rev 1

Description:

The Dlt_LogInfoType structure type used for the "logInfo" parameter of the Dlt_GetLogInfo() API is not fully compatible with the function's intended purpose.

Rationale:

The structure type only supports the storage of one ApplId/ContextId tuple, which is not fully compatible with the API's intended use: the "applId" and "contextId" parameters can be given as "0", which triggers the API to write multiple entries in the structure type. Due to this issue, the "logInfo" parameter has been changed to a pointer to uint8. This can fully support multiple tuples but comes at a disadvantage because its size must be known beforehand.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00197 AUTOSAR 4.3.1: SWS_Dlt_00732

- ▶ Dlt does not respond with "DLT_NOT_SUPPORTED" when receiving deprecated commands

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

When the Dlt module receives any of the following deprecated commands, it does not respond with "DLT_NOT_SUPPORTED": * 0x07 SetComInterfaceStatus * 0x08 SetComInterfaceMaxBandwidth * 0x09 SetVerboseMode * 0x0A SetMessageFiltering * 0x0C GetLocalTime * 0x0D SetUseECUID * 0x0E SetUseSessionID * 0x0F SetUseTimestamp * 0x10 SetUseExtendedHeader * 0x14 MessageBufferOverflow * 0x16 GetComInterfaceStatus * 0x18 GetComInterfaceMaxBandwidth * 0x19 GetVerboseModeStatus * 0x1A GetMessageFilteringStatus * 0x1B GetUseECUID * 0x1C GetUseSessionID * 0x1D GetUseTimestamp * 0x1E GetUseExtendedHeader

Rationale:

The functionality is currently not implemented.

Requirements:

AUTOSAR 4.3.1: PRS_Dlt_00644

- ▶ DltGeneralRxDataPathSupport is not used

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

The DltGeneralRxDataPathSupport configuration parameter is not used by the Dlt module to accept/reject incoming control messages. Instead, the DltRxPduld parameter is used for this purpose. If it exists and is configured correctly, the Dlt uses a macro to accept/reject incoming control messages.

Rationale:

The functionality is currently not implemented.

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00698, SWS_Dlt_00699, ECUC_Dlt_00848

- ▶ DltLogChannelBufferOverflowTimer is not used

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

DltLogChannelBufferOverflowTimer's functionality is not supported.

Rationale:

The configuration parameter's functionality is not currently implemented.

Requirements:

AUTOSAR 4.3.1: ECUC_Dlt_00886, SWS_Dlt_00760

- ▶ DltLogChannelTrafficShapingBandwidth is not used

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

DltLogChannelTrafficShapingBandwidth's functionality is not supported.

Rationale:

The configuration parameter's functionality is not currently implemented.

Requirements:

AUTOSAR 4.3.1: ECUC_Dlt_00883, SWS_Dlt_00758, ECUC_Dlt_00849

- ▶ No support for multiple SWC instances on R4.2

Affected AUTOSAR releases:

- ▶ R4.2 rev 1

Description:

Dlt module does not support handling of multiple SWC instances on R4.2.

Rationale:

Support for handling multiple SWC instances implies the possibility to register the same ApplId/ContextId tuple for different SessionIds. This is not possible when `DltServiceAPI` configuration parameter is set to other value than `AUTOSAR_431`.

Requirements:

Dlt_Chap7.1.6_Implicit1

- ▶ Set/GetDefaultTraceStatus are global and not log channel specific

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

The Dlt_Set/GetDefaultTraceStatus() APIs, as well as the Set/GetDefaultTraceStatus control commands/ interface operations do not change the log channel specific default trace status, but change the global default trace status instead.

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00744, SWS_Dlt_00745, SWS_Dlt_00747, SWS_Dlt_00748, SWS_Dlt_00743, SWS_Dlt_00746, SWS_Dlt_00772

- ▶ GetLogChannelNames's parameter "logChannelNames" is now of type "Dlt_LogChannelNameArrayType"

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

The logChannelNames parameter of the Dlt_GetLogChannelNames() API and of the GetLogChannelNames control command and interface operation is now of type Dlt_LogChannelNameArrayType instead of Dlt_LogChannelNameType. This new array type has its size equal to the number of configured log channels.

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00749, SWS_Dlt_00772

- ▶ VFB Trace Messages use 0x10000000U as Message ID

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

VFB Trace Messages currently use 0x10000000U as Message ID for the Dlt_SendTraceMessage() calls. However, SWS_Dlt_00031 states that they should use 0x00000003U for Message IDs. This functionality is not planned for the current release.

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00031

- ▶ Unused DET error codes

Affected AUTOSAR releases:

- ▶ R4.2 rev 1
- ▶ R4.3 rev 1

Description:

AUTOSAR	4.2.1:	Type	or	error		Relevance		Related	error	code		Value [hex]
Development		DLT_E_INIT_FAILED		0x07		initialize the service.						
API was unable to												
AUTOSAR 4.3.1: Type of error Related												
error code Value [hex] ----- API service called												
with wrong parameter DLT_E_PARAM 0x01 Initialization failed DLT_E_INIT_FAILED 0x03 Registration failed DLT_E_REGISTRATION 0x04 -----												

The listed DET error codes are currently not used.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00447 AUTOSAR 4.3.1: SWS_Dlt_00727

- ▶ No support for runtime error reporting

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

Support for runtime error code reporting is not planned for the current release.

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00728

- ▶ Dlt_TriggerTransmit() is not a public API

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

Dlt_TriggerTransmit() is a static function called only from Dlt_MainFunction() at the moment. Publishing of this API is not planned for the current release.

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00754

- ▶ Dlt_TxFunction() is not implemented

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

The Dlt_TxFunction() API is not implemented and not planned for the current release.

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_91005, SWS_Dlt_00760, SWS_Dlt_00761, SWS_Dlt_00673

- ▶ DltEcudCalloutChoice is not configurable and DltEcud is not used.

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

The possibility to retrieve Ecudls via call-outs using DltEcudCalloutChoice is implemented using the current user callout approach, meaning that the name of the callout is not configurable. The Dlt_AppGetEcudAddress() user callout is used for Ecud retrieval.

Additionally the container DltEcud is not used, DltEcudValueChoice and DltEcudCalloutChoice are placed in the container DltProtocol and named DltEcud and DltEcudCallout respectively.

Requirements:

AUTOSAR 4.3.1: ECUC_Dlt_00860, ECUC_Dlt_00902, ECUC_Dlt_00862

- ▶ RxPdu configuration parameters are not implemented

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

DltIRxPduHandleId, DltIRxPduUsesTp and DltRxPduIdRef are not implemented and not planned for the current release.

Requirements:

AUTOSAR 4.3.1: ECUC_Dlt_00899, ECUC_Dlt_00900, ECUC_Dlt_00912, ECUC_Dlt_00898

- ▶ Getter functions not supported under multiple instances of SwCs

Affected AUTOSAR releases:

► R4.3 rev 1

Description:

Getter functions for log level and trace status do not currently support multiple instances of SwCs, as AR specifications do not provide argument for session IDs, in order to distinguish identical tuples under different sessions.

Requirements:

Dlt.ASR431.Chap7.1.2_Implicit1

- Several GetSoftwareVersion requirements are not implemented

Affected AUTOSAR releases:

► R4.2 rev 1

Description:

The requirements listed below are for the external client and cannot be implemented by the Dlt module.

Rationale:

The Dlt module cannot detect when a connection is established. The Dlt is initialized and then waits until the startup delay timer has elapsed. The messages are sent afterwards until the buffers are empty. The external client is responsible for making sure that the first control message sent is GetSoftwareVersion.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00394, SWS_Dlt_00395, SWS_Dlt_00492

- No support for post-build selectable behavior

Affected AUTOSAR releases:

► R4.2 rev 1

Description:

The Dlt module does not support post-build behavior for any parameter.

Requirements:

ECUC_Dlt_00800, ECUC_Dlt_00831, ECUC_Dlt_00802, ECUC_Dlt_00803, ECUC_Dlt_00835, ECUC_Dlt_00805, ECUC_Dlt_00843, ECUC_Dlt_00807, ECUC_Dlt_00806, ECUC_Dlt_00811, ECUC_Dlt_00812, ECUC_Dlt_00813, ECUC_Dlt_00814, ECUC_Dlt_00836, Dlt.ASR431.ECUC_Dlt_00870, Dlt.ASR431.ECUC_Dlt_00871, Dlt.ASR431.ECUC_Dlt_00895, Dlt.ASR431.ECUC_Dlt_00874, Dlt.ASR431.ECUC_Dlt_00874, Dlt.ASR431.ECUC_Dlt_00887, Dlt.ASR431.ECUC_Dlt_00896, Dlt.ASR431.ECUC_

Dlt_00888, Dlt.ASR431.ECUC_Dlt_00864, Dlt.ASR431.ECUC_Dlt_00889, Dlt.ASR431.ECUC_Dlt_00886, Dlt.ASR431.ECUC_Dlt_00877, Dlt.ASR431.ECUC_Dlt_00884, Dlt.ASR431.ECUC_Dlt_00878, Dlt.ASR431.ECUC_Dlt_00883, Dlt.ASR431.ECUC_Dlt_00879, Dlt.ASR431.ECUC_Dlt_00893, Dlt.ASR431.ECUC_Dlt_00892, Dlt.ASR431.ECUC_Dlt_00913, Dlt.ASR431.ECUC_Dlt_00856, Dlt.ASR431.ECUC_Dlt_00854, Dlt.ASR431.ECUC_Dlt_00858, Dlt.ASR431.ECUC_Dlt_00859, Dlt.ASR431.ECUC_Dlt_00812, Dlt.ASR431.ECUC_Dlt_00911

- Message counter is increased individually per log channel

Affected AUTOSAR releases:

- R4.3 rev 1

Description:

The message counter in the MCNT field of each Dlt message is currently incremented per log channel instead of globally.

Rationale:

The PRS_Dlt_00105 requirement specifies that a generic message counter shall be implemented, which shall count every log and trace message received via the Dlt API. This somewhat contradicts SWS_Dlt_00671, which states that a message counter shall be implemented for each specific log channel. Due to this conflict, both requirements cannot be implemented. As such, the behavior stated in SWS_Dlt_00671 has been chosen for implementation.

Requirements:

AUTOSAR 4.3.1: PRS_Dlt_00105

- Size of internal Dlt buffer for message processing is set via a single configuration parameter

Affected AUTOSAR releases:

- R4.2 rev 1

Description:

The size of the internal Dlt buffer used for log and trace messages is determined by a specific chosen parameter.

Rationale:

The SWS_Dlt_00003 requirement specifies that the size of the internal Dlt buffer, used prior to the initialization of the module (and re-used later as normal buffer if desired), shall be determined by the configuration parameter DltInitBufferSize (user definable). The specifications however mention other buffers as well, each with its size determined by a different configuration parameter (for example DltMessageBufferSize, from requirement SWS_Dlt_00342). Because of this, for the sake of memory efficiency a single internal

buffer has been implemented for general usage (pre-initialization, runtime, no external client connected), with its size determined by the parameter `DltMessageBufferSize`, as required by SWS_Dlt_00342. This leaves the `DltInitBufferSize` parameter unused, thus deviating from the SWS_Dlt_00003 requirement.

Requirements:

AUTOSAR 4.2.1: SWS_Dlt_00003

- ▶ Dlt will filter messages with a `LogLevel` higher than the configured value of the `LogChannel` threshold or the `Log Level` of the found `ApplicationID/ContextId`

Affected AUTOSAR releases:

- ▶ R4.3 rev 1

Description:

Log messages with a `LogLevel` higher than the configured value of log level threshold of the element for which the `Dlt_SendLogMessage()` API was called. Log messages with a `LogLevel` higher than the configured value of `LogChannel` threshold for the identified `LogChannel` shall be discarded and `E_OK` shall be returned. This shall be done on each `LogChannel` from the list of output `LogChannels` for the `LogMessages`.

Rationale:

These requirements are wrong (AUTOSAR ticket AR-96503), the logic for filtering messages was reversed when these requirements were introduced with AUTOSAR 4.3.0 SWS. The correct behavior is the one presented in AUTOSAR 4.2.2 SWS: Dlt shall check if the log level of the incoming log message is the same or below as the maximum log level stored for this Context ID - Application ID tuple (the log level of the incoming message shall be in the pass through range). If the check is not successful, the messages shall be discarded, otherwise the message shall be transmitted to the external client.

Requirements:

AUTOSAR 4.3.1: SWS_Dlt_00662, SWS_Dlt_00667

3.3.1.5. Limitations

This chapter lists the limitations of the module. Refer to the module references chapter *Integration notes*, subsection *Integration requirements* for requirements on integrating this module.

- ▶ Limitation of number of session IDs

Description:

The number of session IDs which can be registered by SWCs is limited to 2147483647.

Rationale:

This is the maximum value supported by the `size()` method of Java's `Lists<>` class, which is needed for evaluating the system description files.

Requirements:

SWS_Dlt_225

- ▶ Appld/ContextId registration cannot differ only by SessionId

Description:

Only one SessionId (port belonging to a SWC) can be registered per tuple of Appld/ContextId.

Rationale:

The current internal data structure does not allow to have the same Appld/ContextId mapped to different SessionIds to have more optimal data handling.

- ▶ Limitation of traffic shaping

Description:

The minimum limit for traffic shaping is 1kByte/sec.

Rationale:

The configuration parameter `DltBandwidthForComModule` expects the value in kbit/sec, but the limiting of traffic can only be done on whole bytes.

- ▶ Limitation of maximum number of contexts and maximum message length

Description:

When `DltEnableBswDistribution` is set to true, the maximum number of possible contexts registered is limited to 4095 and the maximum message length is limited to 8188. These values depend on the architecture on which the stack is configured.

Rationale:

When multi-core is enabled, data needs to be exchanged through the IOC module between the satellites and the master to ensure a consistent configuration. The size of the data exchanged through the IOC cannot exceed 65536. To meet this constraint, when BSW Distribution is enabled, maximum values were computed for `DltMaxCountContextIds` and `DltMaxMessageLength`. If these parameters are configured with a greater value, the project was risked not to compile as the compilation is stopped in the IOC code.

- ▶ Limitation related to the basic software distribution functionality

Description:

When `DltEnableBswDistribution` is set to true, control APIs can only be called from the master context in order to modify the status of the following run-time variables: `DltDefaultTraceStatus`, `DltFilterMessages`, `DltDefaultMaxLogLevel`, `DltHeaderUseEculd`, `DltHeaderUseExtendedHeader`, `DltHeaderUseSessionID`, `DltHeaderUseTimestamp`. If these functions are called from the slave context, a negative return value is reported because these APIs cannot be called from the satellite cores.

Rationale:

Run-time variables are only stored in the master core. Therefore, the necessity to only call the control APIs from the master core is justified.

Description:

If `DltImplementFilterMessages` and `DltFilterMessages` are enabled, then DLT filtering functionality is available for both master core and satellite cores. By using the filtering functionality on the slave core, a lot of inter-core communication can be avoided, because each message which does not pass the filter can simply be discarded by the slave and does not need to be forwarded to the master.

Description:

If `DltImplementNVRamStorage` is enabled, then the persistent storage functionality shall be possible from both master core and slave core. Note that on the satellite core, the slave sends the session ID to the master Dlt instance via SchM send call. On the master core this then triggers a function which receives the session ID of a session from the slave and triggers the `Dlt_StorePersistent()` API.

Description:

If the satellite core calls `Dlt_SendLogMessage()`/`Dlt_SendTraceStatus()` but the processing of the log message/trace status fails on the master's side, the slave will never be informed about this.

Rationale:

If a `Dlt_SendLogMessage()`/`Dlt_SendTraceStatus()` request fails on the master core with a negative return value, the information is not passed back from the master to the slave core.

► Limitation functionality related to some input parameters

Description:

`Dlt_RegisterContext()` API will not use the input parameters `app_description`, `len_app_description`, `context_description`, `len_context_description`.

Rationale:

To reduce the size of memory footprint, `app_description` and `context_description` is ignored in the current implementation.

Requirements:

SWS_Dlt_00245, ECUC_Dlt_00836

► Reception PDU Ids

Description:

Only one Rx PDU Id can be used for receiving messages.

Rationale:

A maximum multiplicity of 1 for DltRxPdu should be sufficient for most use cases.

► Mapping of error codes for Dlt_SendLogMessage API.

Description:

For Autosar 4.1 and 4.2: If Det is enabled and Dlt_SendLogMessage() is called with an options parameter different from DLT_TYPE_LOG in the log_info structure, the function shall report a DLT_E_WRONG_PARAMETERS error to Det and exit with return value DLT_E_ERROR_UNKNOWN. If Det is enabled and Dlt_SendLogMessage() is called with a structure containing the relevant information for filtering the message (log_info) or the payload of the send message (log_data) as NULL_PTR, the function shall report a DLT_E_PARAM_POINTER error to Det and exit with return value DLT_E_ERROR_UNKNOWN. For Autosar 4.3: If Det is enabled and Dlt_SendLogMessage() is called with an options parameter different from DLT_TYPE_LOG in the log_info structure, the function shall report a DLT_E_WRONG_PARAMETERS error to Det and exit with return value DLT_E_UNKNOWN_SESSION_ID. If Det is enabled and Dlt_SendLogMessage() is called with a structure containing the relevant information for filtering the message (log_info) or the payload of the send message (log_data) as NULL_PTR, the function shall report a DLT_E_PARAM_POINTER error to Det and exit with return value DLT_E_UNKNOWN_SESSION_ID.

Rationale:

In Autosar 4.3 DLT_E_ERROR_UNKNOWN is no longer a valid return value for Dlt_SendLogMessage. DLT_E_UNKNOWN_SESSION_ID is the semantically closest out of all the available return values.

► Mapping of error codes for Dlt_SendTraceMessage API.

Description:

For Autosar 4.1 and 4.2: If Det is enabled and Dlt_SendTraceMessage() is called with an options parameter different from DLT_TYPE_APP_TRACE and DLT_TYPE_NW_TRACE in the trace_info structure, the function shall report a DLT_E_WRONG_PARAMETERS error to Det and exit with return value DLT_E_ERROR_UNKNOWN. If Det is enabled and Dlt_SendTraceMessage() is called with a structure containing the relevant information for filtering the message (trace_info) or the payload of the send message (trace_data) as NULL_PTR, the function shall report a DLT_E_PARAM_POINTER error to Det and exit with return value DLT_E_ERROR_UNKNOWN. For Autosar 4.3: If Det is enabled and Dlt_SendTraceMessage() is

called with an options parameter different from `DLT_TYPE_APP_TRACE` and `DLT_TYPE_NW_TRACE` in the `trace_info` structure, the function shall report a `DLT_E_WRONG_PARAMETERS` error to Det and exit with return value `DLT_E_UNKNOWN_SESSION_ID`. If Det is enabled and `Dlt_SendTraceMessage()` is called with a structure containing the relevant information for filtering the message (`trace_info`) or the payload of the send message (`trace_data`) as `NULL_PTR`, the function shall report a `DLT_E_PARAM_POINTER` error to Det and exit with return value `DLT_E_UNKNOWN_SESSION_ID`.

Rationale:

In Autosar 4.3 `DLT_E_ERROR_UNKNOWN` is no longer a valid return code. `DLT_E_UNKNOWN_SESSION_ID` is the semantically closest out of all the available return values.

- Limitation of setter API functions, control messages and operations

Description:

If a setter function is called with a valid tuple, all identical tuples under all SWCs will be updated with the requested change.

Rationale:

The Autosar APIs `Dlt_SetLogLevel()`, `Dlt_SetTraceStatus()`, and `Dlt_SetVerboseMode()` control messages (from the `DltControlService` interface), do not provide a way to distinguish between identical tuples under different SWCs. This makes setting a specific tuple under a particular SWC impossible, in scenarios where there are multiple identical tuples under different SWCs. Because of this, the setter function APIs requested for a specific tuple will affect all identical tuples.

3.3.1.6. Open-source software

`Dlt` does not use open-source software.

4. ACG8 DLT user guide

4.1. Overview

This chapter provides you with Dlt-specific information:

- ▶ [Section 4.2, “Background Information”](#) explains the concepts of the Dlt module.
- ▶ [Section 4.3, “Configuring the Dlt module”](#) provides instructions on how to configure the Dlt module.

4.2. Background Information

4.2.1. Dlt core functions

4.2.1.1. Generic creation of log and trace messages

Log and trace messages are created by providing the following information:

- ▶ *SessionId*: SessionId of the SWC (e.g. 0x1000U)
- ▶ *Log/trace information*: contains ApplId/ContextId tuple, message type (e.g. log, trace, control), log level, and trace status
- ▶ *Log/trace data*: the actual data for which the message is sent
- ▶ *Log/trace data length*: length of the data sent with the message

4.2.1.2. Generic reception of log and trace messages

Log and trace messages are received either by:

- ▶ direct API calls of `Dlt_SendLogMessage()` and `Dlt_SendTraceMessage()`
- ▶ SWCs that call the `SendLogMessage` and `SendTraceMessage` operations (members of the `DLTService` service interface when `DltServiceAPI` is set to `AUTOSAR_421` or `AUTOSAR_422` and of the `DltSwcMessageService` service interface when `DltServiceAPI` is set to `AUTOSAR_431`).

The `Dlt` processes, filters, and puts the received messages into an internal buffer. When the next `Dlt_MainFunction()` cycle executes, the messages received in the previous cycle are sent to the `PduR`.

4.2.1.3. Buffering and filtering management

The `Dlt` uses a circular internal buffer to store incoming messages. Multiple messages can be received and stored without immediate transmission to the `PduR` by a `Dlt_MainFunction()` call. The number of messages that can be stored depends on the buffer size configured with `DltMessageBufferSize`. If too many incoming messages are stored in this buffer without an actual transmission, the oldest messages can be lost. In this case, `Dlt` reports the `Det` error code `DLT_E_MSG_LOOSE` if `DltDevErrorDetect` is enabled.

The `Dlt` can filter both log and trace messages. The filter options are configured at precompile time and can be modified at run-time. The filtering allows you to change the general module default log level and trace status, or change the tuple-specific log level and trace status. Based on these, log and/or trace messages can be rejected or permitted for transmission.

4.2.1.4. Message filtering based on log level and trace status

The `Dlt` filters incoming log and trace messages based on their log level and trace statuses. Log messages support the following log levels:

- ▶ `DLT_LOG_OFF` (0x00U)
- ▶ `DLT_LOG_FATAL` (0x01U)
- ▶ `DLT_LOG_ERROR` (0x02U)
- ▶ `DLT_LOG_WARN` (0x03U)
- ▶ `DLT_LOG_INFO` (0x04U)
- ▶ `DLT_LOG_DEBUG` (0x05U)
- ▶ `DLT_LOG_VERBOSE` (0x06U)

`DLT_LOG_FATAL` (0x01U) is the most severe type of log message, while `DLT_LOG_VERBOSE` (0x06U) is the least severe type. For example, if the `Dlt` log level is set to `DLT_LOG_WARN` (0x03U), the filtering works as follows:

- ▶ An incoming log message with `DLT_LOG_WARN` (0x03U) is accepted and processed.
- ▶ An incoming log message with `DLT_LOG_FATAL` (0x01U) is accepted and processed.
- ▶ An incoming log message with `DLT_LOG_DEBUG` (0x05U) is rejected and `Dlt_SendLogMessage()` returns `E_OK`.

Trace messages support the following trace statuses:

- ▶ DLT_TRACE_STATUS_OFF (0x00U)
- ▶ DLT_TRACE_STATUS_ON (0x01U)

If the `Dlt` trace status is `DLT_TRACE_STATUS_OFF`, no trace message is sent.

4.2.1.5. Generic handling of control requests

If the `DltRxPduId` configuration parameter is enabled, the `Dlt` can receive control messages. These messages can be sent by a `Dlt` client to change the run-time behavior of the `Dlt`. They consist of changing tuple log level and trace status, getting information about tuples, and modifying log channel behavior. For a complete list of these control messages, together with their description and usage, see [Section 4.2.8.1, “Controlling the Dlt via one communication channel by means of control messages”](#).

4.2.1.6. Parallel transmission of multiple frames within one PDU

The multiple frames transmission feature allows you to transmit multiple `Dlt` frames within one PDU. The feature is enabled with the `DltEnableMultipleFrames` configuration parameter. The number of `Dlt` frames contained in the PDU is defined by the length of the individual `Dlt` frames and the value of the `DltMaxMessageLength` configuration parameter. The maximum number of `Dlt` frames packed into one PDU is based on whether their total size does not exceed the value set for `DltMaxMessageLength`.

The individual frames are simply concatenated within the PDU. The receiver must analyze the length of the whole PDU and compare it to the length parameters in the header fields of the first frame in order to determine whether the PDU contains one or multiple frames. If the PDU contains multiple frames, each subsequent frame is found by using the length parameter of the previous frame as offset.

If data is overwritten and the `DltDevErrorDetect` configuration parameter is enabled, the `Dlt` reports the Det error `DLT_E_MSG_LOOSE` once, regardless of how many messages are overwritten.

4.2.1.7. Handling of log channels

When the `DltServiceAPI` configuration parameter is set to `AUTOSAR_431`, the `Dlt` supports the configuration of multiple log channels in the `DltLogChannel` list.

At run-time, the assignment of a registered `ApplId/ContextId` tuple to a log channel can be controlled through the `Dlt_SetLogChannelAssignment()` API. The threshold of a log channel can be set using the API `Dlt_SetLogChannelThreshold()`.

If a tuple does not have any log channel assigned, the configured default log channel is used.

NOTE



The parameter `logChannelNames` that is used in the `Dlt_GetLogChannelNames()` API is of type `Dlt_LogChannelNameArrayType` instead of `Dlt_LogChannelNameType`. The size of this array type is equal to the number of configured log channels.

When the `Rte` is used, the `RTE_PTR2ARRAYTYPE_PASSING` macro shall be used to enforce the use of the array type and not the array base type for the `logChannelName` of the `SetLogChannelAssignment` operation. As such, every inclusion of the `Rte-generated` prototypes (`Rte_Dlt.h`) has `RTE_PTR2ARRAYTYPE_PASSING`'s definition before it.

4.2.2. Dlt service interface according to AUTOSAR 4.2.1 and AUTOSAR 4.3.1

4.2.2.1. AUTOSAR 4.2.1/4.2.2

The following service interfaces are available when the `DltServiceAPI` configuration parameter is set to `AUTOSAR_421` or `AUTOSAR_422`:

Service interface	Defined operation
DLTService	RegisterContext
	StorePersistent
	SendLogMessage
	SendTraceMessage
LogTraceSessionControl	SetLogLevel
	SetTraceStatus
VerboseModeControl	SetVerboseMode

4.2.2.2. AUTOSAR 4.3.1

The following service interfaces are available when the `DltServiceAPI` configuration parameter is set to `AUTOSAR_431`:

Service interface	Defined operation
DltControlService	GetDefaultLogLevel
	SetDefaultLogLevel

Service interface	Defined operation
	GetDefaultTraceStatus
	SetDefaultTraceStatus
	SetMessageFiltering
	ResetToFactoryDefault
	StoreConfiguration
	SetLogChannelAssignment
	SetLogChannelThreshold
	GetLogChannelThreshold
	GetLogChannelNames
	SetLogLevel
	SetTraceStatus
	GetTraceStatus
	GetLogInfo
DltSwcMessageService	RegisterContext
	UnregisterContext
	SendLogMessage
	SendTraceMessage
LogTraceSessionControl	LogLevelChangedNotification
	TraceStatusChangedNotification

For each SWC, you can enable only the interfaces that the SWC needs with the following parameters:

- ▶ `DltProvideLogTraceSessionControlPort`
- ▶ `DltProvideSwcMessageServicePort`
- ▶ `DltProvideControlServicePort`

Then the `Dlt` generates only the ports, events, and runnable entities relevant for each SWC. The interfaces are generated internally. You do not need to run the **Create Dlt Port Defined Argument Values** wizard.

If the `DltProvideLogTraceSessionControlPort` parameter is enabled, `Dlt` provides the operations `TraceStatusChangedNotification` and `LogLevelChangedNotification` for the `LogTraceSessionControl` interface. Each SWC that wants to receive this notification through the `Rte`, must provide the client/server interface `LogTraceSessionControl`, with the operations `LogLevelChangedNotification` and `TraceStatusChangedNotification`. These operations must be accessible by a P-Port.

If the `DltProvideSwcMessageServicePort` parameter is enabled, `Dlt` provides the following operations for the `DltSwcMessageService` interface:

- ▶ RegisterContext
- ▶ UnregisterContext
- ▶ SendLogMessage
- ▶ SendTraceMessage

Each SWC that wants to receive this notification through the `Rte` must provide the client/server interface `DltSwcMessageService`, with the operations `LogLevelChangedNotification` and `TraceStatusChangedNotification`. These operations must be accessible by a R-Port.

If the `DltProvideControlServicePort` parameter is enabled, `Dlt` provides the following operations for the `DltControlService` interface:

- ▶ GetDefaultLogLevel
- ▶ SetDefaultLogLevel
- ▶ GetDefaultTraceStatus
- ▶ SetDefaultTraceStatus
- ▶ SetMessageFiltering
- ▶ ResetToFactoryDefault
- ▶ StoreConfiguration
- ▶ SetLogChannelAssignment
- ▶ SetLogChannelThreshold
- ▶ GetLogChannelThreshold
- ▶ GetLogChannelNames
- ▶ SetLogLevel
- ▶ SetTraceStatus
- ▶ GetTraceStatus
- ▶ GetLogInfo

Each SWC that wants to send a control message through the `Rte` must provide the client/server interface `LogTraceSessionControl`, with the same operations as listed above for `DltControlService`. These operations must be accessible by a R-Port.

4.2.2.3. Available APIs

`Dlt` provides the following APIs for all AUTOSAR versions:

- ▶ `Dlt_SendLogMessage`
- ▶ `Dlt_SendTraceMessage`

- ▶ Dlt_RegisterContext
- ▶ Dlt_GetDefaultLogLevel
- ▶ Dlt_GetLogLevel
- ▶ Dlt_SetDefaultLogLevel
- ▶ Dlt_SetLogLevel
- ▶ Dlt_GetDefaultTraceStatus
- ▶ Dlt_GetTraceStatus
- ▶ Dlt_SetDefaultTraceStatus
- ▶ Dlt_SetTraceStatus
- ▶ Dlt_GetComInterfaceMaxBandwidth
- ▶ Dlt_GetGlobalLogging
- ▶ Dlt_GetMessageFilteringStatus
- ▶ Dlt_GetUseECUID
- ▶ Dlt_GetUseExtendedHeader
- ▶ Dlt_GetUseSessionID
- ▶ Dlt_GetUseTimestamp
- ▶ Dlt_GetVerboseModeStatus
- ▶ Dlt_SetComInterfaceMaxBandwidth
- ▶ Dlt_SetGlobalLogging
- ▶ Dlt_SetUseECUID
- ▶ Dlt_SetUseExtendedHeader
- ▶ Dlt_SetUseSessionID
- ▶ Dlt_SetUseTimestamp
- ▶ Dlt_SetVerboseMode
- ▶ Dlt_GetLogInfo
- ▶ Dlt_SetMessageFiltering

The following API is provided only if the `DltServiceAPI` configuration parameter is set to AUTOSAR_421 or AUTOSAR_422:

- ▶ Dlt_StorePersistent

The following APIs are provided only if the `DltServiceAPI` configuration parameter is set to AUTOSAR_431:

- ▶ Dlt_UnregisterContext

- ▶ Dlt_StoreConfiguration
- ▶ Dlt_GetLogChannelNames
- ▶ Dlt_GetLogChannelThreshold
- ▶ Dlt_SetLogChannelAssignment
- ▶ Dlt_SetLogChannelThreshold

4.2.2.4. Endianness of Appld, ContextId and log channel name

When AUTOSAR 4.3 is used (i.e. `DltServiceAPI` is set to `AUTOSAR_431`), `Dlt_ApplicationIDType` and `Dlt_ContextIDType` are defined as a 4-byte array. The type used for log channel names is `Dlt_LogChannelNameArrayType`, which is a matrix with `DLT_TXPDU_NO` rows. Each row holds the 4 bytes of each log channel name. Because of this, the platform endianness is relevant.

The interpretation of application IDs, context IDs and log channel names in interfaces that use them, is done either based on the platform endianness that the `Dlt` runs on, or in MSB-only format, if the parameter `Dlt-TupleEndianness` is enabled.

The following control messages have `Appld/ContextId` as parameters in the request payload:

- ▶ `GetLogInfo`
- ▶ `SetLogChannelAssignment`
- ▶ `SetLogLevel`
- ▶ `SetTraceStatus`
- ▶ `GetTraceStatus`
- ▶ `SetVerboseMode`
- ▶ `GetVerboseModeStatus`

The following operations have `Appld/ContextId` as parameters in the request payload:

- ▶ `RegisterContext`
- ▶ `UnregisterContext`
- ▶ `SendLogMessage`
- ▶ `SendTraceMessage`

The following control messages have `LogChannelName` as parameter in the request payload:

- ▶ `SetLogChannelAssignment`
- ▶ `SetLogChannelThreshold`
- ▶ `GetLogChannelThreshold`

The configuration parameter `DltTupleEndianness` is available under AUTOSAR 4.3.1 (`DltServiceAPI` is set to `AUTOSAR_431`). This parameter can change the interpretation of SWC tuples when using the APIs provided by the `Dlt` module that use application IDs and context IDs.

The `DltTupleEndianness` parameter has two states - enabled and disabled. By default, the parameter is disabled. In this case, all SWC tuples are interpreted according to the endianness of the platform. If the parameter is enabled, all `ApplId/ContextId` tuples coming from direct API calls as well as `DltSwcMessageService` and `DltControlService` operations are interpreted in MSBF format only.

The parameter's state also affects the names of the log channels in the `Dlt` configuration during precompile time. The log channel IDs (`DltLogChannelId`) are interpreted with the same endianness as SWC tuples, based on the value configured in `DltTupleEndianness`.

4.2.2.5. Multiple instances of `ApplId/ContextId` tuples

When the `DltServiceAPI` configuration parameter is set to `AUTOSAR_431`, the `Dlt` module supports multiple instances of the `ApplId/ContextId` tuples configured under SWCs.

This allows multiple instances of the configured tuples to be accepted and stored internally as separate tuples.

Control messages that are received from a `Dlt` client do not provide the session ID as argument. Therefore, they only affect the first tuple of `ApplId/ContextId` identified.

4.2.2.6. Registering software components and contexts using `Dlt_RegisterContext()`

SWCs can register `applicationId/contextId` tuples with the `Dlt` by using the `Dlt_RegisterContext()` API or the `RegisterContext` operation of the `DLTService` service interface (when `DltServiceAPI` is set to `AUTOSAR_421` or `AUTOSAR_422`) or of the `DltSwcMessageService` service interface (when `DltServiceAPI` is set to `AUTOSAR_431`).

When `DltServiceAPI` is set to `AUTOSAR_421` or `AUTOSAR_422`, any `ApplId/ContextId` tuple can be registered, as the `Dlt` is not aware at run-time of the SWCs that want to register tuples with the module.

When `DltServiceAPI` is set to `AUTOSAR_431`, only SWCs that explicitly configured their `ApplId/ContextId` tuples with the `Dlt` can register them at run-time.

4.2.2.7. Unregistering software components and contexts using `Dlt_UnregisterContext()` (only for AUTOSAR 4.3.1)

When `DltServiceAPI` is set to `AUTOSAR_431`, SWCs that registered `ApplId/ContextId` tuples with the `Dlt` can unregister them at run-time. This provides the possibility for a SWC to completely unregister its `ApplId/ContextId` tuples.

4.2.2.8. Sending log and trace messages from SWCs using `Dlt_SendLogMessage()` and `Dlt_SendTraceMessage()`

BSW modules (SessionIDs less than 0x1000U) and SWCs (SessionIDs greater than or equal to 0x1000U) can use the two APIs provided by the `Dlt` in order to send various types of log and/or trace messages.

These messages are subject to filtering, based on the current run-time configuration. If they pass all filters, they are sent to the `PduR` module by using `PduR_DltTransmit()`. This happens on every cycle of the `Dlt_MainFunction()` API.

4.2.2.9. Notifying SWCs about log level and trace status changes

The `Dlt` requires the existence of the `LogTraceSessionControl` service interface if the SWCs want to receive notifications about log level/trace status changes of `ApplId/ContextId` tuples that are registered with the `Dlt` at run-time.

When `DltServiceAPI` is set to `AUTOSAR_421` or `AUTOSAR_422`, the `LogTraceSessionControl` service interface provides the operations `SetLogLevel` and `SetTraceStatus`.

When `DltServiceAPI` is set to `AUTOSAR_431`, the `LogTraceSessionControl` service interface provides the operations `LogLevelChangedNotification` and `TraceStatusChangedNotification`. Also, the notify mechanism is only available if SWCs have the `DltSwcSupportLogLevelChangeNotification` configuration parameter enabled.

4.2.2.10. Dlt control by SWCs at run-time (only for AUTOSAR 4.3.1)

When `DltServiceAPI` is set to `AUTOSAR_431`, the `Dlt` provides the `DltControlService` service interface with the following operations:

- ▶ `GetDefaultLogLevel`
- ▶ `SetDefaultLogLevel`
- ▶ `GetDefaultTraceStatus`
- ▶ `SetDefaultTraceStatus`
- ▶ `SetMessageFiltering`
- ▶ `ResetToFactoryDefault`
- ▶ `StoreConfiguration`
- ▶ `SetLogChannelAssignment`
- ▶ `SetLogChannelThreshold`
- ▶ `GetLogChannelThreshold`

- ▶ GetLogChannelNames
- ▶ SetLogLevel
- ▶ SetTraceStatus
- ▶ GetTraceStatus
- ▶ GetLogInfo

This service interface allows SWCs to directly control the `Dlt` run-time behavior. This is not possible in AUTOSAR 4.2 where only control messages can change the behavior and SWCs do not have direct control.

Also, with AUTOSAR 4.3.1, it is possible to have a SWC whose sole purpose is to control the `Dlt` behavior, through the `DltProvideControlServicePort` configuration parameter. For more information about this mechanism see [Section 4.2.2.2, "AUTOSAR 4.3.1"](#).

4.2.3. Virtual function bus tracing

4.2.3.1. Interface for VFB trace

When VFB (Virtual Functional Bus) tracing is enabled, `Dlt` provides a trace hook function for every `Rte` function call that is configured to have trace hook functions enabled.

For every hook function, `Dlt` assigns a unique Message ID, starting from value `0x10000000U` and incrementing it for every new generated function.

The trace data of the trace message that is sent for every hook function is composed of:

- ▶ Message ID - 4 bytes, the value is written considering the MSBF bit of the HTYP field of the standard header
- ▶ Value of every function parameter - for each parameter, the size of its data type is copied, if `DltVfbSendHookFunctionParameters` is enabled

NOTE



No size for pointer data types

When the parameter of a function is of type pointer (e.g. an array), `Dlt` does not know the size of the data that must be copied. So it copies only the address.

NOTE



No tracing benefit for start function

For the output parameters of a function, `Dlt` copies the value provided by the parameter. So this data only makes sense for a return function, not for the start function.

VFB trace messages can be transmitted in two ways, based on the state of the parameter `DltVfbMainFunctionPeriod`:

- ▶ `DltVfbMainFunctionPeriod` is disabled: VFB trace messages are transmitted when the hook function is called.
- ▶ `DltVfbMainFunctionPeriod` is enabled: VFB trace messages are transmitted via the VFB MainFunction, with the periodicity configured in the parameter.

NOTE**Impact of a too small buffer**

It is possible that some of the VFB trace messages are not sent, if the size of the VFB buffer calculated based on the configured number of interruptions and the maximum size of a VFB message is not large enough for holding the new messages. Then this message is discarded. In this case, `Dlt` reports a production error.

NOTE**Buffer overflow notification**

If the transmission buffer is not large enough to hold all messages before sending them, it is possible that some of the VFB trace messages are overwritten, based on the behavior described by the AUTOSAR requirements, which request that the newest message replaces the older ones. In this case, `Dlt` reports a buffer overflow development error. It is possible that the first VFB trace messages are not sent.

4.2.3.2. Support for generating and implementing RTE hook functions

When all configuration conditions are met, the `Rte` module will generate hook functions.

If one hook function is configured in the `Rte` for tracing, the generated `Rte.c` file will include calls to several hook functions defined in the `Dlt`.

In each of the hook functions, the `Dlt` calls the `Dlt_SendTraceMessage()` API in order to send the traces to the `PduR`.

For VFB configuration steps, see [Section 4.3.4, “Configuring VFB tracing”](#).

4.2.4. Persistent storage of configuration

4.2.4.1. Storing the run-time configuration in non-volatile (NV) memory

The persistent storage functionality allows you to modify the run-time configuration and ensure that this configuration is recovered after an ECU reset.

To guarantee that the configuration is restored at every start-up, the `Dlt` provides a persistent storage in NVRAM to store general configuration data and explicitly set (by an external client) log level, trace status, and verbose mode for a tuple of application ID and context ID.

When the `DltServiceAPI` configuration parameter is set to `AUTOSAR_421` or `AUTOSAR_422`, the API `Dlt_StorePersistent()` is used for the persistent storage service.

This service, unlike those listed in [Section 4.2.4.1.3, “Dlt_ApplGetConfigFactoryDefault\(\) call-out”](#), must be assigned to a port interface in the `Rte`, i.e. to the `DLTService` operation `StorePersistent`.

When the `DltServiceAPI` configuration parameter is set to `AUTOSAR_431`, the operation `StoreConfiguration` of the interface `DltControlService` or the API `Dlt_StoreConfiguration()` are used for the persistent storage service. For this AUTOSAR version, the log channel assignment is added to the stored data.

The `Dlt` uses two types of non-volatile (NV) blocks:

- An `NvM` block of type `DATASET` is used for storing log level and trace status for a registered tuple of application ID and context ID.

Start address	Dataset NvM Block							
	ApplicationId (uint32)	ContextId (uint32)	Log Level (uint8)	Trace Status (uint8)	SessionId (uint32)	NewData + OsCoreId (uint8)	Verbose Mode (uint8)	Log Channel Assignments (uint8)
0x00U, block length = 16 bytes + no. of configured log channels	APP0	CTX0	4	ON	0x00U	0U	ON	0U, 1U, 1U...
Next Address, block length = 16 bytes + no. of configured log channels	APP1	CTX1	1	OFF	0x1000U	7U	OFF	0U, 0U, 1U...
Next Address, block length = 16 bytes + no. of configured log channels	APP2	CTX2	4	OFF	0x00U	14U	ON	1U, 1U, 0U...
<div style="border: 1px solid black; padding: 5px;"> The number of rows for the Dataset NvM block is equal to the number of registered pairs of ApplId/ContextId via <code>Dlt_RegisterContext()</code> </div>					SWC SessionId range: $\geq 0x1000U$ BSW SessionId range: $< 0x1000U$	NewData is stored on the first bit. When <code>DltServiceAPI == AUTOSAR_431</code> , <code>OsCoreId</code> is stored on the next 4 bits. This allows up to 16 core IDs to be configured.		Number of bytes occupied by the log channel assignments = Number of configured log channels, when <code>DltServiceAPI == AUTOSAR_431</code> .
Current Address = (previous address of APPN-2) + block length (16 bytes min.)	APPN-1	CTX8	5	ON	0x1001U	1U	OFF	1U, 1U, 1U...
Current Address = (previous address of APPN-1) + block length (16 bytes min.)	APPN	CTX9	5	OFF	0x1002U	1U	ON	1U, 0U, 1U...

Figure 4.1. `Dlt`'s mapping of information persistently stored in a dataset block

The fields `OsCoreId` and Log channel assignment are stored only if `DltServiceAPI` is set to `AUTOSAR_431`.

- An `NvM` block of type `NATIVE` is used for storing general configuration parameters.

Start address	Native NvM block
0x00U, block length = 1 byte	<code>DltFilterMessages</code> (uint8)
0x01U, block length = 1 byte	<code>DltDefaultMaxLogLevel</code> (uint8)
0x02U, block length = 1 byte	<code>DltHeaderUseTimestamp</code> (uint8)
0x03U, block length = 1 byte	<code>DltHeaderUseEculd</code> (uint8)
0x04U, block length = 1 byte	<code>DltHeaderUseExtendedHeader</code> (uint8)

Start address	Native NvM block
0x05U, block length = 1 byte	DltHeaderUseSessionId (uint8)
0x06U, block length = 1 byte	DltHeaderUseVerboseMode (uint8)
0x07U, block length = 1 byte Not supported for current implementation. Space reserved.	DltVfbTraceLogLevel (uint8)
0x08U, block length = 4 bytes	DltBandWidthForComModule (uint8)
0x0CU, block length = 1 byte	Empty byte
0x0DU, block length = 1 byte	DltDefaultTraceStatus (uint8)
0x0EU, block length = 1 byte	Dlt_GlobalLogStatus (uint8)
0x0FU - 0xYYU, variable block length	Dlt_LogChannelThresholdInfo (uint8)

Table 4.1. Dlt's mapping of information persistently stored in a native block

The field Dlt_LogChannelThresholdInfo is occupied only if DltServiceAPI is set to AUTOSAR_431.

For both blocks, the explicit synchronization mechanism (NvMBlockUseSyncMechanism) is automatically enabled. The configuration shown below is automatically generated by the Service Needs Calculator:

Dlt block name: NVM_BLOCK_DLT_GENERAL

- ▶ NvMBlockManagementType: NVM_BLOCK_NATIVE
- ▶ NvMBlockCrcType: NVM_CRC16
- ▶ NvMNvBlockLength: 0
- ▶ NvMCalcRamBlockCrc: false
- ▶ NvMBlockWriteProt: false
- ▶ NvMResistantToChangedSw: false
- ▶ NvMSelectBlockForReadAll: false
- ▶ NvMWriteBlockOnce: false
- ▶ NvMBlockJobPriority: 0
- ▶ NvMBlockUseSyncMechanism: true
- ▶ NvMInitBlockCallback: Dlt_NvMInitNativeBlockCbk
- ▶ NvMReadRamBlockFromNvCallback: Dlt_NvMReadRamBlockFromNvMNativeCbk
- ▶ NvMSingleBlockCallback: Dlt_NvMSingleBlockCallbackNative
- ▶ NvMWriteRamBlockToNvCallback: Dlt_NvMWriteRamBlockToNvMNativeCbk

Dlt block name: NVM_BLOCK_DLT_DATASET

- ▶ NvMBlockManagementType: NVM_BLOCK_DATASET
- ▶ NvMBlockCrcType: NVM_CRC16
- ▶ NvMNvBlockLength: 0
- ▶ NvMCalcRamBlockCrc: false
- ▶ NvMBlockWriteProt: false
- ▶ NvMResistantToChangedSw: false
- ▶ NvMSelectBlockForReadAll: false
- ▶ NvMWriteBlockOnce: false
- ▶ NvMBlockJobPriority: 1
- ▶ NvMBlockUseSyncMechanism: true
- ▶ NvMInitBlockCallback: Dlt_NvMInitDataSetBlockCbk
- ▶ NvMReadRamBlockFromNvCallback: Dlt_NvMReadRamBlockFromNvMDataSetCbk
- ▶ NvMSingleBlockCallback: Dlt_NvMSingleBlockCallbackDataSet
- ▶ NvMWriteRamBlockToNvCallback: Dlt_NvMWriteRamBlockToNvMDataSetCbk

NOTE



Variable block length value

The configured parameter `length` is set to 0U so that you are not limited to a specific value of the non-volatile block length. Rationale: The block length is variable and depends on the platform configuration.

4.2.4.1.1. Length of NvM blocks

The minimum value for the parameter `length` is defined as follows:

Block type	DltServiceAPI set to	Minimum block length
Native	AUTOSAR_421 or AUTOSAR_422	15U
	AUTOSAR_431	Depends on the number of channels configured: <ul style="list-style-type: none"> ▶ at least 17U if only one channel is configured ▶ 2 bytes for every additional channel
Dataset	AUTOSAR_421 or AUTOSAR_422	16U
	AUTOSAR_431	Depends on the number of channels configured:

Block type	DltServiceAPI set to	Minimum block length
		<ul style="list-style-type: none"> ▶ at least 17U if only one channel is configured ▶ 1 byte for every additional channel

4.2.4.1.2. Number of NvM blocks

The number of non-volatile blocks is configured with the `NvmNvBlockNum` parameter and depends on the NvM block type.

- ▶ **Native block type**
This block type can contain only one non-volatile block. The `NvmNvBlockNum` parameter must be set to 1.
- ▶ **Dataset block type**
The value of `NvmNvBlockNum` should be set so that all expected tuples of application IDs/context IDs can be safely stored in the non-volatile memory.

If `DltServiceAPI` is set to AUTOSAR_421 or AUTOSAR_422, configure `NvmNvBlockNum` to the same value as `DltMaxCountContextIds`.

NOTE



Number of blocks per dataset and number of dataset blocks

The maximum number of dataset blocks is configured via the `NvmDatasetSelectionBits` parameter. Ensure that this maximum number is at least equal to `DltMaxCountContextIds`. This allows you to configure, in each dataset block created, the number of blocks to be less or equal to the maximum number of available datasets.

If `DltServiceAPI` is set to AUTOSAR_431, the parameter `DltMaxCountContextIds` is not available. So no check is performed in the configuration.

4.2.4.1.3. Dlt_ApplGetConfigFactoryDefault() call-out

The call-out `Dlt_ApplGetConfigFactoryDefault()` is a user-defined callout. Its purpose is to pass a set of parameters needed in order to re-configure the registered context to the factory default values. As specified, only the log level of a uniquely defined tuple of application ID and context ID given by the user shall be set to `DltFactoryDefaultMaxLogLevel`. Thus, no value is requested for it. The rest of the parameter values are to be decided by the user. A data set index has to be uniquely defined. This data set index is given in order to trigger the initialization callback, which registers the information provided in the register context tables.

In other words, the information passed via `Dlt_ApplGetConfigFactoryDefault()` is considered as a request for a reset to the factory default values. A suggestion on the implementation itself would be to define

an array with wanted values for each parameter that needs to be configured (all five input parameters of the callout have to be configured with values), and at each data set index a different context will be registered.

4.2.5. Dlt assistant (tooling)

4.2.5.1. Support for generating Dlt ports according to service needs

NOTE**Only for AUTOSAR 4.2.1 and 4.2.2**

This feature is available only if the `DltServiceAPI` configuration parameter is set to AUTOSAR_421 or AUTOSAR_422.

The `Dlt` module configuration does not contain any information about the SWCs that use the `Dlt`. Thus, the ports that are required for communication cannot be created based on the module configuration.

The **Create Dlt Port Defined Argument Values** unattended wizard (`DltAs`) uses the software component descriptions (SWCDs) to obtain the necessary information. The wizard checks the <INTERNAL-BEHAVIOR> containers for <SERVICE-NEEDS> items. If they are of type <DLT-USER-NEEDS>, the wizard retrieves all assigned ports from the corresponding <ASSIGNED-PORTS> containers.

For advice on how to describe the `Dlt` service needs in the SWCD, see [Section 4.3.3, “Configuring the Dlt service needs”](#).

4.2.6. Message transmission

4.2.6.1. Data transmission via a network-specific communication channel

The `Dlt` is located above the `PduR`. This guarantees that `Dlt` is independent from the network. It allows the `Dlt` to transmit communication data via any specific communication channel of a specific network (e.g. CAN, FlexRay) using underlying communication layers.

4.2.6.2. Segmentation/adaptation of log or trace messages

If a transport protocol (TP) is used, the `Dlt` can receive and/or transmit messages that are adapted/segmented according to the needs of the communication channel.

4.2.6.3. Delay of message transmission

When `DltServiceAPI` is set to `AUTOSAR_431`, the `DltGeneralStartUpDelayTimer` configuration parameter is available for configuring. After the `Dlt` initializes, this parameter introduces a delay of seconds in message transmission.

4.2.7. Verbose mode

4.2.7.1. Transmitting messages in verbose mode

The `Dlt` allows the transmission of messages in verbose mode, which provides full description of the data. Verbose mode requires the presence of the extended header in the messages.

4.2.7.2. Support of a configuration switch to enable/disable verbose mode

The `Dlt` uses the following parameters to control verbose mode:

- ▶ `DltImplementVerboseMode`
- ▶ `DltUseVerboseMode`
- ▶ `DltImplementExtendedHeader`
- ▶ `DltHeaderUseExtendedHeader`

4.2.7.3. Building Dlt messages with extended headers [SWS_Dlt_00457]

When the `DltImplementExtendedHeader` and `DltHeaderUseExtendedHeader` configuration parameters are enabled, all log and trace messages have the extended header embedded in them. The following extra fields are present in the message header:

- ▶ MSIN (Message Info): verbose mode (enabled/disabled), message type, message type info
- ▶ NOAR (Number of Arguments): number of arguments that the traced function has
- ▶ APID (Application ID): the AppId of the log/trace message
- ▶ CTID (Context ID): the ContextId of the log/trace message

These fields add an extra 10 bytes to the total size of a message.

4.2.8. Control messages

4.2.8.1. Controlling the Dlt via one communication channel by means of control messages

The `Dlt` module offers two ways to receive control requests, e.g. for setting the log level:

- ▶ via dedicated C APIs
C API control messages are always available.
- ▶ via communication services as specified by AUTOSAR
Control messages via communication services are enabled with the `DltRxPduId` configuration parameter.

4.2.8.1.1. Dlt control messages via C APIs

If `DltRxPduId` is disabled, the control messages can only be received via C API calls that are provided via the `Dlt_Control.h` header.

The following table shows the mappings between the AUTOSAR 4.2.1 control messages and the implemented C APIs.

AUTOSAR 4.2.1 control message	Dlt API function	Comment
<i>Set_LogLevel</i>	<i>Dlt_SetLogLevel()</i>	
<i>Set_DefaultLogLevel</i>	<i>Dlt_SetDefaultLogLevel()</i>	
<i>Set_TraceStatus</i>	<i>Dlt_SetTraceStatus()</i>	
<i>Set_DefaultTraceStatus</i>	<i>Dlt_SetDefaultTraceStatus()</i>	
<i>Get_LogInfo</i> , option 3	not supported	
<i>Get_LogInfo</i> , option 4	<i>Dlt_GetLogLevel()</i>	for one Appld/ContextId tuple at a time
<i>Get_LogInfo</i> , option 5	<i>Dlt_GetTraceStatus()</i>	for one Appld/ContextId tuple at a time
<i>Get_LogInfo</i> , option 6	<i>Dlt_GetLogInfo()</i>	
<i>Get_LogInfo</i> , option 7	<i>Dlt_GetLogInfo()</i>	
<i>Get_DefaultLogLevel</i>	<i>Dlt_GetDefaultLogLevel()</i>	
<i>Get_DefaultTraceStatus</i>	<i>Dlt_GetDefaultTraceStatus()</i>	
<i>Store_Config</i>	<i>Dlt_StorePersistent()</i>	
<i>ResetToFactoryDefault</i>	not supported	

AUTOSAR 4.2.1 control message	DLT API function	Comment
<i>SetComInterfaceStatus</i>	not supported	
<i>GetComInterfaceStatus</i>	not supported	
<i>GetComInterfaceNames</i>	not supported	
<i>SetComInterfaceMaxBandwidth</i>	<i>Dlt_SetComInterfaceMaxBandwidth()</i>	
<i>GetComInterfaceMaxBandwidth</i>	<i>Dlt_GetComInterfaceMaxBandwidth()</i>	
<i>SetVerboseMode</i>	<i>Dlt_SetVerboseMode()</i>	
<i>GetVerboseModeStatus</i>	<i>Dlt_GetVerboseModeStatus()</i>	
<i>SetMessageFilterering</i>	<i>Dlt_SetMessageFiltering()</i>	
<i>GetMessageFiltereringStatus</i>	<i>Dlt_GetMessageFilteringStatus()</i>	
<i>SetTimingPackets</i>	not supported	
<i>GetLocalTime</i>	not supported	
<i>SetUseECUID</i>	<i>Dlt_SetUseECUID()</i>	
<i>GetUseECUID</i>	<i>Dlt_GetUseECUID()</i>	
<i>SetUseSessionID</i>	<i>Dlt_SetUseSessionID()</i>	
<i>GetUseSessionID</i>	<i>Dlt_GetUseSessionID()</i>	
<i>UseTimestamp</i>	<i>Dlt_SetUseTimestamp()</i>	
<i>GetUseTimestamp</i>	<i>Dlt_GetUseTimestamp()</i>	
<i>UseExtendedHeader</i>	<i>Dlt_SetUseExtendedHeader()</i>	
<i>GetUseExtendedHeader</i>	<i>Dlt_GetUseExtendedHeader()</i>	
<i>CallSW-ClInjection</i>	not supported	
<i>GetSoftwareVersion</i>	<i>Dlt_GetSoftwareVersion - User-Callout</i>	
<i>MessageBufferOverflow</i>	not supported	

Table 4.2. Control messages conversion to C APIs, AUTOSAR 4.2.1

The following table shows the mappings between the AUTOSAR 4.3.1 control messages and the implemented C APIs.

AUTOSAR 4.3.1 control message	DLT API function	Comment
<i>SetLogLevel</i>	<i>Dlt_SetLogLevel()</i>	

AUTOSAR 4.3.1 control message	Dlt API function	Comment
<i>SetTraceStatus</i>	<i>Dlt_SetTraceStatus()</i>	
<i>GetLogInfo</i>	<i>Dlt_GetLogInfo()</i>	
<i>GetDefaultLogLevel</i>	<i>Dlt_GetDefaultLogLevel()</i>	
<i>StoreConfiguration</i>	<i>Dlt_StoreConfiguration()</i>	
<i>RestoreToFactoryDefault</i>	<i>Dlt_ResetToFactoryDefault()</i>	
<i>SetMessageFiltering</i>	<i>Dlt_SetMessageFiltering()</i>	
<i>SetDefaultLogLevel</i>	<i>Dlt_SetDefaultLogLevel()</i>	
<i>SetDefaultTraceStatus</i>	<i>Dlt_SetDefaultTraceStatus()</i>	
<i>GetSoftwareVersion</i>	<i>Dlt_GetSoftwareVersion()</i>	
<i>GetLogChannelNames</i>	<i>Dlt_GetLogChannelNames()</i>	
<i>GetTraceStatus</i>	<i>Dlt_GetTraceStatus()</i>	
<i>SetLogChannelAssignment</i>	<i>Dlt_SetLogChannelAssignment()</i>	
<i>SetLogChannelThreshold</i>	<i>Dlt_SetLogChannelThreshold()</i>	
<i>GetLogChannelThreshold</i>	<i>Dlt_GetLogChannelThreshold()</i>	
<i>BufferOverflowNotification</i>	not supported	
<i>SyncTimeStamp</i>	not supported	

Table 4.3. Control messages conversion to C APIs, AUTOSAR 4.3.1

4.2.8.1.1.1. Dlt_GetSoftwareVersion() call-out

`Dlt_GetSoftwareVersion()` is a user-defined call-out. Its purpose is to write a string representing the ECU software version to a buffer passed to it via one of its parameters. The other parameter is the maximum length of the software version string. You must check that the written string does not exceed the maximum length.

4.2.8.1.1.2. Dlt_AppGetEculdAddress() call-out

`Dlt_AppGetEculdAddress()` is an user-defined call-out that can be used when the "DltEculdChoice" configuration parameter is set to "Callout". It is called upon module initialization and it retrieves the address of a buffer that holds an user-defined Eculd. This Eculd is used by log and/or trace messages to compose the ECU field in the standard header. It is up to the user to make sure that the Eculd string does not exceed the maximum length (4 bytes). If the call-out retrieves a NULL pointer, the Dlt module will report the DLT_E_PARAM_POINTER error code to the Det, with a 0x89U ServiceId. If the Eculd cannot be retrieved, the corresponding bytes will be filled with 0x00U.

4.2.8.1.1.3. Dlt_GetLogInfo() buffer size

The `Dlt_GetLogInfo()` API takes the following arguments:

- ▶ *options*: This can either be `6U` for non-textual information, or `7U` for textual information about the given *AppId*/*ContextId* tuple(s). Any other value is considered invalid and the function returns with `E_NOT_OK`.
- ▶ *appId*: This can either be an already registered application ID or the value `0U`. With `0U`, all registered application IDs are retrieved.
- ▶ *contextId*: This can either be a valid context ID of an already registered application ID, or the value `0U`. With `0U`, if a valid application ID is given, all context IDs of the given application ID are retrieved.
- ▶ *status*: This returns the API status, which is separate from its return values.
- ▶ *logInfo*: This returns information about one or multiple *AppId*/*ContextId* tuples. This parameter is a buffer that needs its size well defined before the API can be called. The size is calculated based on the following formula:

Size when non-textual descriptions are requested:

$$\text{BufferSize} = 2 \text{ bytes} + (6 \text{ bytes} * \text{TotalNoOfAppIds}) + (6 \text{ bytes} * \text{TotalNoOfContextIds})$$

Note: The buffer does not contain any information related to textual descriptions when they are not requested (i.e. the *options* argument equals `6U`).

Size when textual descriptions are requested:

$$\text{BufferSize} = 2 \text{ bytes} + ((7 \text{ bytes} * \text{TotalNoOfAppIds}) + \text{TotalDescLengthOfAppIds}) + ((7 \text{ bytes} * \text{TotalNoOfContextIds}) + \text{TotalDescLengthOfContextIds})$$

- ▶ *TotalNoOfAppIds*: total number of requested application IDs. Its value can either be `1U` when a specific valid application ID is given. Or it is equal to the total number of registered application IDs when the *appId* argument is given as `0U`.
- ▶ *TotalDescLengthOfAppIds*: total description length of all application IDs
- ▶ *TotalNoOfContextIds*: total number of requested context IDs. Its value is based on the total number of registered context IDs across all given application IDs.
- ▶ *TotalDescLengthOfContextIds*: total description length of all context IDs.

For a valid call of the API, the exact number of registered *AppId*/*ContextId* tuples must be known. If the given application ID is different from `0U` and it was previously registered, only the number of context IDs must be known. The first 2 bytes are the number of application IDs requested, while the rest of the buffer size is based on the total number of registered *AppId*/*ContextId* tuples.

Note: When the `DltServiceAPI` configuration parameter is set to `AUTOSAR_421` or `AUTOSAR_422`, the `Dlt_GetLogInfo()` API is not capable of retrieving textual descriptions because they are not supported by `Dlt_RegisterContext()`. In this case, *TotalDescLengthOfAppIds* and *TotalDescLengthOfContextIds* from the buffer size calculation are not applicable. The description length for application IDs and context IDs is always written as `0U`.

4.2.8.1.2. Dlt control messages via communication services

If `DltRxPduId` is enabled, the control messages can also be received via the communication services, i.e. `PduR`.

When the `DltServiceAPI` configuration parameter is set to `AUTOSAR_431`, the `Dlt` supports the configuration of multiple log channels, for which a `DltITxPduHandleId` and a `DltTxPduIdRef` must be configured. The handle IDs for log channels are zero-based and consecutive.

PDU's are configured in the `EcuC` module and are referenced in the `DltTxPduIdRef` parameter of a log channel.

`Dlt` always responds to a received control message with the configured standard header and the extended header. The extended header is sent regardless of the `Dlt_HeaderUseExtendedHeader` value. The ECU ID is sent regardless of the `Dlt_HeaderUseEcuId` value.

If there is a validation error of the received message, e.g. a wrong ECU ID, the length is lower than expected, or the extended header is not sent, `Dlt` responds with a message that has the status `ERROR` and service ID = 0 in the payload.

If the underlying communication layer is Ethernet, the following limitations apply:

- ▶ `Dlt_Init()` must be called after `SoAd_Init()`.
- ▶ The `SoAdSocketAutomaticSoConSetup` parameter must be set to false. `Dlt_Init()` opens the connection itself.
- ▶ The `SoAdPduHeaderEnable` parameter must be set to false. The PDU header is not described in the `Dlt` protocol, and a `Dlt`-external client does not add it.
- ▶ If UDP is used, the `SoAdSocketUdpRetryEnabled` parameter must be set to true.

When a control message is sent via `PduR`, the message is stored in the internal reception buffer. The message is processed during the `Dlt_MainFunction()` call. The `Dlt` responds via a `PduR_DltTransmit()` call.

4.2.9. Support for synchronized time-base

4.2.9.1. Support of synchronized time stamps/chronological order of log and trace data

This feature is only available when `DltServiceAPI` is set to `AUTOSAR_431`.

If the configuration parameter `DltImplementTimestamp` is enabled and `DltGeneralStbMTimeBaseRef` is configured, time stamps are provided by the `StbM_GetCurrentTime()` API. Thus, this requires the existence of a `StbM` configuration in the current project. The **StbMSynchronizedTimeBase** container needs to have

an entry that enables the **StbMLocalTimeClock** container. This container needs a hardware counter (`Rte_Counter`) mapped to `StbMLocalTimeHardware`.

If the configuration parameter `DltImplementTimestamp` is enabled and `DltGeneralStbMTimeBaseRef` is not configured, time stamps are provided by the `OS_GetTimeStamp()` API. Thus, this requires the existence of an `Os` in the current project. An alarm needs to be configured in the `Os` (`OsAlarm`) with a hardware counter mapped to it, as an alarm counter reference. Therefore, if the time stamp functionality in `Dlt` is wanted, the current project needs to integrate the `Os`. Otherwise, if `DltImplementTimestamp` is enabled but no `Os` is available, the project fails to compile.

4.2.10. Support for BSW distribution

For multi-core support, a *master-satellite* concept is implemented.

Each core that is able to register `ApplId/ContextId` tuples and send `Dlt` messages gets its own instance of a `Dlt` satellite.

4.2.10.1. Supported APIs

The following APIs are requested and processed only on the master core:

- ▶ `Dlt_ComTxConfirmation()`
- ▶ `Dlt_ComCopyTxData()`
- ▶ `Dlt_GetTraceStatus()`
- ▶ `Dlt_SetLogLevel()`
- ▶ `Dlt_SetTraceStatus()`
- ▶ `Dlt_GetLogLevel()`
- ▶ `Dlt_GetLogInfo()`
- ▶ `Dlt_GetComInterfaceMaxBandwidth()`
- ▶ `Dlt_SetComInterfaceMaxBandwidth()`
- ▶ `Dlt_GetUseExtendedHeader()`
- ▶ `Dlt_SetUseExtendedHeader()`
- ▶ `Dlt_GetUseTimestamp()`
- ▶ `Dlt_SetUseTimestamp()`
- ▶ `Dlt_GetDefaultLogLevel()`
- ▶ `Dlt_GetDefaultTraceStatus()`

- ▶ Dlt_SetDefaultLogLevel()
- ▶ Dlt_SetDefaultTraceStatus()
- ▶ Dlt_SetMessageFiltering()
- ▶ Dlt_GetGlobalLogging()
- ▶ Dlt_GetMessageFilteringStatus()
- ▶ Dlt_GetUseECUID()
- ▶ Dlt_GetUseSessionID()
- ▶ Dlt_GetVerboseModeStatus()
- ▶ Dlt_SetGlobalLogging()
- ▶ Dlt_SetUseECUID()
- ▶ Dlt_SetUseSessionID()
- ▶ Dlt_SetVerboseMode()
- ▶ Dlt_GetLogChannelNames()
- ▶ Dlt_GetLogChannelThreshold()
- ▶ Dlt_SetLogChannelAssignment()
- ▶ Dlt_SetLogChannelThreshold()
- ▶ Dlt_ResetToFactoryDefault()
- ▶ Dlt_NvMWriteRamBlockToNvMDataSetCbk()
- ▶ Dlt_NvMWriteRamBlockToNvMNativeCbk()
- ▶ Dlt_NvMInitDataSetBlockCbk()
- ▶ Dlt_NvMInitNativeBlockCbk()
- ▶ Dlt_NvMReadRamBlockFromNvMDataSetCbk()
- ▶ Dlt_NvMReadRamBlockFromNvMNativeCbk()
- ▶ Dlt_NvMSingleBlockCallbackDataSet()
- ▶ Dlt_NvMSingleBlockCallbackNative()

The following APIs are requested on a satellite core, but processed on the master core:

- ▶ Dlt_StorePersistent() - only if `DltServiceAPI` is set to AUTOSAR_421 or AUTOSAR_422
- ▶ Dlt_StoreConfiguration() - only if `DltServiceAPI` is set to AUTOSAR_431

The following APIs can be requested on both master core and satellite cores:

- ▶ Dlt_SendLogMessage()
- ▶ Dlt_SendTraceMessage()

- ▶ `Dlt_RegisterContext()`
- ▶ `Dlt_UnregisterContext()` - only if `DltServiceAPI` is set to `AUTOSAR_431`

NOTE



AUTOSAR_431: Use core where tuple is registered

When `AUTOSAR_431` is selected, the tables containing information about the registered tuples are updated locally, on the core where `Dlt_RegisterContext()` is called. All API calls for a register tuple should always be made on the same core, for BSW applications, because the information from the registration is only available on that core.

NOTE



No SWC cross-core calls

Cross-core calls are not supported for SWCs.

The validation of the data in the `Dlt_SendLogMessage()` and `Dlt_SendTraceMessage()` APIs is done locally, on the core on which they were called. But the transmission of the log/trace messages is always done on the master core, regardless of the core on which the API was called.

4.2.10.2. BSW distribution initialization

If `DltEnableBswDistribution` is set to true, BSW distribution support is enabled. To ensure a consistent initialization state for both master and satellite cores, the following sequence must be completed during the start-up phase of the project:

1. Initialize all `Dlt` satellite cores.
2. Initialize the `Dlt` master core.

This sequence protects the project against inconsistent data storage in the system and invalid run-time data exchange between the cores.

For configuring BSW distribution, see [Section 4.3.5, “Configuring BSW distribution”](#).

4.2.11. Traffic shaper

4.2.11.1. Support of bandwidth management

Bandwidth management is defined as traffic shaping in the `Dlt` implementation. According to the specifications, a *sliding time window* is to be used for this purpose.

The `Dlt_MainFunction()` API uses pre-configured time periods during which it can measure traffic and bandwidth exhaustion. These time windows also enforce a specific number of bytes that can be transmitted.

4.2.11.2. Configurable bandwidth limits per communication channel

The maximum number of bytes that can be transmitted within the time window is calculated at precompile time, based on the bandwidth configured for the communication channel multiplied by the configured traffic shaping time period. This is divided by 1000 to obtain the maximum bytes allowed.

4.2.11.3. Delaying of message transmission if bandwidth is exhausted

If more than the maximum number of bytes is sent and awaiting transmission, the `Dlt_MainFunction()` calculates a certain number of *wait states*, considering the amount of data in excess. These wait states are used by the `Dlt_MainFunction()` to delay message transmission in order to balance the average bus load so the `Dlt` can meet the bandwidth limits.

4.3. Configuring the Dlt module

4.3.1. Configuring the Rte for AUTOSAR 4.2.1 and 4.2.2

Each software component (SWC) that shall be able to communicate with the `Dlt` must provide a `Log-TraceSessionControl` client/server interface with the operations `Dlt_SetLogLevel()` and `Dlt_SetTraceStatus()`. These operations must be accessible by a P-Port that has a `Port Defined Argument Value` of type `Dlt_SessionIDType`. The port defined argument values must be consecutive and start from 0x1000.

If the `DltImplementVerboseMode` parameter is set to `true`, each SWC must also provide a `Verbose-ModeControl` client/server interface with the operation `Dlt_SetVerboseMode()`. This operation must be accessible by a P-Port that has a `Port Defined Argument Value` of type `Dlt_SessionIDType`.

Additionally, each SWC that shall be able to communicate with the `Dlt` must offer the following R-Ports with the `DLTService` interface assigned to *required interface*:

- ▶ `R_StorePersistent`
- ▶ `R_RegisterContext`

- ▶ R_SendLogMessage
- ▶ R_SendTraceMessage

To make the `Dlt` aware of the port defined argument values, run the **Create Dlt Port Defined Argument Values** wizard. Follow the sequence described here:



Mapping the SWC and Dlt ports

Step 1

Run the *System Description Importer* to import the system descriptions of the SWCs.

Step 2

Run the **Update Service Component and BSWM Descriptions** wizard.

Step 3

Run the **Create Dlt Port Defined Argument Values** wizard.

Step 4

Open the **Compositions and Connections** editor.

Step 5

Map the R-Ports `R_StorePersistent`, `R_RegisterContext`, `R_SendLogMessage` and `R_SendTraceMessage` of the SWCs to the corresponding `Dlt_service_gen` P-Ports of the `Dlt` module.

Step 6

Map the `LogTraceSessionControl` and, if `DltImplementVerboseMode` parameter is set to `true`, the `VerboseModeControl` P-Ports of the software components to the corresponding `PSCN` R-Port of the `Dlt` module.

Step 7

Run the **Create an ECU Extract** wizard.

Now you can configure the `Rte`.



Configuring the Rte

Step 1

In the `Os`, create a task for the runnable entities

- ▶ RE_SetLogLevel
- ▶ RE_SetTraceStatus
- ▶ RE_SetVerboseMode

Step 2

Set the task priority to a value that is greater than the priority of the task that the software cyclic counter is mapped to. In this way, the three runnable entities are called before the cyclic counter is incremented.

Step 3

In the `Rte`, map the three runnable entities to their associated task that you created in the `Os`.

Step 4

Map the `RE_SetLogLevel`, `RE_SetTraceStatus` and `RE_SetVerboseMode` runnable entities to internal trigger events.

For detailed information about the integration with the `Rte`, see the following documents:

- Specification of Diagnostic Log and Trace, AUTOSAR 4.2.1., chapter 7.6.3
- Specification of Diagnostic Log and Trace, AUTOSAR 4.3.1., chapter 7.1.2

4.3.2. Configuring Dlt for AUTOSAR 4.3.1

You can configure the AUTOSAR version to be used by setting the parameter `DltServiceAPI`. When using AUTOSAR 4.3, you must configure the SWCs in the `Dlt` (`DltSwc`). You must also configure the contexts you want to use for a specific SWC (`DltSwcContext`).



Configuring the SWC context

Step 1

Open the `Dlt` editor on the `DltSwcContext` tab.

Step 2

Configure a list of `ApplicationId/ContextId` tuples that are supported by this SWC:

Step 2.1

In `DltSwcApplicationId`, set the SWC application ID.

Step 2.2

In `DltSwcContextId`, set the context ID.

Step 3

Go to the `General` tab.

Step 4

In `DltSwcSessionId`, set the session ID.

If you enter a value that is smaller than `0x1000`, the configured SWC is considered to be a BSW module.

In this case, the parameter `DltSwcSupportLogLevelChangeNotification` is disabled because BSW modules cannot be notified about log and trace changes.

Step 5

Enable parameter `DltSwcSupportLogLevelChangeNotification` if the `Dlt` shall notify the SWC via `LogLevelChangedNotification` about log level changes.

Step 6

In `MaxSwcLogMessageLength` and `MaxSwcTraceMessageLength`, configure the maximum length of log and trace messages for this SWC.

Step 7

The tab `RtePorts` is available if the value of the `DltSwcSessionId` is greater than 0x1000. If the `DltRteUsage` parameter is enabled, you can configure the generation of the ports `DltProvideControlServicePort`, `DltProvideSwcMessageServicePort` and `DltProvideLogTraceSessionControlPort`.

NOTE



No registration without context configuration

At run-time, if `Dlt` receives a request to register a context, `Dlt` only allows it if the context was configured for this SWC. Otherwise, `Dlt` rejects the request.

4.3.2.1. Configuring Dlt functionalities

In the `DltConfigSet` tab, you can configure the global `Dlt` functionalities that can be enabled or disabled.

4.3.2.1.1. Configuring the log channels

In the `DltLogOutput`, configure the log/trace message output. `Dlt` supports the configuration of multiple log channels.



Configuring the log channels

Step 1

Go to tab `DltLogChannel` to configure the available log channels. For each channel, configure the following parameters:

- ▶ the channel name in `DltLogChannelId`
- ▶ the maximum length of the message in `DltLogChannelMaxMessageLength`
- ▶ the log level threshold in `DltLogChannelThreshold`
- ▶ the buffer size in `DltLogChannelBufferSize`
- ▶ the transmit cycle time in `DltLogChannelTransmitCycle`
- ▶ the handle IDs in `DltITxPduHandleId`. The handle IDs for log channels are 0-based and consecutive.
- ▶ the PDUs that are configured in the `EcuC` module. These PDUs are referenced in the `DltTxPduIdRef` parameter of a log channel.

Step 2

Go to the **General** tab.

Step 3

In `DltDefaultLogChannelRef`, configure the reference to the default log channel. If one tuple does not have a log channel assigned, this default channel is used.

Step 4

To assign a channel to a configured context, go to the `DltLogChannelAssignment` tab.

Step 5

For every entry in the list, reference a configured `ApplicationId/ContextId` tuple in `DltLogChannelAssignmentSwcContextRef`, and a configured log channel in `DltLogChannelRef`.

You can assign multiple log channels to one `ApplicationId/ContextId` tuple. In this case, if a request to send a log or trace message is received, the message is sent on every assigned log channel.

4.3.2.1.2. Configuring the trace status

In the **DltTraceStatusSetting** tab, you can configure the trace status for the configured `ApplicationId/ContextId` tuples.



Configuring the trace status

Step 1

Go to the **General** tab.

Step 2

Enable the parameter `DltDefaultTraceStatus` to set the default trace status. This status is used for every tuple that does not have a trace status configured.

Step 3

Go to the **DltTraceStatusAssignment** tab.

Step 4

For every configured `ApplicationId/ContextId` tuple, configure the trace status with `DltTraceStatus`.

4.3.2.1.3. Configuring the log level

In the **DltLogLevelSetting** tab, you can configure the log level for the configured `ApplicationId/ContextId` tuples.



Configuring the log level

Step 1

In the **General** tab, in parameter `DltDefaultLogLevel`, select the default log level. The default log level is used as the log level for every tuple that does not have a log level configured.

Step 2

In the **DltLogLevelThreshold** tab, set the log level for a configured ApplicationId/ContextId tuple.

4.3.3. Configuring the Dlt service needs

For background information, see [Section 4.2.5.1, “Support for generating Dlt ports according to service needs”](#).



Describing the Dlt service needs in the SWCD

For each group of ports that belong to one session ID and are handled with one *PortDefinedArgumentValue* by the Dlt service:

Step 1

For each SessionId, create one *SwcServiceDependency* as part of the *SwcInternalBehavior*.

Step 2

Add the *DltUserNeeds* to this *SwcServiceDependency*.

Step 3

For each included port, add one *RoleBasedPortAssignment* with a reference to the *PortPrototype*. The role of *RoleBasedPortAssignment* can be left empty.

Step 4

Create a new *PortAPIOption* with the value of the SessionId as *PortDefinedArgumentValue*.

Step 5

Attach to *RoleBasedPortAssignment* all *PortPrototype* elements that belong to this SessionId.

4.3.4. Configuring VFB tracing

For background information, see [Section 4.2.3, “Virtual function bus tracing”](#).



Configuring virtual function bus tracing

Step 1

Enable VFB tracing with the parameter *DltImplementVfbTrace*.

Step 2

To send trace messages periodically in the VFB MainFunction, enable the parameter *DltVfbMainFunctionPeriod*. Otherwise, the transmission is triggered in the hook function.

Step 3

To add the hook function parameter values in the trace message payload, enable the parameter *DltVfbSendHookFunctionParameters*.

Step 4

If you enabled `DltVfbSendHookFunctionParameters`, you must configure the maximum size of the trace data sent by a VFB hook function in the `DltVfbTracePayloadMaxSize` parameter.

Step 5

In parameter `DltVfbTraceNoOfInterrupts`, configure the maximum number of times that VFB hook function calls can interrupt other calls of this hook function. This value is used for calculating the necessary size of the VFB buffer. This buffer is allocated in RAM memory, so a large value configured will have an impact on the RAM usage.

Step 6

If the actual number of interruptions is greater than the one configured in `DltVfbTraceNoOfInterrupts`, it is possible that there is not enough space in the buffer to save the data of the hook function. In this case `Dlt` can report a production error.

Configure `DltReportToDem` to report an error to `Dem`, to `Det`, or to ignore the error.

Step 6.1

For a `Dem` error, reference a valid `Dem` event parameter in `DltDemEventParameterRefs`.

4.3.5. Configuring BSW distribution

The `Dlt` BSW distribution depends on the multi-core configuration of the OS. As a mandatory precondition, the project must integrate and configure the OS stack with multi-core support. To enable multi-core support, the parameter `OsNumberOfCores` must be configured to a value higher than 1.

Only if `OsNumberOfCores` is set to a value higher than 1, the `Dlt` BSW distribution feature with all associated configuration parameters is available.

Moreover, `OsNumberOfCores` defines the number of core configurations. For example, if `OsNumberOfCores` is configured to 3, there are three configurations in the **OsCoreConfig** tab.

In addition to the `Os` module, the BSW distribution functionality depends on the existence of the `Rte` module. The data transfer between the master and satellite instances is realized with the help of the scheduler `SchM`, which is integrated into the `Rte`.

This section describes the configuration dependencies of the basic software distribution functionality (multi-core support) and the interaction between the `Dlt` and the `Rte` module. For background information on the `Dlt` BSW distribution, see [Section 4.2.10, “Support for BSW distribution”](#).

4.3.5.1. Configuring the Rte for Dlt BSW distribution



Configuring the Rte

Step 1

Open the **Rte Generic Editor**.

Step 2

In the **BSW Module Instances** tab, create BSW module instances for each core on which the module should run. The module does not necessarily need to run on all cores.

Step 3

In **RteBswRequiredSenderReceiverConnection**, define the ports between satellites and master based on the following port connection information.

	Master instance
RteBswProvidedVariableDataPrototypeRef	Dlt_MasterSendSyncTablePort_<satellite_id>
RteBswRequiredVariableDataPrototypeRef	Dlt_SlaveReceiveSyncTablePort_<satellite_id>

Table 4.4. Port connection for the master

For each satellite, a `Dlt_MasterSendSyncTablePort_<satellite_id>` port and a `Dlt_SlaveReceiveSyncTablePort_<satellite_id>` port is generated. Each master port needs to be connected to its corresponding satellite port.

	send Message	send Context	send SessionID
RteBswProvidedVariableDataPrototypeRef	Dlt_SlaveSendMessagePort	Dlt_SlaveSendContextMessagePort	Dlt_SlaveSendSessionIdPort
RteBswRequiredVariableDataPrototypeRef	Dlt_MasterReceiveMessagePort	Dlt_MasterReceiveContextMessagePort	Dlt_MasterReceiveSessionIdPort

Table 4.5. Port connection for each satellite

4.3.6. Configuring the Dlt main function

The `Dlt` provides one scheduled function, `Dlt_MainFunction()`. This function is used for timing measurements and proper bandwidth management. Thus, this function must be called regularly on a fixed time base.

Information about this function is exported to the basic software module description (BSWMD) of `Dlt` to allow a simple mapping of `Dlt_MainFunction()` to a suitable, periodically scheduled task with the help of EB tresos AutoCore Generic 8 RTE (`Rte`).



Mapping Dlt_MainFunction() to an Rte task

Step 1

Set the `DltMainFunctionPeriod` configuration parameter to the desired `Dlt_MainFunction()` call interval in seconds. Note that this interval also defines the minimum interval between the transmission of two Dlt messages.

Step 2

Run the **Update Service Component and BSWM Descriptions** wizard.

Step 3

Use the `Rte Editor` to assign the `Dlt_MainFunction()` to a proper task.

For more information on the `Rte Editor`, see the EB tresos AutoCore Generic 8 RTE user guide.

5. ACG8 DLT module references

5.1. Overview

This chapter provides module references for the ACG8 DLT product modules. These include a detailed description of all configuration parameters. Furthermore this chapter lists the application programming interface with all data types, constants and functions.

The content of the sections is sorted alphabetically according the EB tresos AutoCore Generic module names.

For further information on the functional behavior of these modules, refer to the chapter ACG8 DLT user's guide.

5.1.1. Notation in EB module references

EB notation may differ from the AUTOSAR standard notation in the software specification documents (SWS). This section describes the notation of *default value* and *range* fields in the EB module references.

5.1.1.1. Default value of configuration parameters

If there is no default value specified for a parameter, the default value field is omitted to prevent ambiguity with parameters that have -- as default values.

Example: The parameter `BswMCompuConstText` of the `BswM` module of EB tresos AutoCore Generic 8 Mode Management has no default value field, therefore it is omitted.

5.1.1.2. Range information of configuration parameters

The range of a configuration parameter contains an upper and a lower boundary. However, in special cases the range of allowed values can be computed by means of an XPath function that is evaluated at configuration time. An XPath function can either be a standard `xpath:<function>()` or a custom `cxpath:<function>()` function. The range of a configuration parameter may be computed based on other configuration parameters that are referenced from the XPath function. For more information on custom XPath functions, see section *Custom XPath Functions API* of the EB tresos Studio developer's guide.

Example: The parameter `BswMCompuConstText` of the `BswM` module of EB tresos AutoCore Generic 8 Mode Management has the custom XPath function `cxpath:getCompuMethodsVT()` in the range field which provides the allowed values.

5.2. Dlt

5.2.1. Configuration parameters

Containers included		
Container name	Multiplicity	Description
CommonPublishedInformation	1..1	Label: Common Published Information Common container, aggregated by all modules. It contains published information about vendor and versions.
DltGeneral	1..1	Flags for adding removing functionality from code.
ReportToDem	1..1	Label: Production error handling Production error handling
DltMemory	1..1	Configuration parameters for reserving memory for some internal storing and buffer.
DltVfbTrace	0..0	All functions to trace from the VFB by the Dlt.
DltConfigSet	1..1	This container lists all the global Dlt functionalities that can be enabled or disabled at pre-compile time to optimize resource consumption. It is supported starting with AUTOSAR_431
DltMultipleConfigurationContainer	1..1	This container contains the configuration parameters and sub containers of the AUTOSAR Dlt module.
DltDefensiveProgramming	1..1	Label: Defensive Programming Options Parameters for defensive programming
DltSwc	1..n	This container purpose is to register a number of Sw Components. It is supported starting with AUTOSAR_431
PublishedInformation	1..1	Label: EB Published Information Additional published parameters not covered by CommonPublishedInformation container.

Parameters included	
Parameter name	Multiplicity
IMPLEMENTATION_CONFIG_VARIANT	1..1

Parameter Name	IMPLEMENTATION_CONFIG_VARIANT
----------------	-------------------------------

Label	Config Variant	
Multiplicity	1..1	
Type	ENUMERATION	
Default value	VariantPreCompile	
Range	VariantPreCompile	
Configuration class	VariantPreCompile:	VariantPreCompile

5.2.1.1. CommonPublishedInformation

Parameters included	
Parameter name	Multiplicity
ArMajorVersion	1..1
ArMinorVersion	1..1
ArPatchVersion	1..1
SwMajorVersion	1..1
SwMinorVersion	1..1
SwPatchVersion	1..1
ModuleId	1..1
VendorId	1..1
Release	1..1

Parameter Name	ArMajorVersion
Label	AUTOSAR Major Version
Description	Major version number of AUTOSAR specification on which the appropriate implementation is based on.
Multiplicity	1..1
Type	INTEGER_LABEL
Default value	4
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

Parameter Name	ArMinorVersion
Label	AUTOSAR Minor Version

Description	Minor version number of AUTOSAR specification on which the appropriate implementation is based on.	
Multiplicity	1..1	
Type	INTEGER_LABEL	
Default value	2	
Configuration class	PublishedInformation:	
Origin	Elektrobit Automotive GmbH	

Parameter Name	ArPatchVersion	
Label	AUTOSAR Patch Version	
Description	Patch level version number of AUTOSAR specification on which the appropriate implementation is based on.	
Multiplicity	1..1	
Type	INTEGER_LABEL	
Default value	1	
Configuration class	PublishedInformation:	
Origin	Elektrobit Automotive GmbH	

Parameter Name	SwMajorVersion	
Label	Software Major Version	
Description	Major version number of the vendor specific implementation of the module.	
Multiplicity	1..1	
Type	INTEGER_LABEL	
Default value	1	
Configuration class	PublishedInformation:	
Origin	Elektrobit Automotive GmbH	

Parameter Name	SwMinorVersion	
Label	Software Minor Version	
Description	Minor version number of the vendor specific implementation of the module. The numbering is vendor specific.	
Multiplicity	1..1	
Type	INTEGER_LABEL	
Default value	8	

Configuration class	PublishedInformation:	
Origin	Elektrobit Automotive GmbH	

Parameter Name	SwPatchVersion	
Label	Software Patch Version	
Description	Patch level version number of the vendor specific implementation of the module. The numbering is vendor specific.	
Multiplicity	1..1	
Type	INTEGER_LABEL	
Default value	3	
Configuration class	PublishedInformation:	
Origin	Elektrobit Automotive GmbH	

Parameter Name	ModuleId	
Label	Numeric Module ID	
Description	Module ID of this module from Module List	
Multiplicity	1..1	
Type	INTEGER_LABEL	
Default value	55	
Configuration class	PublishedInformation:	
Origin	Elektrobit Automotive GmbH	

Parameter Name	VendorId	
Label	Vendor ID	
Description	Vendor ID of the dedicated implementation of this module according to the AUTOSAR vendor list	
Multiplicity	1..1	
Type	INTEGER_LABEL	
Default value	1	
Configuration class	PublishedInformation:	
Origin	Elektrobit Automotive GmbH	

Parameter Name	Release	
Label	Release Information	

Multiplicity	1..1
Type	STRING_LABEL
Default value	
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

5.2.1.2. DltGeneral

Containers included		
Container name	Multiplicity	Description
DltDemEventParameterRefs	1..1	Label: Dem Events References

Parameters included	
Parameter name	Multiplicity
DltRteUsage	1..1
DltGeneralStartUpDelayTimer	0..1
DltDevErrorDetect	1..1
DltEnableTrafficShaper	1..1
DltImplementAppldContextIdQuery	1..1
DltImplementExtendedHeader	1..1
DltImplementFilterMessages	1..1
DltImplementNVRamStorage	1..1
DltImplementSWCInjection	1..1
DltImplementTimestamp	1..1
DltImplementVerboseMode	1..1
DltImplementVfbTrace	1..1
DltVersionInfoApi	1..1
DltGeneralRegisterContextNotification	1..1
DltVfbTraceLogLevel	1..1
DltGptChannel	1..1
DltGeneralStbMTimeBaseRef	0..1
DltCSPortsQueueLength	1..1
DltControlMessageMaxResponseSize	1..1

Parameters included	
DltTupleEndianness	1..1
DltVfbMainFunctionPeriod	0..1
DltVfbSendHookFunctionParameters	1..1
DltVfbTracePayloadMaxSize	1..1
DltVfbTraceNoOfInterrupts	1..1

Parameter Name	DltRteUsage	
Label	Enable Rte Usage	
Description	<p>This parameter enables the usage of the RTE for this module.</p> <p>For an easy integration it is recommended to disable the usage of the RTE at the beginning of the integration work.</p>	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPostBuild:	VariantPostBuild
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltGeneralStartUpDelayTimer	
Description	Defines the delay of starting the transmission of messages after the Dlt module has been initialized in seconds.	
Multiplicity	0..1	
Type	FLOAT	
Default value	0.1	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltDevErrorDetect	
Description	Enables/Disables development error detection.	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	true	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltEnableTrafficShaper	
Description	Enable Traffic Shaper feature for Dlt.	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	EB	

Parameter Name	DltImplementAppldContextIdQuery	
Description	If set the functionality for Verbose Mode shall be available. <p>Note: The functionality related to this parameter is not supported by the current implementation.</p>	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltImplementExtendedHeader	
Description	If set the extended functionality for the header shall be available. For AUTOSAR_431 this parameter shall be disabled	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltImplementFilterMessages	
Description	This flag is for code generation of Dlt. If set the functionality for filtering messages shall be included in the code. For AUTOSAR_431 this parameter shall be disabled	
Multiplicity	1..1	
Type	BOOLEAN	

Default value	true	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltImplementNVRamStorage	
Description	<p>If set the functionality for storing and loading information in and from NVRam shall be available.</p> <p>For AUTOSAR_431 this parameter shall be disabled</p>	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltImplementSWCInjection	
Description	<p>If the remote call from functions over the Dlt in SW-C shall be available.</p> <p><p>Note: The functionality related to this parameter is not supported by the current implementation.</p></p>	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltImplementTimestamp	
Description	<p>If set the timestamp functionality for the header shall be available.</p> <p>In the AUTOSAR 4.3.1 specifications this parameter is called differently (DltGeneralTimeStampSupport).</p>	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltImplementVerboseMode	
-----------------------	--------------------------------	--

Description	If set the timestamp functionality for the header shall be available. For AUTOSAR_431 this parameter shall be disabled	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltImplementVfbTrace	
Description	If set the header files and the implementation of VFB-trace shall be generated. For AUTOSAR_431 this parameter shall be disabled	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltVersionInfoApi	
Description	Pre-processor switch for enabling Version Info API support.	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	true	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltGeneralRegisterContextNotification	
Description	If this parameter is set to TRUE, a Dlt Control Message is sent every time a SWC registers and/or de-registers at/from the Dlt Module. Else, this notification is not sent. TODO This parameter is not enabled yet	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	PreCompile:	VariantPreCompile

Origin	AUTOSAR_ECUC
--------	--------------

Parameter Name	DltVfbTraceLogLevel	
Description	The log level of the log messages generated by the VFB-Trace.. Note: The functionality related to this parameter is not supported by the current implementation.	
Multiplicity	1..1	
Type	INTEGER	
Default value	0	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltGptChannel	
Description	Reference to the hardware free running timer of the GPT module for timestamps (if no HWFRT is applied, calls to add timestamps are ignored).	
Multiplicity	1..1	
Type	SYMBOLIC-NAME-REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltGeneralStbMTimeBaseRef	
Description	If DltImplementTimestamp is set to TRUE and DltGeneralStbMTimeBaseRef is configured, the Dlt module shall fetch the time from the StbM module by calling StbM_GetCurrentTime with the here referenced StbMSynchronizedTimeBase.	
Multiplicity	0..1	
Type	SYMBOLIC-NAME-REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltCSPortsQueueLength	
Description	Configuration parameter which allows defining the queue length of the <i>Client / Server ComSpec Operations</i> . If parameter is set to value 0 no SERVER-COM-SPECs are created and the queue length will be calculated by RTE based on the number of connected ports, otherwise the configured DltCSPortsQueueLength value is assigned.	

Multiplicity	1..1
Type	INTEGER
Default value	1
Configuration class	VariantPreCompile: VariantPreCompile
Origin	Elektrobit Automotive GmbH

Parameter Name	DltControlMessageMaxResponseSize
Description	<p>Allows customization of the response buffer's size for control messages.</p> <p>If the GetLogInfo control message is to be used, the following formula must be used to calculate the response size:</p> <p>Size when no textual descriptions are requested:</p> $\text{ResponseBufferSize} = 2 \text{ bytes} + (6 \text{ bytes} * \text{TotalNoOfApplIds}) + (6 \text{ bytes} * \text{TotalNoOfContextIds}) + \text{ReservedBytes}$ <p>ReservedBytes (4 bytes) is always filled with 0</p> <p>Size when textual descriptions are requested:</p> $\text{ResponseBufferSize} = 2 \text{ bytes} + (7 \text{ bytes} * \text{TotalNoOfApplIds}) + (7 \text{ bytes} * \text{TotalNoOfContextIds}) + \text{ReservedBytes}$ <p>ReservedBytes (4 bytes) is always filled with 0</p> <p>Note: Textual descriptions are not supported when the DltServiceAPI configuration parameter is set to "AUTOSAR_421" or "AUTOSAR_422". As such, the description length fields for ApplIds (1 byte) and ContextIds (1 byte) will be written and filled with 0.</p>
Multiplicity	1..1
Type	INTEGER
Default value	4
Configuration class	PreCompile: VariantPreCompile
Origin	Elektrobit Automotive GmbH

Parameter Name	DltTupleEndianness
Description	<p>If enabled, the Application and Context Id of a tuple, under Autosar 4.3.1 (DltServiceAPI == AUTOSAR_431), is taken in MSB order. If this parameter is disabled, the Application/Context IDs will be interpreted according to the platform endianness.</p>

	For Autosar versions different than 4.3.1 (DltServiceAPI == AUTOSAR_421) this parameter is disabled.	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltVfbMainFunctionPeriod	
Label	Period of Dlt_VfbMainFunction()	
Description	Period of Dlt_VfbMainFunction() calls in seconds.	
Multiplicity	0..1	
Type	FLOAT	
Default value	0.1	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltVfbSendHookFunctionParameters	
Label	Send VFB Hook Function Parameters	
Description	<p>Enable this parameter in order to send parameter information of the configured hook functions.</p> <p>If disabled, only the Message ID will be sent as payload in the trace message.</p>	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltVfbTracePayloadMaxSize	
Label	VFB Hook Function Payload Max. Size	
Description	Maximum size of the trace data (payload) sent by a VFB hook function.	
Multiplicity	1..1	
Type	INTEGER	
Default value	4	

Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltVfbTraceNoOfInterrupts	
Label	VFB Trace Number of Max. Interrupts	
Description	The maximum number of interrupts possible within the system.	
Multiplicity	1..1	
Type	INTEGER	
Default value	0	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

5.2.1.3. DltDemEventParameterRefs

Parameters included	
Parameter name	Multiplicity
DLT_E_VFB_BUFFER_FULL	1..1

Parameter Name	DLT_E_VFB_BUFFER_FULL	
Label	Error for VFB full buffer	
Description	Reference to the DemEventParameter that shall be issued when the buffer allocated for the configured trace hook function's parameters has no available space left.	
Multiplicity	1..1	
Type	REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

5.2.1.4. ReportToDem

Parameters included	
Parameter name	Multiplicity

Parameters included	
DltVfbBufferFullReportToDem	1..1
DltVfbBufferFullDemDetErrorId	1..1

Parameter Name	DltVfbBufferFullReportToDem	
Label	Dlt VFB buffer full	
Description	<p>Defines the handling of the production error: <i>DLT_E_VFB_BUFFER_FULL</i></p> <ul style="list-style-type: none"> ▶ DEM: All errors are reported to the Diagnostics Event Manager (Dem). ▶ DET: All errors are reported to the Development Error Tracer (Det) if enabled. ▶ DISABLE: Production errors are not reported at all. 	
Multiplicity	1..1	
Type	ENUMERATION	
Default value	DISABLE	
Range	DEM DET DISABLE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltVfbBufferFullDemDetErrorId	
Label	Dlt VFB buffer full DET ErrorId	
Description	<p>Defines the <code>ErrorId</code> of the Dlt VFB buffer full error when it is reported to Det instead of Dem.</p> <p>Range:</p> <ul style="list-style-type: none"> ▶ 30 .. 255 	
Multiplicity	1..1	
Type	INTEGER	
Default value	30	
Range	<=255 >=30	
Configuration class	PreCompile:	VariantPreCompile

Origin	Elektrobit Automotive GmbH
---------------	----------------------------

5.2.1.5. DltMemory

Parameters included	
Parameter name	Multiplicity
DltInitBufferSize	1..1
DltMaxCountApplIds	1..1
DltMaxCountContextIds	1..1
DltMaxCountContextIdsPerApplId	1..1
DltMessageBufferSize	1..1
DltReceptionBufferSize	1..1

Parameter Name	DltInitBufferSize	
Description	<p>Buffer size for the C-init buffer.</p> <p>This buffer is for storing messages from other BSW modules before Dlt is initialized.</p>	
Multiplicity	1..1	
Type	INTEGER	
Default value	0	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltMaxCountApplIds	
Description	<p>The maximum count of registrable Application Ids. There shall be a table to manage registered Application IDs, this is the number of lines to hold in this table.</p> <p>To enable the parameter , AUTOSAR_42 or lower version shall be configured.</p>	
Multiplicity	1..1	
Type	INTEGER	
Default value	10	
Range	<p><=4294967295</p> <p>>=1</p>	

Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltMaxCountContextIds	
Description	<p>The maximum count of registrable Context Ids. There shall be a table to manage registered Context IDs, this is the number of lines to hold in this table.</p> <p>Note: To enable the parameter , AUTOSAR_42 or lower version shall be configured.</p>	
Multiplicity	1..1	
Type	INTEGER	
Default value	100	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltMaxCountContextIdsPerAppId	
Description	<p>Each Context ID belongs to a specific Application ID. Dlt shall handle the correlation between them. The table of the registered Application IDs shall hold for every Application ID several references to the proper Context IDs. This is the maximum count for Context IDs per Application ID. Note: To enable the parameter , AUTOSAR_42 or lower version shall be configured, otherwise its default value will be equal to 1 since in AUTOSAR431 each ApplicationId/ContextId tuple shall be preconfigured and used within the application</p>	
Multiplicity	1..1	
Type	INTEGER	
Default value	10	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltMessageBufferSize	
Description	<p>Buffer size for storing Dlt messages for waiting to transmit over the Network (send buffer). This parameter can be enabled only when AUTOSAR_42 or lower version is used</p>	
Multiplicity	1..1	
Type	INTEGER	
Default value	1024	

Range	<=4294967295	
	>=20	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltReceptionBufferSize	
Description	<p>Defines the buffer size for the receiving buffer. This buffer is for storing messages from communication lower layer.</p> <p>Note: As some external Dlt clients might send all Control Messages at once, this buffer must be large enough to accomodate them all. Length of a Control Message varies but, to get a sense of how much size one might have, 30 bytes could be initially considered for one Control Message.</p> <p>Dependency on parameter(s):</p> <ul style="list-style-type: none"> ► Dlt Rx Pdu Id (DltRxPduId): this parameter must be enabled in order to be able to configure the Rx buffer size. 	
Multiplicity	1..1	
Type	INTEGER	
Default value	200	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

5.2.1.6. DltVfbTrace

Parameters included	
Parameter name	Multiplicity
DltVfbTraceFunction	1..1
DltBswModuleEntryRef	1..1

Parameter Name	DltVfbTraceFunction
Description	The Dlt generator shall enable VFB tracing for a given hook function when there is a #define in the Dlt-VFB configuration header file for the hook function name and tracing is globally enabled.
Multiplicity	1..1

Type	FUNCTION-NAME	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltBswModuleEntryRef	
Description	Foreign reference to the BSWModuleEntry describing the trace function implementation.	
Multiplicity	1..1	
Type	FOREIGN-REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.2.1.7. DltConfigSet

Containers included		
Container name	Multiplicity	Description
DltLogOutput	0..1	This container contains settings for log/trace message output.
DltLogLevelSetting	1..1	Contains settings for thresholds.
DltTraceStatusSetting	1..1	Contains settings for trace status

5.2.1.8. DltLogOutput

Containers included		
Container name	Multiplicity	Description
DltLogChannel	1..255	This container contains settings for log/trace message output.
DltLogChannelAssignment	0..n	This container contains a preconfiguration of ApplicationId / ContextId pairs and their assigned log channel.

Parameters included	
Parameter name	Multiplicity
DltDefaultLogChannelRef	1..1

Parameter Name	DltDefaultLogChannelRef	
Description	Reference to the default log channel, which has to be used for a log/trace output, if no other match has been found.	
Multiplicity	1..1	
Type	REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.2.1.9. DltLogChannel

Containers included		
Container name	Multiplicity	Description
DltTxPdu	1..1	Contains the configuration parameters of the AUTOSAR Dlt module's Tx Pdus.

Parameters included	
Parameter name	Multiplicity
DltLogChannelBufferOverflowTimer	1..1
DltLogChannelBufferSize	1..1
DltLogChannelId	1..1
DltLogChannelMaxMessageLength	1..1
DltLogChannelMaxNumOfRetries	1..1
DltLogChannelThreshold	1..1
DltLogChannelTrafficShapingBandwidth	1..1
DltLogChannelTransmitCycle	1..1
DltLogTraceStatusFlag	1..1

Parameter Name	DltLogChannelBufferOverflowTimer
Description	Specifies the cycle time in seconds for resetting the buffer overflow flag in case a buffer overflow occurred. The implementation for this parameter is not done yet
Multiplicity	1..1
Type	FLOAT
Default value	1

Configuration class	VariantPreCompile:	VariantPreCompile
----------------------------	---------------------------	-------------------

Parameter Name	DltLogChannelBufferSize	
Description	Buffer size in bytes for the LogChannel specific message buffer.	
Multiplicity	1..1	
Type	INTEGER	
Configuration class	VariantPreCompile:	VariantPreCompile

Parameter Name	DltLogChannelId	
Description	This is the 4 ASCII character long name of the log channel	
Multiplicity	1..1	
Type	STRING	
Configuration class	VariantPreCompile:	VariantPreCompile

Parameter Name	DltLogChannelMaxMessageLength	
Description	The maximum length of a Dlt log or trace message.	
Multiplicity	1..1	
Type	INTEGER	
Range	>=0	
	<=65535	
Configuration class	VariantPreCompile:	VariantPreCompile

Parameter Name	DltLogChannelMaxNumOfRetries	
Description	The maximum number of retries for sending a message on a log channel , in case the message wasn't successfully sent . This parameter is not used yet	
Multiplicity	1..1	
Type	INTEGER	
Default value	0	
Range	>=0	
	<=255	
Configuration class	VariantPreCompile:	VariantPreCompile

Parameter Name	DltLogChannelThreshold	
-----------------------	-------------------------------	--

Description	This is the default log level for the channel in use	
Multiplicity	1..1	
Type	ENUMERATION	
Range	DLT_LOG_DEBUG	
	DLT_LOG_ERROR	
	DLT_LOG_FATAL	
	DLT_LOG_INFO	
	DLT_LOG_OFF	
	DLT_LOG_VERBOSE	
	DLT_LOG_WARN	
Configuration class	VariantPreCompile:	VariantPreCompile

Parameter Name	DltLogChannelTrafficShapingBandwidth	
Description	Set the maximum possible bandwidth in bit/s. The implementation for this parameter is not done yet	
Multiplicity	1..1	
Type	INTEGER	
Default value	8	
Configuration class	VariantPreCompile:	VariantPreCompile

Parameter Name	DltLogChannelTransmitCycle	
Description	Specifies the cycle time in ms of the transmit functionality of this log channel.	
Multiplicity	1..1	
Type	INTEGER	
Default value	1	
Range	>=1	
	<=1000	
Configuration class	VariantPreCompile:	VariantPreCompile

Parameter Name	DltLogTraceStatusFlag	
Description	Parameter to turn on/off sending trace information on this LogChannel completely.	
Multiplicity	1..1	

Type	BOOLEAN	
Configuration class	VariantPreCompile:	VariantPreCompile

5.2.1.10. DltTxPdu

Parameters included	
Parameter name	Multiplicity
DltITxPduHandleId	1..1
DltITxPduldRef	1..1
DltITxPduUsesTp	1..1

Parameter Name	DltITxPduHandleId
Description	The numerical value used as the ID of this I-PDU. This handle Id is used for the APIs calls Dlt_TxConfirmation, Dlt_TriggerTransmit, Dlt_TriggerIPDUSend or Dlt_TriggerIPDUSendWithMetaData, Dlt_CopyTxData and Dlt_TpTxConfirmation to transmit respectively confirm transmissions of I-PDUs, as well as the Pduld passed to the Tx-I-PDU-callout configured with DltIPduCallout and/or DltIPduTriggerTransmitCallout.
Multiplicity	1..1
Type	INTEGER
Configuration class	VariantPreCompile: VariantPreCompile

Parameter Name	DltITxPduldRef
Description	Reference to the global Pdu structure to allow harmonization of handle IDs in the COM-Stack.
Multiplicity	1..1
Type	REFERENCE
Configuration class	VariantPreCompile: VariantPreCompile

Parameter Name	DltITxPduUsesTp
Description	If set to TRUE, the PDU is transmitted using the TP API. If FALSE, the IF API is used. Implementation for this parameter is not done yet
Multiplicity	1..1
Type	BOOLEAN

Range	true	
	false	
Configuration class	VariantPreCompile:	VariantPreCompile

5.2.1.11. DltLogChannelAssignment

Parameters included	
Parameter name	Multiplicity
DltLogChannelAssignmentSwcContextRef	1..1
DltLogChannelRef	1..1

Parameter Name	DltLogChannelAssignmentSwcContextRef
Description	Reference to an ApplicationId/ContextId pair that is assigned to a DltLogChannel.
Multiplicity	1..1
Type	REFERENCE
Configuration class	VariantPreCompile: VariantPreCompile
Origin	AUTOSAR_ECUC

Parameter Name	DltLogChannelRef
Description	Reference to a DltLogChannel that is assigned to an ApplicationId / ContextId pair.
Multiplicity	1..1
Type	REFERENCE
Configuration class	VariantPreCompile: VariantPreCompile
Origin	AUTOSAR_ECUC

5.2.1.12. DltLogLevelSetting

Containers included		
Container name	Multiplicity	Description
DltLogLevelThreshold	0..n	This is the effective trace status used for a valid tuple of ApplicationId/ContextId.

Parameters included		
Parameter name	Multiplicity	
DltDefaultLogLevel	1..1	

Parameter Name	DltDefaultLogLevel	
Description	This is the effective trace status used in case no filter matches the given ApplicationId and ContextId. This can be seen as a fall-through filter definition with wildcard for ApplicationId and ContextId, which will be used, when no other filter matches.	
Multiplicity	1..1	
Type	ENUMERATION	
Range	DLT_LOG_DEBUG	
	DLT_LOG_ERROR	
	DLT_LOG_FATAL	
	DLT_LOG_INFO	
	DLT_LOG_OFF	
	DLT_LOG_VERBOSE	
	DLT_LOG_WARN	
Configuration class	VariantPreCompile:	VariantPreCompile

5.2.1.13. DltLogLevelThreshold

Parameters included		
Parameter name	Multiplicity	
DltLogLevelThresholdSwcContextRef	1..1	
DltSwCLogLevel	1..1	

Parameter Name	DltLogLevelThresholdSwcContextRef	
Description	Reference to an ApplicationId/ContextId pair to which a DltTraceStatus is assigned.	
Multiplicity	1..1	
Type	REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltSwCLogLevel	
Description	LogLevel for a mapping ApplicationId/ContextId.	
Multiplicity	1..1	
Type	ENUMERATION	
Range	DLT_LOG_DEBUG	
	DLT_LOG_ERROR	
	DLT_LOG_FATAL	
	DLT_LOG_INFO	
	DLT_LOG_OFF	
	DLT_LOG_VERBOSE	
	DLT_LOG_WARN	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.2.1.14. DltTraceStatusSetting

Containers included		
Container name	Multiplicity	Description
DltTraceStatusAssignment	0..n	This container contains a preconfiguration of ApplicationId / ContextId pairs and their assigned trace status.

Parameters included	
Parameter name	Multiplicity
DltDefaultTraceStatus	1..1

Parameter Name	DltDefaultTraceStatus	
Description	This is the effective trace status used in case no filter matches the given ApplicationId and ContextId. This can be seen as a fall-through filter definition with wildcard for ApplicationId and ContextId, which will be used, when no other filter matches.	
Multiplicity	1..1	
Type	BOOLEAN	
Configuration class	VariantPreCompile:	VariantPreCompile

5.2.1.15. DltTraceStatusAssignment

Parameters included	
Parameter name	Multiplicity
DltTraceStatusAssignmentSwcContextRef	1..1
DltTraceStatus	1..1

Parameter Name	DltTraceStatusAssignmentSwcContextRef	
Description	Reference to an ApplicationId/ContextId pair to which a DltTraceStatus is assigned.	
Multiplicity	1..1	
Type	REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltTraceStatus	
Description	Trace status for the given ApplicationId/ContextId tuple.	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile

5.2.1.16. DltMultipleConfigurationContainer

Containers included		
Container name	Multiplicity	Description
DltBandwidth	1..1	Configuration parameters controlling network and diagnostic interfaces bandwidth. If DltImplementNVRamStorage is enabled these parameters are the initial values for the NVRam. If DltImplementNVRamStorage is not set, Link-Time or Post-Build configuration shall be used.
DltMessageFiltering	1..1	Configuration parameters for setting message filtering properties in Dlt module.
DltBswDistribution	1..1	Configuration parameters controlling the BSW distribution of the Dlt module on multi-core platforms.

Containers included		
DltPduConfig	1..1	Configuration parameters referencing the Pdus for transmitting and receiving messages.
DltServiceAPI	1..1	Support for AUTOSAR API releases
DltProtocol	1..1	Configuration parameters for handling the specific protocol variants.

Parameters included	
Parameter name	Multiplicity
DltNvRamBlockRef	1..1
DltNvRamDataSetBlockRef	1..1
DltMainFunctionPeriod	1..1

Parameter Name	DltNvRamBlockRef	
Description	Reference to the NvM Block which is used to store the Dlt parameters.	
Multiplicity	1..1	
Type	SYMBOLIC-NAME-REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltNvRamDataSetBlockRef	
Description	Reference to the NvM DataSetBlock which is used to store the Dlt parameters.	
Multiplicity	1..1	
Type	SYMBOLIC-NAME-REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltMainFunctionPeriod	
Description	Period of Dlt_MainFunction calls in seconds.	
Multiplicity	1..1	
Type	FLOAT	
Default value	0.1	
Range	<=1.000	
	>=0.001	

Configuration class	VariantPreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

5.2.1.17. DltBandwidth

Parameters included	
Parameter name	Multiplicity
DltBandwidthForComModule	1..1
DltBandwidthForDiagChannel	1..1
DltTimePeriodTrafficShaping	1..1

Parameter Name	DltBandwidthForComModule	
Description	For communication over the Dlt Communication Module the maximum bandwidth shall be set. Unit: kbits/s. Note : Parameter is editable only if Traffic Shaping functionality is enabled via DltEnableTrafficShaper.	
Multiplicity	1..1	
Type	INTEGER	
Default value	8	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltBandwidthForDiagChannel	
Description	For communication over the DCM and as follows over the diagnostic interface the maximum bandwidth shall be set. Note : Functionality for DltBandwidthForDiagChannel is currently not implemented.	
Multiplicity	1..1	
Type	INTEGER	
Default value	0	
Range	<div><=4294967295</div> <div>>=0</div>	
Configuration class	VariantPreCompile:	VariantPreCompile

Origin	AUTOSAR_ECUC	
Parameter Name	DltTimePeriodTrafficShaping	
Description	<p>For implementing a traffic shaping, a time window for measuring shall be provided. This parameter specifies the size of this Window in milliseconds. Upper limit: 300000ms (5 minutes).</p> <p>Note : Parameter is editable only if Traffic Shaping functionality is enabled.</p>	
Multiplicity	1..1	
Type	FLOAT	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.2.1.18. DltMessageFiltering

Parameters included	
Parameter name	Multiplicity
DltDefaultMaxLogLevel	1..1
DltDefaultTraceStatus	1..1
DltFactoryDefaultMaxLogLevel	1..1
DltFilterMessages	1..1

Parameter Name	DltDefaultMaxLogLevel
Description	<p>The maximum log level a received message (from SW-C to Dlt) can have. This can also be modified at runtime and stored persistently in NVRAM. If DltImplementNVRamStorage is enabled this parameter is the initial value for the corresponding NVRam entry. If DltImplementNVRamStorage is not set, Link-Time or Post-Build configuration shall be used. The value 0 means logging is disabled. Note: This parameter is disabled with AUTOSAR_43 or later version. With the Autosar_43 or later default value for log messages is configured with DltDefaultLogLevel from DltLogLevelSetting.</p>
Multiplicity	1..1
Type	INTEGER
Default value	3
Range	<div><=6</div> <div>>=0</div>

Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltDefaultTraceStatus	
Description	Tells if trace messages shall be forwarded by Dlt. This functionality can also be modified at runtime and changed can stored persistently in NVRAM. If DltImplementNVRamStorage is enabled this parameter is the initial value for the corresponding NVRam entry. If DltImplementNVRamStorage is not set, Link-Time or Post-Build configuration shall be used. Note: This parameter is disabled with the Autosar_43 or later. Instead DltDefaultTraceStatus from the DltTraceStatusSetting is used	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	true	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltFactoryDefaultMaxLogLevel	
Description	The maximum log levels a received message (from SW-C to Dlt) can have. This is for setting DltDefaultMaxLogLevel to factory defaults. The value 0 means logging is disabled.	
Multiplicity	1..1	
Type	INTEGER	
Default value	3	
Range	<div><=6</div> <div>>=0</div>	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltFilterMessages	
Description	This flag gives the Dlt the instruction to filter or not to filter incoming log or trace messages. If it is not set all incoming messages are forwarded to the communication channel. So also the caller of the DltSendXXXMessage can leave the field trace_info or log_info empty.	
Multiplicity	1..1	
Type	BOOLEAN	

Default value	true	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.2.1.19. DltBswDistribution

Containers included		
Container name	Multiplicity	Description
DltSatelliteCore	0..n	Core IDs of satellite cores.

Parameters included	
Parameter name	Multiplicity
DltEnableBswDistribution	1..1
DltNumberOfSatellites	1..1
DltNumberOfMessagesPerSatellite	1..1
DltCoreSyncQueueSize	1..1
DltMasterCore	1..1

Parameter Name	DltEnableBswDistribution
Description	Enable BSW distribution features for Dlt.
Multiplicity	1..1
Type	BOOLEAN
Default value	false
Configuration class	PreCompile: VariantPreCompile
Origin	Elektrobit Automotive GmbH

Parameter Name	DltNumberOfSatellites
Description	Number of satellite cores (in addition to the master core).
Multiplicity	1..1
Type	INTEGER
Default value	1
Configuration class	PreCompile: VariantPreCompile
Origin	Elektrobit Automotive GmbH

Parameter Name	DltNumberOfMessagesPerSatellite	
Description	Number of messages per satellite core. The queue size for the reception policy of the master is generated according to the number of satellites and according to the value configured for this parameter. This way a minimisation of the possibility of losing message, in case the data received events are mapped to a task which is not immediately planned and the master cannot read fast enough, is performed.	
Multiplicity	1..1	
Type	INTEGER	
Default value	1	
Range	<=65535	
	>=1	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltCoreSyncQueueSize	
Description	The queue size for the reception policy of sync data for each satellite. Increasing this value will decrease the possibility of losing sync data, in case sync data is generated too fast and the satellite RTE task is not scheduled in time to empty the queue. When this queue size is too small, the DET error DLT_E_CORE_SYNC_FAILED is reported.	
Multiplicity	1..1	
Type	INTEGER	
Default value	1	
Range	<=65535	
	>=1	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltMasterCore	
Description	Core ID of the Dlt master.	
Multiplicity	1..1	
Type	SYMBOLIC-NAME-REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

5.2.1.20. DltSatelliteCore

Parameters included	
Parameter name	Multiplicity
DltSatelliteCoreId	1..1

Parameter Name	DltSatelliteCoreId	
Description	Core ID of the core a satellite is running on.	
Multiplicity	1..1	
Type	SYMBOLIC-NAME-REFERENCE	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

5.2.1.21. DltPduConfig

Parameters included	
Parameter name	Multiplicity
DltRxPduId	0..1
DltRxPduRef	1..1
DltTxPduId	1..1
DltTxPduRef	1..1
DltEnableMultipleFrames	1..1
DltDiscardMsgTxFail	1..1

Parameter Name	DltRxPduId	
Description	PduId of Pdu for receiving messages. If enabled, Dlt can receive Control Messages.	
Multiplicity	0..1	
Type	INTEGER	
Default value	0	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltRxPduRef
----------------	-------------

Description	Reference to Pdu for receiving messages. This parameter is only available if DltRxPduld is enabled.	
Multiplicity	1..1	
Type	SYMBOLIC-NAME-REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltTxPduld	
Description	Pduld of Pdu for transmitting messages.	
Multiplicity	1..1	
Type	INTEGER	
Default value	0	
Range	<=65535	
	>=0	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltTxPduRef	
Description	Reference to Pdu for transmitting messages. Note : This parameter is disabled if AUTOSAR_43 or newer version is configured Default value will be the Pdu wich is assigned to the default log channel	
Multiplicity	1..1	
Type	SYMBOLIC-NAME-REFERENCE	
Configuration class	PreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltEnableMultipleFrames	
Description	If enabled, multiple Dlt frames are transmitted within one Pdu. The number of frames per Pdu depends on the size of the individual frames and the Dlt-MaxMessageLength setting, i.e. as many frames are transmitted as fit into one Pdu.	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	

Configuration class	VariantPreCompile: VariantPreCompile
Origin	Elektrobit Automotive GmbH

Parameter Name	DltDiscardMsgTxFail
Description	Defines if DLT messages are discarded or not when transmit request to PduR return an error. If enabled the messages will be discarded by DLT when PduR_ - DltTransmit returns E_NOT_OK.
Multiplicity	1..1
Type	BOOLEAN
Default value	true
Configuration class	VariantPreCompile: VariantPreCompile
Origin	AUTOSAR_ECUC

5.2.1.22. DltServiceAPI

Parameters included	
Parameter name	Multiplicity
DltServiceAPI	1..1

Parameter Name	DltServiceAPI
Label	Default AUTOSAR return values
Description	<p>Defines the default AUTOSAR return values.</p> <ul style="list-style-type: none"> ▶ AUTOSAR_421 = AUTOSAR 4.2.1 return values (default) ▶ AUTOSAR_422 = AUTOSAR 4.2.2 return values ▶ AUTOSAR_431 = AUTOSAR 4.3.1 return values
Multiplicity	1..1
Type	ENUMERATION
Default value	AUTOSAR_421
Range	<div>AUTOSAR_421</div> <div>AUTOSAR_422</div> <div>AUTOSAR_431</div>
Configuration class	VariantPreCompile: VariantPreCompile
Origin	Elektrobit Automotive GmbH

5.2.1.23. DltProtocol

Parameters included	
Parameter name	Multiplicity
DltHeaderUseEcuid	1..1
DltEcuid	1..1
DltEcuidCallout	1..1
DltHeaderPayloadEndianes	1..1
DltHeaderUseExtendedHeader	1..1
DltHeaderUseSessionID	1..1
DltHeaderUseTimestamp	1..1
DltMaxMessageLength	1..1
DltUseVerboseMode	1..1
DltGetSoftwareVersion	1..1
DltGetSoftwareVersionLength	1..1
DltEcuidChoice	1..1

Parameter Name	DltHeaderUseEcuid
Description	Corresponds to field WEID (With ECU ID). If set ECU ID shall be placed in the header, else not.
Multiplicity	1..1
Type	BOOLEAN
Default value	true
Configuration class	VariantPreCompile: VariantPreCompile
Origin	AUTOSAR_ECUC

Parameter Name	DltEcuid
Description	This is the name of the ECU for use within the Dlt protocol. The meaning is described in the AUTOSAR SWS document. This name is transmitted within the Dlt protocol and contains 4 characters.
Multiplicity	1..1
Type	STRING
Configuration class	PreCompile: VariantPreCompile
Origin	AUTOSAR_ECUC

Parameter Name	DltEcuidCallout	
Description	This is the name of the user callout to call in order to get the ECU id.	
Multiplicity	1..1	
Type	STRING	
Default value	Dlt_AppGetEcuidAddress	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltHeaderPayloadEndianes	
Description	Determines the endianness of the CPU (Most Significant Byte).	
Multiplicity	1..1	
Type	ENUMERATION	
Default value	LittleEndian	
Range	BigEndian LittleEndian	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltHeaderUseExtendedHeader	
Description	Corresponds to field UEH (Use Extended Header). If set the Extended Header shall be attached, else not.	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltHeaderUseSessionID	
Description	Corresponds to field WSID (with Session ID). If set the Session ID shall be placed in the header, else not.	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	true	
Configuration class	VariantPreCompile:	VariantPreCompile

Origin	AUTOSAR_ECUC
---------------	--------------

Parameter Name	DltHeaderUseTimestamp	
Description	Corresponds to field WTMS (With Timestamp). If set the timestamp shall be placed in the header, else not.	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltMaxMessageLength	
Description	The maximum length of a Dlt log or trace message.	
Multiplicity	1..1	
Type	INTEGER	
Default value	128	
Configuration class	PreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltUseVerboseMode	
Description	If this flag is set Dlt shall use the Verbose Mode for generating the header of the transport protocol. Also it shall store the information provided by registering Context ID and Application ID (description) at runtime if flag is set. If it is not set, the Non Verbose Mode shall be used.	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltGetSoftwareVersion	
Label	GetSoftwareVersion control message	
Description	Enables the control message GetSoftwareVersion.	
Multiplicity	1..1	
Type	BOOLEAN	

Default value	false
----------------------	-------

Parameter Name	DltGetSoftwareVersionLength
Label	GetSoftwareVersion control message length
Description	The length of the ECU software version string in bytes.
Multiplicity	1..1
Type	INTEGER

Parameter Name	DltEculdChoice
Label	Get Eculd via
Description	Enables the user to provide Eculd at runtime via a user defined callout function
Multiplicity	1..1
Type	ENUMERATION
Default value	Value
Range	Value Callout

5.2.1.24. DltDefensiveProgramming

Parameters included	
Parameter name	Multiplicity
DltDefProgEnabled	1..1
DltPrecondAssertEnabled	1..1
DltPostcondAssertEnabled	1..1
DltStaticAssertEnabled	1..1
DltUnreachAssertEnabled	1..1
DltInvariantAssertEnabled	1..1

Parameter Name	DltDefProgEnabled
Label	Enable Defensive Programming
Description	<p>Enables or disables the defensive programming feature for the module Dlt.</p> <p>Note: This feature is dependent on the use of the development error detection module. To use the defensive programming feature, proceed as follows:</p> <ol style="list-style-type: none"> 1. Enable development error detection

	2. Enable defensive programming 3. Enable assertions as required
Multiplicity	1..1
Type	BOOLEAN
Default value	false
Configuration class	VariantPreCompile: VariantPreCompile
Origin	Elektrobit Automotive GmbH

Parameter Name	DltPrecondAssertEnabled
Label	Enable Precondition Assertions
Description	Enables handling of precondition assertion checks reported from the module Dlt. Dependency on parameter(s): <ul style="list-style-type: none"> ▶ Enable Development Error Detection (DltDevErrorDetect): must be enabled ▶ Enable Defensive Programming (DltDefProgEnabled): must be enabled
Multiplicity	1..1
Type	BOOLEAN
Default value	false
Configuration class	VariantPreCompile: VariantPreCompile
Origin	Elektrobit Automotive GmbH

Parameter Name	DltPostcondAssertEnabled
Label	Enable Postcondition Assertions
Description	Enables handling of postcondition assertion checks reported from the module Dlt. Dependency on parameter(s): <ul style="list-style-type: none"> ▶ Enable Development Error Detection (DltDevErrorDetect): must be enabled ▶ Enable Defensive Programming (DltDefProgEnabled): must be enabled
Multiplicity	1..1
Type	BOOLEAN
Default value	false
Configuration class	VariantPreCompile: VariantPreCompile

Origin	Elektrobit Automotive GmbH
---------------	----------------------------

Parameter Name	DltStaticAssertEnabled	
Label	Enable Static Assertions	
Description	<p>Enables handling of static assertion checks reported from the module Dlt.</p> <p>Dependency on parameter(s):</p> <ul style="list-style-type: none"> ▶ Enable Development Error Detection (DltDevErrorDetect): must be enabled ▶ Enable Defensive Programming (DltDefProgEnabled): must be enabled 	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltUnreachAssertEnabled	
Label	Enable Unreachable Code Assertions	
Description	<p>Enables handling of unreachable code assertion checks reported from the module Dlt.</p> <p>Dependency on parameter(s):</p> <ul style="list-style-type: none"> ▶ Enable Development Error Detection (DltDevErrorDetect): must be enabled ▶ Enable Defensive Programming (DltDefProgEnabled): must be enabled 	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltInvariantAssertEnabled	
Label	Enable Invariant Assertions	
Description	Enables handling of invariant assertion checks reported from functions of the module Dlt.	

	Dependency on parameter(s):	
	<ul style="list-style-type: none"> ▶ Enable Development Error Detection (<code>DltDevErrorDetect</code>): must be enabled ▶ Enable Defensive Programming (<code>DltDefProgEnabled</code>): must be enabled 	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

5.2.1.25. DltSwc

Containers included		
Container name	Multiplicity	Description
DltSwcContext	1..n	This container contains the configuration of ApplicationId / ContextId pairs which are supported by this SWC.

Parameters included	
Parameter name	Multiplicity
DltSwcSessionId	1..1
DltSwcSupportLogLevelChangeNotification	1..1
MaxSwcLogMessageLength	1..1
MaxSwcTraceMessageLength	1..1
DltProvideControlServicePort	1..1
DltProvideSwcMessageServicePort	1..1
DltProvideLogTraceSessionControlPort	1..1

Parameter Name	DltSwcSessionId
Description	An ECU wide unique ID to identify the port a SWC (instance) uses. It is supported starting with AUTOSAR_431 Note: Base value ID for SWCs will be 0x1000. From this value DltSwcSupportLogLevelChangeNotification parameter will be enabled and can be used. Values < 0x1000 will be for BSW modules and they cannot be notified about log and trace changes
Multiplicity	1..1

Type	INTEGER
Range	<=4294967295
	>=0
Configuration class	VariantPreCompile: VariantPreCompile
Origin	AUTOSAR_ECUC

Parameter Name	DltSwcSupportLogLevelChangeNotification
Description	Flag indicating, whether Dlt has to provide a R-Port for the notification of the SWC about LogLevel changes. If this parameter is set to true, at each log information change, Dlt shall notify the SwC via LogLevelChangedNotification about it. Note : Parameter in use only for DltSwcSessionId >= 0x1000
Multiplicity	1..1
Type	BOOLEAN
Default value	false
Configuration class	PreCompile: VariantPreCompile
Origin	AUTOSAR_ECUC

Parameter Name	MaxSwcLogMessageLength
Description	Defines the maximum allowed length (unit16) for LogMessages of a SwC.
Multiplicity	1..1
Type	INTEGER
Range	>=0
	<=65535
Configuration class	VariantPreCompile: VariantPreCompile
Origin	AUTOSAR_ECUC

Parameter Name	MaxSwcTraceMessageLength
Description	Defines the maximum allowed length (unit16) for TraceMessages of a SwC.
Multiplicity	1..1
Type	INTEGER
Range	>=0
	<=65535
Configuration class	VariantPreCompile: VariantPreCompile

Origin	AUTOSAR_ECUC	
Parameter Name	DltProvideControlServicePort	
Label	Generate ControlService Port	
Description	<p>Enables the generation of the <code>DltControlService</code> port</p> <p>Dependency on parameter(s):</p> <ul style="list-style-type: none"> ▶ <code>DltRteUsage</code> must be enabled. <p>This port includes the following operations:</p> <ul style="list-style-type: none"> ▶ <code>SetDefaultLogLevel</code> ▶ <code>GetDefaultLogLevel</code> ▶ <code>SetDefaultTraceStatus</code> ▶ <code>GetDefaultTraceStatus</code> ▶ <code>SetLogLevel</code> ▶ <code>GetLogInfo</code> ▶ <code>SetTraceStatus</code> ▶ <code>GetTraceStatus</code> ▶ <code>SetMessageFiltering</code> ▶ <code>GetLogChannelNames</code> ▶ <code>GetLogChannelThreshold</code> ▶ <code>SetLogChannelAssignment</code> ▶ <code>SetLogChannelThreshold</code> ▶ <code>ResetToFactoryDefault</code> ▶ <code>StoreConfiguration</code> 	
Multiplicity	1..1	
Type	BOOLEAN	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltProvideSwcMessageServicePort	
Label	Generate SwcMessageService Port	
Description	<p>Enables the generation of the <code>DltSwcMessageService</code> port</p> <p>Dependency on parameter(s):</p>	

	<p>► <code>DltRteUsage</code> must be enabled.</p> <p>This port includes the following operations:</p> <ul style="list-style-type: none"> ► <code>RegisterContext</code> ► <code>UnregisterContext</code> ► <code>SendLogMessage</code> ► <code>SendTraceMessage</code> 	
Multiplicity	1..1	
Type	BOOLEAN	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

Parameter Name	DltProvideLogTraceSessionControlPort	
Label	Generate LogTraceSessionControl Port	
Description	<p>Enables the generation of the <code>LogTraceSessionControl</code> port</p> <p>Dependency on parameter(s):</p> <ul style="list-style-type: none"> ► <code>DltRteUsage</code> must be enabled. ► <code>DltSwcSupportLogLevelChangeNotification</code> must be enabled. <p>This port includes the following operations:</p> <ul style="list-style-type: none"> ► <code>LogLevelChangedNotification</code> ► <code>TraceStatusChangedNotification</code> 	
Multiplicity	1..1	
Type	BOOLEAN	
Default value	false	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	Elektrobit Automotive GmbH	

5.2.1.26. DltSwcContext

Parameters included	
Parameter name	Multiplicity
DltSwcApplicationId	1..1

Parameters included	
DltSwcContextId	1..1

Parameter Name	DltSwcApplicationId	
Description	SWC Application Id.	
Multiplicity	1..1	
Type	INTEGER	
Default value	0	
Range	>=1	
	<=4294967295	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

Parameter Name	DltSwcContextId	
Description	SWC Context Id.	
Multiplicity	1..1	
Type	INTEGER	
Default value	0	
Range	>=1	
	<=4294967295	
Configuration class	VariantPreCompile:	VariantPreCompile
Origin	AUTOSAR_ECUC	

5.2.1.27. PublishedInformation

Parameters included	
Parameter name	Multiplicity
PbcfgMSupport	1..1

Parameter Name	PbcfgMSupport
Label	PbcfgM support
Description	Specifies whether or not the Dlt can use the PbcfgM module for post-build support.

Multiplicity	1..1
Type	BOOLEAN
Default value	false
Configuration class	PublishedInformation:
Origin	Elektrobit Automotive GmbH

5.2.2. Application programming interface (API)

5.2.2.1. Type definitions

5.2.2.1.1. Dlt_ApplicationIDType

Purpose	This type describes the Application ID.
Type	uint8[4U]

5.2.2.1.2. Dlt_AssignmentOperation

Purpose	Assignment operation used for setting log channel assignments.
Type	uint8

5.2.2.1.3. Dlt_AssignmentOperationType

Purpose	Assignment operation used for setting log channel assignments.
Type	uint8

5.2.2.1.4. Dlt_ContextIDType

Purpose	This type describes the Context ID.
Type	uint8[4U]

5.2.2.1.5. Dlt_CtrlReturnType

Purpose	
Type	uint8

5.2.2.1.6. Dlt_FilterMessagesType

Purpose	
Type	uint8

5.2.2.1.7. Dlt_GlobalLogStatusType

Purpose	
Type	uint8

5.2.2.1.8. Dlt_Internal_ApplicationIDType

Purpose	Internal representation of Dlt_ApplicationIDType.
Type	uint32

5.2.2.1.9. Dlt_Internal_ContextIDType

Purpose	Internal representation of Dlt_ContextIDType.
Type	uint32

5.2.2.1.10. Dlt_MessageArgumentCountType

Purpose	
Type	uint16

5.2.2.1.11. Dlt_MessageCommonInfoType

Purpose	
Type	struct

Members	Dlt_MessageArgumentCountType arg_count	
	Dlt_MessageLogTraceType log_ level_trace_info	
	Dlt_MessageOptionsType options	
	Dlt_ContextIDType context_id	
	Dlt_ApplicationIDType app_id	

5.2.2.1.12. Dlt_MessageControlInfoType

Purpose	
Type	uint8

5.2.2.1.13. Dlt_MessageIDType

Purpose	Contains the unique Message ID for a message.
Type	uint8

5.2.2.1.14. Dlt_MessageLogInfoType

Purpose		
Type	struct	
Members	Dlt_MessageArgumentCountType arg_count	
	Dlt_MessageLogLevelType log_ level	
	Dlt_MessageOptionsType options	
	Dlt_ContextIDType context_id	
	Dlt_ApplicationIDType app_id	

5.2.2.1.15. Dlt_MessageLogLevelType

Purpose	
Type	uint8

5.2.2.1.16. Dlt_MessageLogTraceType

Purpose	
Type	uint8

5.2.2.1.17. Dlt_MessageNetworkTraceInfoType

Purpose	
Type	uint8

5.2.2.1.18. Dlt_MessageOptionsType

Purpose	Bitfield.
Type	uint8

5.2.2.1.19. Dlt_MessageTraceInfoType

Purpose		
Type	struct	
Members	Dlt_MessageTraceType trace_info	
	Dlt_MessageOptionsType options	
	Dlt_ContextIDType context_id	
	Dlt_ApplicationIDType app_id	

5.2.2.1.20. Dlt_MessageTraceStatusType

Purpose	
Type	uint8

5.2.2.1.21. Dlt_MessageTraceType

Purpose	
----------------	--

Type	uint8
-------------	-------

5.2.2.1.22. Dlt_MessageTypeType

Purpose	This type describes the type of the message.
Type	uint8

5.2.2.1.23. Dlt_MsgLengthType

Purpose	Type that represents the length of a Dlt message.
Type	uint16

5.2.2.1.24. Dlt_ReturnType

Purpose	
Type	uint8

5.2.2.1.25. Dlt_SessionIDType

Purpose	This type describes the Session ID.
Type	uint32

5.2.2.1.26. Dlt_TxConnectionType

Purpose		
Type	struct	
Members	PduLengthType PositionInMessage	Holds the index of valid data in bytes to be transmitted from the current message. This also represents the amount of data which has already been copied to the lower layer from the current message, though not confirmed.
	PduLengthType ConfirmedPositionInMessage	Holds the index of confirmed data in bytes to be transmitted from this message. This

	also represents the amount of data which has already been copied to the lower layer from the current message and the transmission of which has been confirmed by the lower layer.
--	---

5.2.2.2. Macro constants

5.2.2.2.1. DLT_AR_RELEASE_MAJOR_VERSION

Purpose	AUTOSAR release major version.
Value	4U

5.2.2.2.2. DLT_AR_RELEASE_MINOR_VERSION

Purpose	AUTOSAR release minor version.
Value	2U

5.2.2.2.3. DLT_AR_RELEASE_REVISION_VERSION

Purpose	AUTOSAR release revision version.
Value	1U

5.2.2.2.4. DLT_ASSIGN_ADD

Purpose	This marco is used to add a channel assignment to a registered context.
Value	0x01U

5.2.2.2.5. DLT_ASSIGN_REMOVE

Purpose	This marco is used to remove a channel assignment to a registered context.
Value	0x02U

5.2.2.2.6. DLT_CONTROL_REQUEST

Purpose	Request Control Message.
Value	0x01U

5.2.2.2.7. DLT_CONTROL_RESPONSE

Purpose	Respond Control Message.
Value	0x02U

5.2.2.2.8. DLT_CTRL_ERROR

Purpose	
Value	0x02U

5.2.2.2.9. DLT_CTRL_NOT_SUPPORTED

Purpose	
Value	0x01U

5.2.2.2.10. DLT_CTRL_OK

Purpose	
Value	0x00U

5.2.2.2.11. DLT_E_COM_FAILURE

Purpose	Development error for error in communication module.
Value	0x03U

5.2.2.2.12. DLT_E_CONTEXT_ALREADY_REG

Purpose	
----------------	--

Value	0x02U
--------------	-------

5.2.2.2.13. DLT_E_CORE_SYNC_FAILED

Purpose	Development error for core synchronization.
Value	0x0BU

5.2.2.2.14. DLT_E_ERROR_IN_PROV_SERVICE

Purpose	Development error for error in provided service.
Value	0x02U

5.2.2.2.15. DLT_E_ERROR_TO_MANY_CONTEXT

Purpose	Development error for too many registered contexts.
Value	0x04U

5.2.2.2.16. DLT_E_ERROR_UNKNOWN

Purpose	
Value	0x06U

5.2.2.2.17. DLT_E_IF_BUSY

Purpose	
Value	0x05U

5.2.2.2.18. DLT_E_IF_NOT_AVAILABLE

Purpose	
Value	0x04U

5.2.2.2.19. DLT_E_MSG_LOOSE

Purpose	Development error for message buffer overflow.
Value	0x05U

5.2.2.2.20. DLT_E_MSG_TOO_LARGE

Purpose	
Value	0x01U

5.2.2.2.21. DLT_E_NOT_INITIALIZED

Purpose	Development error for wrong initialization state.
Value	0x08U

5.2.2.2.22. DLT_E_NOT_INITIALIZED_PERSISTENT

Purpose	Development error for wrong initialization state.
Value	0x09U

5.2.2.2.23. DLT_E_NOT_IN_VERBOSE_MODE

Purpose	
Value	0x08U

5.2.2.2.24. DLT_E_NOT_SUPPORTED

Purpose	This marco is used to twhron a not supported error in case the Service is not supported.
Value	0x07U

5.2.2.2.25. DLT_E_OK

Purpose	
----------------	--

Value	0x00U
--------------	-------

5.2.2.2.26. DLT_E_PARAM_POINTER

Purpose	Development error for NULL pointer passed to an API.
Value	0x06U

5.2.2.2.27. DLT_E_PENDING

Purpose	
Value	0x07U

5.2.2.2.28. DLT_E_REQUEST_NOT_ACCEPTED

Purpose	Development error for read/write request unsuccessful.
Value	0x0AU

5.2.2.2.29. DLT_E_UNKNOWN_SESSION_ID

Purpose	
Value	0x03U

5.2.2.2.30. DLT_E_WRONG_PARAMETERS

Purpose	Development error for wrong parameters.
Value	0x01U

5.2.2.2.31. DLT_FILTER_MESSAGES_OFF

Purpose	
Value	0x00U

5.2.2.2.32. DLT_FILTER_MESSAGES_ON

Purpose	
Value	0x01U

5.2.2.2.33. DLT_GETLOGININFO_OPTIONS_NO_DESC

Purpose	
Value	0x06U

5.2.2.2.34. DLT_GETLOGININFO_OPTIONS_WITH_DESC

Purpose	
Value	0x07U

5.2.2.2.35. DLT_LOGGING_DISABLED

Purpose	
Value	0x00U

5.2.2.2.36. DLT_LOGGING_ENABLED

Purpose	
Value	0x01U

5.2.2.2.37. DLT_LOG_DEBUG

Purpose	Message of LogLevel type Debug.
Value	0x05U

5.2.2.2.38. DLT_LOG_DEFAULT

Purpose	Message of LogLevel type Default.
----------------	-----------------------------------

Value	0xffU
--------------	-------

5.2.2.2.39. DLT_LOG_ERROR

Purpose	Application error.
Value	0x02U

5.2.2.2.40. DLT_LOG_FATAL

Purpose	Fatal system error.
Value	0x01U

5.2.2.2.41. DLT_LOG_INFO

Purpose	Message of LogLevel type Information.
Value	0x04U

5.2.2.2.42. DLT_LOG_OFF

Purpose	Message of LogLevel type Information.
Value	0x00U

5.2.2.2.43. DLT_LOG_VERBOSE

Purpose	Message of LogLevel type Verbose.
Value	0x06U

5.2.2.2.44. DLT_LOG_WARN

Purpose	Correct behavior cannot be ensured.
Value	0x03U

5.2.2.2.45. DLT_MODULE_ID

Purpose	AUTOSAR module identification.
Value	55U

5.2.2.2.46. DLT_NW_TRACE_CAN

Purpose	CAN Communications bus.
Value	0x02U

5.2.2.2.47. DLT_NW_TRACE_FLEXRAY

Purpose	FlexRay Communications bus.
Value	0x03U

5.2.2.2.48. DLT_NW_TRACE_IPC

Purpose	Inter-Process-Communication.
Value	0x01U

5.2.2.2.49. DLT_NW_TRACE_MOST

Purpose	Most Communications bus.
Value	0x04U

5.2.2.2.50. DLT_SID_ComCopyRxData

Purpose	Service Id for Dlt_ComCopyRxData() .
Value	0x44U

5.2.2.2.51. DLT_SID_ComCopyTxData

Purpose	Service Id for Dlt_ComCopyTxData() .
----------------	--

Value	0x43U
--------------	-------

5.2.2.2.52. DLT_SID_ComRxIndication

Purpose	Service Id for Dlt_ComRxIndication() .
Value	0x42U

5.2.2.2.53. DLT_SID_ComStartOfReception

Purpose	Service Id for Dlt_ComStartOfReception() .
Value	0x46U

5.2.2.2.54. DLT_SID_GetComInterfaceMaxBandwidth

Purpose	Service Id for Dlt_GetComInterfaceMaxBandwidth() .
Value	0xE8U

5.2.2.2.55. DLT_SID_GetDefaultLogLevel

Purpose	Service Id for Dlt_ASR42/43_GetDefaultLogLevel() .
Value	0x18U

5.2.2.2.56. DLT_SID_GetDefaultTraceStatus

Purpose	Service Id for Dlt_ASR42/43_GetDefaultTraceStatus() .
Value	0x19U

5.2.2.2.57. DLT_SID_GetEculdAddress

Purpose	Service Id for Dlt_AppGetEculdAddress() .
Value	0x89U

5.2.2.2.58. DLT_SID_GetGlobalLogging

Purpose	Service Id for Dlt_GetGlobalLogging() .
Value	0xADU

5.2.2.2.59. DLT_SID_GetLogChannelNames

Purpose	Service Id for Dlt_GetLogChannelNames() .
Value	0x17U

5.2.2.2.60. DLT_SID_GetLogChannelThreshold

Purpose	Service Id for Dlt_GetLogChannelThreshold() .
Value	0x22U

5.2.2.2.61. DLT_SID_GetLogInfo

Purpose	Service Id for Dlt_GetLogInfo() .
Value	0x0AU

5.2.2.2.62. DLT_SID_GetLogLevel

Purpose	Service Id for Dlt_GetLogLevel() .
Value	0xAAU

5.2.2.2.63. DLT_SID_GetMessageFilteringStatus

Purpose	Service Id for Dlt_GetMessageFilteringStatus() .
Value	0xE6U

5.2.2.2.64. DLT_SID_GetTraceStatus

Purpose	Service Id for Dlt_AS42/43_GetTraceStatus() .
----------------	---

Value	0x1FU
--------------	-------

5.2.2.2.65. DLT_SID_GetUseECUID

Purpose	Service Id for Dlt_GetUseECUID() .
Value	0xE5U

5.2.2.2.66. DLT_SID_GetUseExtendedHeader

Purpose	Service Id for Dlt_GetUseExtendedHeader() .
Value	0xE2U

5.2.2.2.67. DLT_SID_GetUseSessionID

Purpose	Service Id for Dlt_GetUseSessionID() .
Value	0xE4U

5.2.2.2.68. DLT_SID_GetVerboseModeStatus

Purpose	Service Id for Dlt_GetVerboseModeStatus() .
Value	0xE7U

5.2.2.2.69. DLT_SID_GetVersionInfo

Purpose	Service Id for Dlt_GetVersionInfo() .
Value	0x02U

5.2.2.2.70. DLT_SID_Init

Purpose	Service Id for Dlt_Init() .
Value	0x01U

5.2.2.2.71. DLT_SID_InternalReadFromDataSetApild

Purpose	Internal API Id for Dlt_NvMReadRamBlockFromNvMDataSetCbk() .
Value	0x84U

5.2.2.2.72. DLT_SID_InternalReadFromNativeApild

Purpose	Internal API Id for Dlt_NvMReadRamBlockFromNvMNativeCbk() .
Value	0x83U

5.2.2.2.73. DLT_SID_InternalRegisterContext

Purpose	Service Id for Dlt_InternalRegisterContext() .
Value	0x86U

5.2.2.2.74. DLT_SID_InternalWriteToDataSetApild

Purpose	Internal API Id for Dlt_NvMWriteRamBlockToNvMDataSetCbk() .
Value	0x82U

5.2.2.2.75. DLT_SID_InternalWriteToNativeApild

Purpose	Internal API Id for Dlt_NvMWriteRamBlockToNvMNativeCbk() .
Value	0x81U

5.2.2.2.76. DLT_SID_NvMSingleBlockCallbackNative

Purpose	Defines API id of function Dlt_NvMSingleBlockCallbackNative() .
Value	0x88U

5.2.2.2.77. DLT_SID_RegisterContext

Purpose	Service Id for Dlt_RegisterContext() .
----------------	--

Value	0x05U
--------------	-------

5.2.2.2.78. DLT_SID_ResetToFactoryDefault

Purpose	Service Id for Dlt_ResetToFactoryDefault() .
Value	0x06U

5.2.2.2.79. DLT_SID_SendLogMessage

Purpose	Service Id for Dlt_SendLogMessage() .
Value	0x03U

5.2.2.2.80. DLT_SID_SendTraceMessage

Purpose	Service Id for Dlt_SendTraceMessage() .
Value	0x04U

5.2.2.2.81. DLT_SID_SetComInterfaceMaxBandwidth

Purpose	Service Id for Dlt_SetComInterfaceMaxBandwidth() .
Value	0xF8U

5.2.2.2.82. DLT_SID_SetDefaultLogLevel

Purpose	Service Id for Dlt_SetDefaultLogLevel() .
Value	0x11U

5.2.2.2.83. DLT_SID_SetDefaultTraceStatus

Purpose	Service Id for Dlt_ASR42/43_SetDefaultTraceStatus() .
Value	0x12U

5.2.2.2.84. DLT_SID_SetGlobalLogging

Purpose	Service Id for Dlt_SetGlobalLogging() .
Value	0xACU

5.2.2.2.85. DLT_SID_SetLogChannelAssignment

Purpose	Service Id for Dlt_SetLogChannelAssignment ().
Value	0x20U

5.2.2.2.86. DLT_SID_SetLogChannelThreshold

Purpose	Service Id for Dlt_SetLogChannelThreshold ().
Value	0x21U

5.2.2.2.87. DLT_SID_SetLogLevel

Purpose	Service Id for Dlt_SetLogLevel() .
Value	0x08U

5.2.2.2.88. DLT_SID_SetMessageFiltering

Purpose	Service Id for Dlt_AS42/43_SetMessageFiltering().
Value	0x1BU

5.2.2.2.89. DLT_SID_SetTraceStatus

Purpose	Service Id for Dlt_SetTraceStatus() .
Value	0x09U

5.2.2.2.90. DLT_SID_SetUseECUID

Purpose	Service Id for Dlt_SetUseECUID() .
----------------	--

Value	0xF3U
--------------	-------

5.2.2.2.91. DLT_SID_SetUseExtendedHeader

Purpose	Service Id for Dlt_SetUseExtendedHeader() .
Value	0xF0U

5.2.2.2.92. DLT_SID_SetUseSessionID

Purpose	Service Id for Dlt_SetUseSessionID() .
Value	0xF2U

5.2.2.2.93. DLT_SID_SetVerboseMode

Purpose	Service Id for Dlt_SetVerboseMode() .
Value	0x93U

5.2.2.2.94. DLT_SID_SingleBlockCallbackDataSet

Purpose	Service Id for Dlt_NvMSingleBlockCallbackDataSet() .
Value	0x85U

5.2.2.2.95. DLT_SID_StoreConfiguration

Purpose	Service Id for Dlt_StoreConfiguration() .
Value	0x1AU

5.2.2.2.96. DLT_SID_StorePersistent

Purpose	Service Id for Dlt_StorePersistent() .
Value	0x87U

5.2.2.2.97. DLT_SID_TriggerTransmit

Purpose	Service Id for Dlt_TriggerTransmit().
Value	0x41U

5.2.2.2.98. DLT_SID_UnregisterContext

Purpose	Service Id for Dlt_UnregisterContext() .
Value	0x16U

5.2.2.2.99. DLT_SW_MAJOR_VERSION

Purpose	AUTOSAR module major version.
Value	1U

5.2.2.2.100. DLT_SW_MINOR_VERSION

Purpose	AUTOSAR module minor version.
Value	8U

5.2.2.2.101. DLT_SW_PATCH_VERSION

Purpose	AUTOSAR module patch version.
Value	3U

5.2.2.2.102. DLT_TRACE_FUNCTION_IN

Purpose	Call of a function.
Value	0x02U

5.2.2.2.103. DLT_TRACE_FUNCTION_OUT

Purpose	Return of a function.
----------------	-----------------------

Value	0x03U
--------------	-------

5.2.2.2.104. DLT_TRACE_STATE

Purpose	State of a State Machine.
Value	0x04U

5.2.2.2.105. DLT_TRACE_STATUS_DEFAULT

Purpose	
Value	0xffU

5.2.2.2.106. DLT_TRACE_STATUS_OFF

Purpose	
Value	0x00U

5.2.2.2.107. DLT_TRACE_STATUS_ON

Purpose	
Value	0x01U

5.2.2.2.108. DLT_TRACE_VARIABLE

Purpose	Value of variable.
Value	0x01U

5.2.2.2.109. DLT_TRACE_VFB

Purpose	RTE events.
Value	0x05U

5.2.2.2.110. DLT_TYPE_APP_TRACE

Purpose	A trace message.
Value	0x01U

5.2.2.2.111. DLT_TYPE_CONTROL

Purpose	A message for internal use/control send between Dlt module and external client.
Value	0x03U

5.2.2.2.112. DLT_TYPE_LOG

Purpose	A log message.
Value	0x00U

5.2.2.2.113. DLT_TYPE_NW_TRACE

Purpose	A message forwarded from a communication bus (like CAN, FlexRay).
Value	0x02U

5.2.2.2.114. DLT_VENDOR_ID

Purpose	AUTOSAR vendor identification: Elektrobit Automotive GmbH.
Value	1U

5.2.2.2.115. Dlt_GetDefaultLogLevel

Purpose	
Value	Dlt_AS43_GetDefaultLogLevel

5.2.2.2.116. Dlt_GetDefaultTraceStatus

Purpose	
----------------	--

Value	Dlt_ASR43_GetDefaultTraceStatus
--------------	---------------------------------

5.2.2.2.117. Dlt_GetLogChannelNames

Purpose	
Value	Dlt_ASR43_GetLogChannelNames

5.2.2.2.118. Dlt_GetLogChannelThreshold

Purpose	
Value	Dlt_ASR43_GetLogChannelThreshold

5.2.2.2.119. Dlt_GetLogInfo

Purpose	
Value	Dlt_ASR43_GetLogInfo

5.2.2.2.120. Dlt_GetTraceStatus

Purpose	
Value	Dlt_ASR43_GetTraceStatus

5.2.2.2.121. Dlt_NW_TRACE_ETHERNET

Purpose	Ethernet Communications bus.
Value	0x05U

5.2.2.2.122. Dlt_NW_TRACE_SOMEIP

Purpose	Inter-SOME/IP Communication.
Value	0x06U

5.2.2.2.123. Dlt_RegisterContext

Purpose	
Value	Dlt_ASR43_RegisterContext

5.2.2.2.124. Dlt_ResetToFactoryDefault

Purpose	
Value	Dlt_ASR43_ResetToFactoryDefault

5.2.2.2.125. Dlt_SendLogMessage

Purpose	
Value	Dlt_ASR43_SendLogMessage

5.2.2.2.126. Dlt_SendTraceMessage

Purpose	
Value	Dlt_ASR43_SendTraceMessage

5.2.2.2.127. Dlt_SetDefaultLogLevel

Purpose	
Value	Dlt_ASR43_SetDefaultLogLevel

5.2.2.2.128. Dlt_SetDefaultTraceStatus

Purpose	
Value	Dlt_ASR43_SetDefaultTraceStatus

5.2.2.2.129. Dlt_SetLogChannelAssignment

Purpose	
----------------	--

Value	Dlt_ASR43_SetLogChannelAssignment
--------------	-----------------------------------

5.2.2.2.130. Dlt_SetLogChannelThreshold

Purpose	
Value	Dlt_ASR43_SetLogChannelThreshold

5.2.2.2.131. Dlt_SetLogLevel

Purpose	
Value	Dlt_ASR43_SetLogLevel

5.2.2.2.132. Dlt_SetMessageFiltering

Purpose	
Value	Dlt_ASR43_SetMessageFiltering

5.2.2.2.133. Dlt_SetTraceStatus

Purpose	
Value	Dlt_ASR43_SetTraceStatus

5.2.2.2.134. Dlt_StoreConfiguration

Purpose	
Value	Dlt_ASR43_StoreConfiguration

5.2.2.2.135. Dlt_UnregisterContext

Purpose	
Value	Dlt_ASR43_UnregisterContext

5.2.2.3. Functions

5.2.2.3.1. Dlt_ASR42_GetDefaultLogLevel

Purpose	Get default log level.
Synopsis	<code>Dlt_MessageLogLevelType Dlt_ASR42_GetDefaultLogLevel (void);</code>
Service ID	DLT_SID_GetDefaultLogLevel
Sync/Async	Synchronous
Reentrancy	Non Reentrant
Return Value	Default log level setting
Description	This service gets the default log level applied to each context for which the log level has not been set explicitly.

5.2.2.3.2. Dlt_ASR42_GetDefaultTraceStatus

Purpose	Get default trace status.
Synopsis	<code>Dlt_MessageTraceStatusType Dlt_ASR42_GetDefaultTraceStatus (void);</code>
Service ID	DLT_SID_GetDefaultTraceStatus
Sync/Async	Synchronous
Reentrancy	Non Reentrant
Return Value	Default trace status setting
Description	This service gets the default trace status applied to each context for which the trace status has not been set explicitly.

5.2.2.3.3. Dlt_ASR42_GetTraceStatus

Purpose	Get trace status.
Synopsis	<code>Dlt_CtrlReturnType Dlt_ASR42_GetTraceStatus (Dlt_Internal_ApplicationIDType AppId , Dlt_Internal_ContextIDType ContextId , Dlt_MessageTraceStatusType * TraceStatus);</code>
Service ID	DLT_SID_GetTraceStatus
Sync/Async	Synchronous
Reentrancy	Non Reentrant

Parameters (in)	AppId	The application Id for which the trace status shall be retrieved
	ContextId	The context Id for which the trace status shall be retrieved
Parameters (out)	TraceStatus	Trace status of the given application and context Ids
Return Value	Result of retrieving the trace status	
	DLT_CTRL_OK	Retrieving the trace status succeeded
	DLT_CTRL_ERROR	Retrieving the trace status failed
Description	This service returns the trace status setting for a given context	

5.2.2.3.4. Dlt_ASR42_SetDefaultLogLevel

Purpose	Set default log level.	
Synopsis	<pre>Dlt_CtrlReturnType Dlt_ASR42_SetDefaultLogLevel(Dlt_MessageLogLevelType NewLevel);</pre>	
Service ID	DLT_SID_SetDefaultLogLevel	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	NewLevel	The new default log level
Return Value	Result of changing the log level	
	DLT_CTRL_OK	Changing the log level succeeded
	DLT_CTRL_ERROR	Changing the log level failed
Description	This service sets the default log level applied to each context for which the log level has not been set explicitly.	

5.2.2.3.5. Dlt_ASR42_SetDefaultTraceStatus

Purpose	Set default trace status.	
Synopsis	<pre>Dlt_CtrlReturnType Dlt_ASR42_SetDefaultTraceStatus(Dlt_MessageTraceStatusType NewStatus);</pre>	
Service ID	DLT_SID_SetDefaultTraceStatus	
Sync/Async	Synchronous	

Reentrancy	Non Reentrant	
Parameters (in)	NewStatus	The new default trace status
Return Value	Result of changing the trace status	
	DLT_CTRL_OK	Changing the trace status succeeded
	DLT_CTRL_ERROR	Changing the trace status failed
Description	This service sets the default trace status applied to each context for which the trace status has not been set explicitly.	

5.2.2.3.6. Dlt_ASR42_SetLogLevel

Purpose	Set log level.	
Synopsis	<pre>Dlt_CtrlReturnType Dlt_ASR42_SetLogLevel (Dlt_Internal_ApplicationIDType AppId , Dlt_Internal_ContextIDType ContextId , Dlt_MessageLogLevelType NewLevel);</pre>	
Service ID	DLT_SID_SetLogLevel	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	AppId	The application Id for which the log level is set
	ContextId	The context Id for which the log level is set
	NewLevel	The new log level for the given application and context Ids
Return Value	Result of changing the log level	
	DLT_CTRL_OK	Changing the log level succeeded
	DLT_CTRL_ERROR	Changing the log level failed
Description	This service sets the maximum level a log message may have to be accepted by the Dlt module.	

5.2.2.3.7. Dlt_ASR42_SetMessageFiltering

Purpose	Enable / disable message filtering.	
Synopsis	<pre>Dlt_CtrlReturnType Dlt_ASR42_SetMessageFiltering (Dlt_FilterMessagesType NewStatus);</pre>	

Service ID	DLT_SID_SetMessageFiltering	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	NewStatus	New status of message filtering DLT_FILTER_MESSAGES_ON: enable message filtering DLT_FILTER_MESSAGES_OFF: disable message filtering
Return Value	Result of changing the message filtering status	
	DLT_CTRL_OK	Changing the message filtering status succeeded
	DLT_CTRL_ERROR	Changing the message filtering status failed
Description	This function enables and disables message filtering. If message filtering is disabled, all messages are processed by the Dlt, independently from the log level or trace status settings.	

5.2.2.3.8. Dlt_ASR42_SetTraceStatus

Purpose	Set trace status.	
Synopsis	<pre>Dlt_CtrlReturnType Dlt_ASR42_SetTraceStatus (Dlt_Internal_ApplicationIDType AppId , Dlt_Internal_ContextIDType ContextId , Dlt_MessageTraceStatusType NewStatus);</pre>	
Service ID	DLT_SID_SetTraceStatus	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	AppId	The application Id for which the trace status is set
	ContextId	The context Id for which the trace status is set
	NewStatus	The new trace status for the given application and context Ids
Return Value	Result of changing the trace status	
	DLT_CTRL_OK	Changing the trace status succeeded
	DLT_CTRL_ERROR	Changing the trace status failed
Description	This service enables or disables the processing of trace messages by the Dlt module.	

5.2.2.3.9. Dlt_ASR43_GetDefaultLogLevel

Purpose	Get default log level.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_GetDefaultLogLevel (Dlt_MessageLogLevelType * defaultLogLevel);</pre>	
Parameters (out)	defaultLogLevel	Returns the stored LogLevel setting
Return Value	Default log level setting	
	E_OK:	No error occurred
	E_NOT_OK:	The default LogLevel could not be returned
Description	<p>Returns the Default Log Level currently used by the Dlt module. The returned Log Level might differ from the one which is stored non volatile.</p> <p>ServiceID{DLT_SID_GetDefaultLogLevel} Reentrancy{Non Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.10. Dlt_ASR43_GetDefaultTraceStatus

Purpose	Get default trace status.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_GetDefault- TraceStatus (boolean * traceStatus);</pre>	
Parameters (out)	traceStatus	current global default trace status (enabled/disabled)
Return Value	Default trace status setting	
	E_OK:	No error occurred
	E_NOT_OK:	Default Trace Status could not be returned
Description	<p>Returns the current global default trace status.</p> <p>ServiceID{DLT_SID_GetDefaultTraceStatus} Reentrancy{Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.11. Dlt_ASR43_GetLogChannelNames

Purpose	Get Log Channel Names.
----------------	------------------------

Synopsis	<pre>Std_ReturnType Dlt_ASR43_GetLogChannel- Names (uint8 * numberOfLogChannels , Dlt_- LogChannelNameArrayType * logChannelNames);</pre>	
Parameters (out)	numberOfLogChannels	Returns the number of configured LogChannels
	logChannelNames	Returns a list of configured LogChannel names
Return Value	Result of changing the log level	
	DLT_CTRL_OK	Changing the log level succeeded
	DLT_CTRL_ERROR	Changing the log level failed
Description	Returns the filter threshold for the given LogChannel. ServiceID{ DLT_SID_GetLogChannelNames } Reentrancy{Non Reentrant} Synchronicity{Synchronous}	

5.2.2.3.12. Dlt_ASR43_GetLogChannelThreshold

Purpose	Get Log Channel Threshold.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_GetLogChannelThreshold (const Dlt_LogChannelNameType * logChannelName , Dlt_MessageL- ogLevelType * logChannelThreshold , boolean * traceStatus);</pre>	
Parameters (in)	logChannelName	Addressed LogChannel name
Parameters (out)	logChannelThreshold	current LogChannelTreshold
	traceStatus	Current TraceStatus. TRUE: TraceMes- sages enabled. FALSE: TraceMessages disabled.
Return Value	Result of changing the log level	
	DLT_CTRL_OK	Changing the log level succeeded
	DLT_CTRL_ERROR	Changing the log level failed
Description	Returns the filter threshold for the given LogChannel. ServiceID{ DLT_SID_GetLogChannelThreshold } Reentrancy{Reentrant for different LogChannelNames} Synchronicity{Synchronous}	

5.2.2.3.13. Dlt_ASR43_GetLogInfo

Purpose	Get log info.
----------------	---------------

Synopsis	<pre>Std_ReturnType Dlt_ASR43_GetLogInfo (uint8 options , const Dlt_ApplicationIDType * appId , const Dlt_ContextIDType * contextId , uint8 * status , uint8 * logInfo);</pre>	
Parameters (in)	options	Used to filter the response in respect to the ApplicationId, ContextId and Trace Status information
	appId	Representation of the ApplicationId
	contextId	Representation of the ContextId
Parameters (out)	status	
	logInfo	Details about the returned Application IDs
Return Value	Result of retrieving the log info	
	E_OK	No error occurred
	E_NOT_OK	LogInfo could not be returned
Description	<p>Called to request information about registered ApplicationIds, their ContextIds and the corresponding log level.</p> <p>ServiceID{DLT_SID_GetLogInfo} Reentrancy{Non Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.14. Dlt_ASR43_GetTraceStatus

Purpose	Get trace status.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_GetTraceStatus (const Dlt_ApplicationIDType * appId , const Dlt_ContextIDType * contextId , boolean * traceStatus);</pre>	
Parameters (in)	appId	ApplicationId
	contextId	ContextId
Parameters (out)	traceStatus	current Trace Status of the tuple ApplicationId/ContextId
Return Value	Result of retrieving the trace status	
	E_OK:	No error occurred
	E_NOT_OK:	TraceStatus could not be returned
Description	<p>Returns the current Trace Status for a given tuple ApplicationId/ContextId.</p> <p>ServiceID{DLT_SID_GetTraceStatus} Reentrancy{Non Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.15. Dlt_ASR43_RegisterContext

Purpose	Register new logging or tracing context.	
Synopsis	<pre>Dlt_ReturnType Dlt_ASR43_RegisterContext (Dlt_SessionID- Type session_id , const Dlt_ApplicationIDType * app_id , const Dlt_ContextIDType * context_id , const uint8 * app_- description , uint8 len_app_description , const uint8 * context_description , uint8 len_context_description);</pre>	
Parameters (in)	session_id	number of the module (Module ID within BSW, port defined argument value within SW-C)
	app_id	the Application ID
	context_id	the Context ID
	app_description	Points to description string for the provided application id. At maximum 255 characters are interpreted.
	len_app_description	The length of the description for the application id string (number of characters of description string).
	context_description	Points to description string for the provided context id. At maximum 255 characters are interpreted.
	len_context_description	The length of the description string (number of characters of description string).
Return Value	Result of registering the context	
	Autosar_4.2	DLT_E_IF_NOT_AVAILABLE The module has not been initialized, thus the interface is not available
	Autosar_4.2	DLT_E_ERROR_UNKNOWN Too many contexts have been registered
	Autosar_4.3	or below version DLT_E_CONTEXT_ALREADY_REG The software module context has already been registered
	Autosar_4.3	or below version DLT_E_UNKNOWN_SESSION_ID The session Id is unknown, i.e. it is not specified by any SW-C In Autosar_4.3 version, each time a registration of a context was not succeeded because of Dlt not be-

		ing initialized or because of a overrun number of registered contexts, or of a wrong parameter used, the DLT_E_UNKNOWN_SESSION_ID shall be returned.
	DLT_E_OK	The required operation succeeded
Description	<p>The service has to be called when a software module wants to use services offered by DLT software component for a specific context. If a context id is being registered for an already registered application id then app_description can be NULL and len_app_description zero.</p> <p>ServiceID{DLT_SID_RegisterContext} Reentrancy{Reentrant} Synchronicity{Synchronous} Possible development errors DLT_E_ERROR_TO_MANY_CONTEXT - the number of contexts to be registered has reached the maximum value DLT_E_NOT_INITIALIZED - Api was called before initializing Dlt module DLT_E_PARAM_POINTER - null pointer was used for context_description DLT_E_WRONG_PARAMETERS -wrong len_context_description was used DLT_E_UNKNOWN_SESSION_ID - wrong session id was used</p>	

5.2.2.3.16. Dlt_ASR43_ResetToFactoryDefault

Purpose	Reset the configuration to factory defaults.	
Synopsis	<code>Std_ReturnType Dlt_ASR43_ResetToFactoryDefault (void);</code>	
Return Value	Result of resetting the configuration to factory defaults	
	E_OK:	Configuration has been reset successfully
	E_NOT_OK:	Configuration has not been reset
Description	<p>The service Dlt_ResetToFactoryDefault sets the LogLevel and TraceStatus back to the persistently stored default values. If the feature NvMRAM support is enabled, all stored Dlt values in the NvM are deleted.</p> <p>ServiceID{DLT_SID_ResetToFactoryDefault} Reentrancy{Non Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.17. Dlt_ASR43_SendLogMessage

Purpose	Send a log message to the DLT module.
Synopsis	<code>Dlt_ReturnType Dlt_ASR43_SendLogMessage (Dlt_SessionID_Type session_id , const Dlt_MessageLogInfoType * log_info , const uint8 * log_data , uint16 log_data_length);</code>

Parameters (in)	<code>session_id</code>	For SW-C this is not visible (Port defined argument value), for BSW-modules it is the module number
	<code>log_info</code>	Structure containing the relevant information for filtering the message
	<code>log_data</code>	Buffer containing the parameters to be logged. The contents of this pointer represents the payload of the send log message
	<code>log_data_length</code>	Length of the data buffer <code>log_data</code>
Return Value	Result of sending the log message	
	<code>DLT_E_OK</code>	The required operation succeeded
	<code>DLT_E_MSG_TOO_LARGE</code>	The message is too large for sending over the network
	<code>DLT_E_IF_NOT_AVAILABLE</code>	The interface is not available
	<code>DLT_E_UNKNOWN_SESSION_ID</code>	The provided session id is unknown
	<code>DLT_E_NOT_IN_VERBOSE_MODE</code>	Unable to send the message in verbose mode
Description	<p>The service represents the interface to be used by basic software modules or by software component to send log messages.</p> <p>ServiceID{DLT_SID_SendLogMessage} Reentrancy{Reentrant} Synchronicity{Synchronous} Possible development errors:</p> <ul style="list-style-type: none"> ▶ <code>DLT_E_PARAM_POINTER</code> - in case a null pointer was used for <code>log_info</code> or <code>log_data</code> input ▶ <code>DLT_E_WRONG_PARAMETERS</code> - a wrong parameter is used in any case ▶ <code>DLT_E_UNKNOWN_SESSION_ID</code> - <code>session_id</code> is used with a wrong/not registered value ▶ <code>DLT_E_NO_BUFFER</code> - <code>log_data_length</code> value is greater than configured maximum length for log messages 	

5.2.2.3.18. Dlt_ASR43_SendTraceMessage

Purpose	Send a trace message to the DLT module.
Synopsis	<pre>Dlt_ReturnType Dlt_ASR43_SendTraceMessage (Dlt_SessionID- Type session_id , const Dlt_MessageTraceInfoType * trace_in- fo , const uint8 * trace_data , uint16 trace_data_length);</pre>

Parameters (in)	<code>session_id</code>	number of the module (Module ID within BSW, port defined argument value within SW-C)
	<code>trace_info</code>	Structure containing the relevant information for filtering the message
	<code>trace_data</code>	Buffer containing the parameters to be traced. The contents of this pointer represents the payload of the send log message
	<code>trace_data_length</code>	Length of the data buffer <code>trace_data</code>
Return Value	Result of sending the trace message	
	<code>DLT_E_OK</code>	The required operation succeeded
	<code>DLT_E_MSG_TOO_LARGE</code>	The message is too large for sending over the network
	<code>DLT_E_IF_NOT_AVAILABLE</code>	The interface is not available
	<code>DLT_E_UNKNOWN_SESSION_ID</code>	The provided session id is unknown
	<code>DLT_E_NOT_IN_VERBOSE_MODE</code>	Unable to send the message in verbose mode
Description	<p>The service represents the interface to be used by basic software modules or by software component to trace parameters.</p> <p>ServiceID{DLT_SID_SendTraceMessage} Reentrancy{Reentrant} Synchronicity{Synchronous} Possible development errors:</p> <ul style="list-style-type: none"> ▶ <code>DLT_E_PARAM_POINTER</code> - in case a null pointer was used for <code>log_info</code> or <code>log_data</code> input ▶ <code>DLT_E_WRONG_PARAMETERS</code> - a wrong parameter is used in any case ▶ <code>DLT_E_UNKNOWN_SESSION_ID</code> - <code>session_id</code> is used with a wrong/not registered value ▶ <code>DLT_E_NO_BUFFER</code> - <code>log_data_length</code> value is greater than configured maximum length for log messages 	

5.2.2.3.19. Dlt_ASR43_SetDefaultLogLevel

Purpose	Set default log level.
Synopsis	<pre>Std_ReturnType Dlt_ASR43_SetDefaultLogLevel(Dlt_MessageLogLevelType newLogLevel);</pre>

Parameters (in)	newLogLevel	sets the new filter value
Return Value	Result of changing the log level	
	E_OK:	No error occurred
	E_NOT_OK:	Default LogLevel could not be set
Description	<p>Called to modify the pass through range for Log Messages for all not explicit set ContextIds.</p> <p>ServiceID{DLT_SID_SetDefaultLogLevel} Reentrancy{Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.20. Dlt_ASR43_SetDefaultTraceStatus

Purpose	Set default trace status.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_SetDefault- TraceStatus (boolean newTraceStatus);</pre>	
Parameters (in)	newTraceStatus	enabling/disabling of Trace messages
Return Value	Result of changing the trace status	
	E_OK:	No error occurred
	E_NOT_OK:	Default Trace Status could not be set
Description	<p>Called to enable or disable trace messages for all not explicitly set ContextIds.</p> <p>ServiceID{DLT_SID_SetDefaultTraceStatus} Reentrancy{Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.21. Dlt_ASR43_SetLogChannelAssignment

Purpose	Set log channel assignment.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_SetLogChannelAssignment (con- st Dlt_ApplicationIDType * appId , const Dlt_ContextID- Type * contextId , const Dlt_LogChannelNameType * logChan- nelName , Dlt_AssignmentOperationType addRemoveOp);</pre>	
Parameters (in)	appId	ID of the addressed application / SW-C
	contextId	The context Id for which the log level is set
	logChannelName	Name of the addressed LogChannel

	addRemoveOp	Operation to add/remove the addressed tuple ApplicationId/ContextId to/from the addressed LogChannel
Return Value	Result of changing the log level	
	DLT_CTRL_OK	Changing the log level succeeded
	DLT_CTRL_ERROR	Changing the log level failed
Description	Adds/removes the addressed tuple ApplicationId/ContextId to/from the addressed LogChannel. ServiceID{ DLT_SID_SetLogChannelAssignment } Reentrancy{Non Reentrant} Synchronicity{Synchronous}	

5.2.2.3.22. Dlt_ASR43_SetLogChannelThreshold

Purpose	Set log Channel Threshold.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_SetLogChannelThreshold (const Dlt_LogChannelNameType * logChannelName , Dlt_MessageLogLevelType newThreshold , boolean newTraceStatus);</pre>	
Parameters (in)	logChannelName	Name of the addressed LogChannel
	newThreshold	Threshold for LogMessages
	newTraceStatus	TRUE: enable TraceMessages FALSE: disable TraceMessages
Return Value	Result of changing the log level	
	DLT_CTRL_OK	Changing the log level succeeded
	DLT_CTRL_ERROR	Changing the log level failed
Description	<p>Sets the filter threshold for the given LogChannel.</p> <p>ServiceID{DLT_SID_SetLogChannelThreshold} Reentrancy{Reentrant for different LogChannelNames} Synchronicity{Synchronous}</p>	

5.2.2.3.23. Dlt_ASR43_SetLogLevel

Purpose	Set log level.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_SetLogLevel (const Dlt_ApplicationIDType * appId , const Dlt_ContextIDType * contextId , Dlt_MessageLogLevelType newLogLevel);</pre>	
Parameters (in)	appId	ID of the SW-C

	contextId	ID of the context
	newLogLevel	new log level to set
Return Value	Result of changing the log level	
	E_OK:	No error occurred
	E_NOT_OK:	LogLevel could not be changed
Description	<p>This service is used to change the LogLevel for the given tuple of ApplicationID/ContextID.</p> <p>ServiceID{DLT_SID_SetLogLevel} Reentrancy{Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.24. Dlt_ASR43_SetMessageFiltering

Purpose	Enable / disable message filtering.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_SetMessageFiltering (boolean status);</pre>	
Parameters (in)	status	TRUE: enable message filtering FALSE: disable message filtering
Return Value	Result of changing the message filtering status	
	E_OK:	No error occurred
	E_NOT_OK:	Setting of message filtering failed
Description	<p>Switches on/off the message filtering functionality of the Dlt module.</p> <p>ServiceID{DLT_SID_SetMessageFiltering} Reentrancy{Non Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.25. Dlt_ASR43_SetTraceStatus

Purpose	Set trace status.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_SetTraceStatus (const Dlt_ApplicationIDType * appId , const Dlt_ContextIDType * contextId , boolean newTraceStatus);</pre>	
Parameters (in)	appId	ID of the SW-C
	contextId	ID of the context
	newTraceStatus	New trace status
Return Value	Result of changing the trace status	

	E_OK:	No error occurred
	E_NOT_OK:	Trace status could not be changed
Description	<p>The service Dlt_SetTraceStatus sets the trace status for a specific tuple of ApplicationID and ContextID.</p> <p>ServiceID{DLT_SID_SetTraceStatus} Reentrancy{Non Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.26. Dlt_ASR43_StoreConfiguration

Purpose	Store the general configuration, log level and trace status set for a pair of Application ID and Context ID in NvM blocks.	
Synopsis	<pre>Std_ReturnType Dlt_ASR43_StoreConfiguration (void);</pre>	
Return Value	Result of configuration storage	
	E_OK:	No error occurred
	E_NOT_OK:	The configuration could not be stored
	DLT_E_NOT_SUPPORTED:	Service is not supported
Description	<p>Copies the current Dlt configuration to NvRAM by calling NvM_WriteBlock().</p> <p>ServiceID{DLT_SID_StoreConfiguration} Reentrancy{Non Reentrant} Synchronicity{Synchronous}</p>	

5.2.2.3.27. Dlt_ASR43_UnregisterContext

Purpose	Unregister already logged application/context ids.	
Synopsis	<pre>Dlt_ReturnType Dlt_ASR43_UnregisterContext (Dlt_SessionIDType sessionId , const Dlt_ApplicationIDType * appId , const Dlt_ContextIDType * contextId);</pre>	
Parameters (in)	sessionId	number of the module (Module ID within BSW, port defined argument value within SW-C)
	appId	the Application ID
	contextId	the Context ID
Return Value	Result of unregistering the context	
	DLT_E_CONTEXT_NOT_YET_REG:	The software module context has not registered before.

	DLT_E_UNKNOWN_SESSION_ID:	The provided session id is unknown.
	DLT_E_OK	The required operation succeeded
Description	<p>The service has to be called when a software module wants to use services offered by DLT software component for a specific context.</p> <p>ServiceID{DLT_SID_UnregisterContext} Reentrancy{Reentrant} Synchronicity{Synchronous}</p> <p>Possible development errors DLT_E_NOT_INITIALIZED - Api was called before initializing Dlt module DLT_E_CONTEXT_NOT_YET_REG - context was not registered yet DLT_E_UNKNOWN_SESSION_ID - wrong session id was used</p>	

5.2.2.3.28. Dlt_ComCopyRxData

Purpose	Copy received data from PduR buffer.	
Synopsis	<pre>BufReq_ReturnType Dlt_ComCopyRxData (PduIdType id , const PduInfoType * info , PduLengthType * bufferSizePtr);</pre>	
Service ID	DLT_SID_ComCopyRxData	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (in)	id	Identification of the received I-PDU.
	info	Provides the source buffer (SduDataPtr) and the number of bytes to be copied (SduDataLength). An SduLength of 0 can be used to query the current amount of available buffer in the upper layer module. In this case, the SduDataPtr may be a NULL_PTR.
Parameters (out)	bufferSizePtr	Available receive buffer after data has been copied
Return Value	The success state of Dlt_ComCopyRxData	
	BUFREQ_OK	Data copied successfully
	BUFREQ_E_NOT_OK	Data was not copied because an error occurred.
Description	<p>This function is called to provide the received data of an I-PDU segment (N-PDU) to the upper layer. Each call to this function provides the next part of the I-PDU data. The size of the remaining data is written to the position indicated by bufferSizePtr.</p>	

5.2.2.3.29. Dlt_ComCopyTxData

Purpose	Copy transmit data to PduR buffer.	
Synopsis	<pre>BufReq_ReturnType Dlt_ComCopyTxData (PduId- Type id , PduInfoType * info , RetryInfoType * retry , PduLengthType * availableDataPtr);</pre>	
Parameters (in)	id	Identification of the transmitted I-PDU
	info	Provides the destination buffer (SduDataPtr) and the number of bytes to be copied (SduLength). If not enough transmit data is available, no data is copied by the upper layer module and BUFREQ_E_BUSY is returned. The lower layer module may retry the call. An Sdulength of 0 can be used to indicate state changes in the retry parameter or to query the current amount of available data in the upper layer module. In this case, the SduDataPtr may be a NULL_PTR.
	retry	This parameter is used to acknowledge transmitted data or to retransmit data after transmission problems. If the retry parameter is a NULL_PTR, it indicates that the transmitted data can be removed from the buffer immediately after it has been copied. Otherwise, the retry parameter must point to a valid RetryInfoType element. If TpDataState indicates TP_CONF_PENDING, the previously copied data must remain in the TP buffer to be available for error recovery. TP_DATACONF indicates that all data that has been copied before this call is confirmed and can be removed from the TP buffer. Data copied by this API call is excluded and will be confirmed later. TP_DATARETRY indicates that this API call shall copy previously copied data in order to recover from an error. In this case TxTpDataCnt specifies the offset in bytes from the current data copy position.

Parameters (out)	availableDataPtr	Indicates the remaining number of bytes that are available in the upper layer module's Tx buffer. availableDataPtr can be used by TP modules that support dynamic payload lengths (e.g. FrIso Tp) to determine the size of the following CFs.
Return Value	The success state of Dlt_ComCopyTxData	
	BUFREQ_OK	Data has been copied to the transmit buffer completely as requested.
	BUFREQ_E_BUSY	Request could not be fulfilled, because the required amount of Tx data is not available. The lower layer module may retry this call later on. No data has been copied.
	BUFREQ_E_NOT_OK	Data has not been copied. Request failed.
Description	This function is called to acquire the transmit data of an I-PDU segment (N-PDU). Each call to this function provides the next part of the I-PDU data unless retry->Tp-DataState is TP_DATARETRY. In this case, the function restarts to copy the data beginning at the offset from the current position indicated by retry->TxTpDataCnt. The size of the remaining data is written to the position indicated by availableDataPtr.	

5.2.2.3.30. Dlt_ComRxIndication

Purpose	
Synopsis	<pre>void Dlt_ComRxIndication (PduIdType Dlt- tRxPduId , NotifResultType Result);</pre>

5.2.2.3.31. Dlt_ComStartOfReception

Purpose	Trigger the reception of a message.	
Synopsis	<pre>BufReq_ReturnType Dlt_ComStartOfReception (PduIdType id , PduLengthType TpSduLength , PduLengthType * bufferSizePtr);</pre>	
Service ID	DLT_SID_ComStartOfReception	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (in)	id	Identification of the I-PDU.

	<code>TpSduLength</code>	Total length of the N-SDU to be received.
Parameters (out)	<code>bufferSizePtr</code>	Available receive buffer in the receiving module. This parameter will be used to compute the Block Size (BS) in the transport protocol module.
Return Value	The success state of <code>Dlt_ComStartofReception</code>	
	<code>BUFREQ_OK</code>	Connection has been accepted. <code>bufferSizePtr</code> indicates the available receive buffer; reception is continued. If no buffer of the requested size is available, a receive buffer size 0 shall be indicated by <code>bufferSizePtr</code> .
	<code>BUFREQ_E_NOT_OK</code>	Connection has been rejected; reception is aborted. <code>bufferSizePtr</code> remains unchanged.
	<code>BUFREQ_E_OVFL</code>	No buffer of the required length can be provided; reception is aborted. <code>bufferSizePtr</code> remains unchanged.
Description	This function is called at the start of receiving an N-SDU. The N-SDU might be fragmented into multiple N-PDUs (FF with one or more following CFs) or might consist of a single N-PDU (SF).	

5.2.2.3.32. `Dlt_ComTxConfirmation`

Purpose	
Synopsis	<pre>void Dlt_ComTxConfirmation (PduIdType DltTxPduId , NotifResultType Result);</pre>

5.2.2.3.33. `Dlt_GetComInterfaceMaxBandwidth`

Purpose	Get maximum bandwidth for the communication interface.
Synopsis	<pre>uint32 Dlt_GetComInterfaceMaxBandwidth (void);</pre>
Service ID	DLT_SID_GetComInterfaceMaxBandwidth
Sync/Async	Synchronous
Reentrancy	Non Reentrant

Return Value	The current maximum bandwidth in bits / second
Description	This function returns the maximum bandwidth available for the Dlt on the communication interface. If the Dlt module is not initialized, no messages will be sent (only stored in the internal buffer), thus this function will return 0 in this case.

5.2.2.3.34. Dlt_GetGlobalLogging

Purpose	Get global message logging status.	
Synopsis	<code>Dlt_GlobalLogStatusType Dlt_GetGlobalLogging (void);</code>	
Service ID	DLT_SID_GetGlobalLogging	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Return Value	Current message logging status	
	DLT_LOGGING_ENABLED	Message logging is enabled
	DLT_LOGGING_DISABLED	Message logging is disabled
Description	This function retrieves the current message logging status.	

5.2.2.3.35. Dlt_GetLogInfoInternal

Purpose	Get log info internal.	
Synopsis	<code>Std_ReturnType Dlt_GetLogInfoInternal (Dlt_SessionIDType SessionID , uint8 options , Dlt_Internal_ApplicationIDType AppID , Dlt_Internal_ContextIDType ContextID , uint8 * status , uint8 * logInfo);</code>	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	SessionID	Used to distinguish identical tuples
	options	Used to filter the response in respect to the ApplicationId, ContextId and Trace Status information
	AppID	Representation of the ApplicationId
	ContextID	Representation of the ContextId
	status	
Parameters (out)		

	logInfo	Details about the returned Application IDs
Return Value	Result of retrieving the log info	
	E_OK	No error occurred
	E_NOT_OK	LogInfo could not be returned
Description	Called to request information about registered ApplicationIds, providing support to Dlt_GetLogInfo by extending the API with a session ID parameter where available.	

5.2.2.3.36. Dlt_GetLogLevel

Purpose	Get log level.	
Synopsis	<pre>Dlt_CtrlReturnTypes Dlt_GetLogLevel (const Dlt_ApplicationIDType * AppId , const Dlt_ContextIDType * ContextId , Dlt_MessageLogLevelType * LogLevel);</pre>	
Service ID	DLT_SID_GetLogLevel	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	AppId	The application Id for which the log level shall be retrieved
	ContextId	The context Id for which the log level shall be retrieved
Parameters (out)	LogLevel	Log level setting for the given application and context Ids
Return Value	Result of retrieving the log level	
	DLT_CTRL_OK	Retrieving the log level succeeded
	DLT_CTRL_ERROR	Retrieving the log level failed
Description	This service returns the maximum level a log message may have to be accepted by the Dlt module.	

5.2.2.3.37. Dlt_GetMessageFilteringStatus

Purpose	Get message filtering status.	
Synopsis	<pre>Dlt_FilterMessagesType Dlt_GetMessageFilteringStatus (void);</pre>	
Service ID	DLT_SID_GetMessageFilteringStatus	

Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Return Value	Current message filtering status	
	DLT_FILTER_MESSAGES_ON	Message filtering is enabled
	DLT_FILTER_MESSAGES_OFF	Message filtering is disabled
Description	This function retrieves the current message filtering status.	

5.2.2.3.38. Dlt_GetUseECUID

Purpose	Get EcuID header field status.	
Synopsis	<code>Dlt_CtrlReturnType Dlt_GetUseECUID (void);</code>	
Service ID	DLT_SID_GetUseECUID	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Return Value	Current EcuID header field status	
	1	EcuID is included in the Dlt message header
	0	EcuID is not included in the Dlt message header
	2	Call to the API to retrieve EcuID usage failed
Description	This function returns whether the EcuID is included in the Dlt message header (Used to get status of DltHeaderUseEculd).	

5.2.2.3.39. Dlt_GetUseExtendedHeader

Purpose	Get extended header use status.	
Synopsis	<code>Dlt_CtrlReturnType Dlt_GetUseExtendedHeader (void);</code>	
Service ID	DLT_SID_GetUseExtendedHeader	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Return Value	Current Dlt header format status	

	1	Extended Dlt message headers are used
	0	Standard Dlt message headers are used
	2	Call to API failed to retrieve status of extended header usage.
Description	This function returns whether extended Dlt message headers are used.	

5.2.2.3.40. Dlt_GetUseSessionID

Purpose	Get SessionID header field status.	
Synopsis	<code>Dlt_CtrlReturnType Dlt_GetUseSessionID (void);</code>	
Service ID	DLT_SID_GetUseSessionID	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Return Value	Current SessionID header field status	
	1	SessionID is included in the Dlt message header
	0	SessionID is not included in the Dlt message header
	2	Call to the API to retrieve SessionID usage failed
Description	This function returns whether the SessionID is included in the Dlt message header.	

5.2.2.3.41. Dlt_GetVerboseModeStatus

Purpose	Get verbose mode status.	
Synopsis	<code>Dlt_CtrlReturnType Dlt_GetVerboseModeStatus (const Dlt_ApplicationIDType * AppId , const Dlt_ContextIDType * ContextId , Dlt_MessageLogLevelType * ModeStatus);</code>	
Service ID	DLT_SID_GetVerboseModeStatus	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	AppId	The application Id for which the verbose mode is set

	ContextId	The context Id for which the verbose mode is set
Parameters (out)	ModeStatus	Mode setting for the given application and context Ids
Return Value	Result of retrieving the mode	
	DLT_CTRL_OK	Retrieving the mode succeeded
	DLT_CTRL_ERROR	Retrieving the mode failed
Description	This function returns whether the verbose mode is ON or OFF for a given application and context Id pair	

5.2.2.3.42. Dlt_GetVersionInfo

Purpose	This service returns the version information of this module.	
Synopsis	<pre>void Dlt_GetVersionInfo (Std_VersionInfoType * versioninfo);</pre>	
Service ID	DLT_SID_GetVersionInfo	
Sync/Async	Synchronous	
Reentrancy	Reentrant	
Parameters (out)	versioninfo	Pointer to where to store the version information of this module.
Description	<p>The version information includes:</p> <ul style="list-style-type: none"> ▶ Module Id ▶ Vendor Id ▶ Vendor specific version numbers (BSW00407). <p>This function shall be pre-compile time configurable On/Off by the configuration parameter: DLT_VERSION_INFO_API</p>	

5.2.2.3.43. Dlt_Init

Purpose	This service initializes the Dlt module.	
Synopsis	<pre>void Dlt_Init (const Dlt_ConfigType * config);</pre>	
Service ID	DLT_SID_Init	
Sync/Async	Synchronous	

Reentrancy	Non Reentrant	
Parameters (in)	config	Pointer to a DLT configuration structure
Description	Dlt is using the NVRamManager and is to be initialized very late in the ECU startup phase. The Dlt_init() function should be called after the NVRamManager is initialized.	

5.2.2.3.44. Dlt_MainFunction

Purpose	Periodically trigger message transmission.	
Synopsis	<pre>void Dlt_MainFunction (void);</pre>	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Description	This function periodically triggers the transmission of Dlt frames to the PduR. The function also performs bandwidth management tasks.	

5.2.2.3.45. Dlt_NvMInitDataSetBlockCbK

Purpose	Callback-Function from NvM that will be called if no ROM data is available for initialization of the NVRAM block.	
Synopsis	<pre>Std_ReturnType Dlt_NvMInitDataSetBlockCbK (void);</pre>	
Sync/Async	Synchronous	
Reentrancy	Non reentrant	
Return Value	returns E_OK	

5.2.2.3.46. Dlt_NvMInitNativeBlockCbK

Purpose	Callback-Function from NvM that will be called if no ROM data is available for initialization of the NVRAM block.	
Synopsis	<pre>Std_ReturnType Dlt_NvMInitNativeBlockCbK (void);</pre>	
Sync/Async	Synchronous	
Reentrancy	Non reentrant	
Return Value	returns E_OK	

5.2.2.3.47. Dlt_NvMReadRamBlockFromNvMDataSetCbk

Purpose	Callback function from NvM for data set block to request the data to be copied from NvM RAM during NvM_ReadBlock().	
Synopsis	<pre>Std_ReturnType Dlt_NvMReadRamBlockFrom- NvMDataSetCbk (void * NvMBuffer);</pre>	
Service ID	DLT_SID_InternalReadFromDataSetApild	
Sync/Async	Synchronous	
Reentrancy	Non reentrant	
Parameters (in)	NvMBuffer	Pointer to NvM RAM mirror
Return Value	always E_OK	
Description	<p>This callback function shall copy information stored in the data set NvM block (the values of log level and trace status explicitly set by a pair of ApplicationID and ContextID registered via Dlt_RegisterContext) to the Dlt RAM.</p> <p>The approach used in this case is to copy the information one by one thus not using TS_MemCpy and more resources shall be saved, because only data is copied directly from NvM buffer to Dlt runtime variables without using additional buffers in Dlt.</p>	

5.2.2.3.48. Dlt_NvMReadRamBlockFromNvMNativeCbk

Purpose	Callback function from NvM for native data block to request the data to be copied from the NvM RAM during NvM_ReadBlock().	
Synopsis	<pre>Std_ReturnType Dlt_NvMReadRamBlock- FromNvMNativeCbk (void * NvMBuffer);</pre>	
Service ID	DLT_SID_InternalReadFromNativeApild	
Sync/Async	Synchronous	
Reentrancy	Non reentrant	
Parameters (in)	NvMBuffer	Pointer to NvM RAM mirror
Return Value	always E_OK	
Description	<p>This callback function shall copy information stored in the native NvM block (runtime configurable variables) to the Dlt RAM.</p> <p>The approach used in this case is to copy the information one by one thus not using TS_MemCpy and more resources shall be saved, because only data is copied directly from NvM buffer to Dlt runtime variables without using additional buffers in Dlt.</p>	

5.2.2.3.49. Dlt_NvMSingleBlockCallbackDataSet

Purpose	Callback-Function from NvM for data set block information notifying successful completion of single block request.	
Synopsis	<pre>Std_ReturnType Dlt_NvMSingleBlockCallbackDataSet (uint8 ServiceId , NvM_RequestResultType JobResult);</pre>	
Service ID	DLT_SID_SingleBlockCallbackDataSet	
Sync/Async	Synchronous	
Reentrancy	Non reentrant	
Parameters (in)	ServiceId	
	JobResult	
Return Value	returns always E_OK	

5.2.2.3.50. Dlt_NvMSingleBlockCallbackNative

Purpose	Callback-Function from NvM for general data data set block notifying successful completion of single block request.	
Synopsis	<pre>Std_ReturnType Dlt_NvMSingleBlockCallbackNative (uint8 ServiceId , NvM_RequestResultType JobResult);</pre>	
Service ID	DLT_SID_NvMSingleBlockCallbackNative	
Sync/Async	Synchronous	
Reentrancy	Non reentrant	
Parameters (in)	ServiceId	
	JobResult	
Return Value	returns always E_OK	

5.2.2.3.51. Dlt_NvMWriteRamBlockToNvMDataSetCbk

Purpose	Callback function from NvM for data set block to request the data to be copied from Dlt module's RAM into non-volatile RAM during NvM_WriteBlock().	
Synopsis	<pre>Std_ReturnType Dlt_NvMWriteRamBlock- ToNvMDataSetCbk (void * NvMBuffer);</pre>	
Service ID	DLT_SID_InternalWriteToDataSetApild	
Sync/Async	Synchronous	
Reentrancy	Non reentrant	

Parameters (in)	NvMBuffer	Pointer to NvM RAM mirror
Return Value	always E_OK	
Description	<p>This callback function shall copy information stored in Dlt module's RAM (the values of log level and trace status explicitly set by an external client for a pair of ApplicationID and ContextID registered via Dlt_RegisterContext)</p> <p>The approach used in this case is to copy the information one by one and not using TS_MemCpy thus more resources shall be saved, because no auxiliary buffer is used to store the data to be copied.</p>	

5.2.2.3.52. Dlt_NvMWriteRamBlockToNvMNativeCbk

Purpose	Callback function from NvM for native data block to request data to be copied into NvM RAM during NvM_WriteBlock().	
Synopsis	<pre>Std_ReturnType Dlt_NvMWriteRamBlock- ToNvMNativeCbk (void * NvMBuffer);</pre>	
Service ID	DLT_SID_InternalWriteToNativeApild	
Sync/Async	Synchronous	
Reentrancy	Non reentrant	
Parameters (in)	NvMBuffer	Pointer to NvM RAM mirror
Return Value	always E_OK	
Description	<p>This callback function shall copy information (the runtime configurable variables) from Dlt module's RAM in the native NvM block.</p> <p>The approach used it this case is to copy the information one by one and not using TS_MemCpy thus resources are saved, because no auxiliary buffer is used.</p>	

5.2.2.3.53. Dlt_SetComInterfaceMaxBandwidth

Purpose	Set the maximum bandwidth for the communication interface.	
Synopsis	<pre>Dlt_CtrlReturnTypes Dlt_SetComInterface- MaxBandwidth (uint32 max_bandwidth);</pre>	
Service ID	DLT_SID_SetComInterfaceMaxBandwidth	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	

Parameters (in)	max_bandwidth	The maximum bandwidth in bits / second This must be a multiple of 8.
Return Value	Result of changing the maximum bandwidth	
	DLT_CTRL_OK	Changing the maximum bandwidth succeeded
	DLT_CTRL_ERROR	Changing the maximum bandwidth failed
Description	This function sets the maximum allowed bandwidth available for the Dlt on the communication interface. If this bandwidth is exceeded, the Dlt will stop transmitting messages until the bandwidth is balanced again.	

5.2.2.3.54. Dlt_SetGlobalLogging

Purpose	Globally enable / disable message logging.	
Synopsis	<pre>Dlt_CtrlReturnType Dlt_SetGlobalLogging (Dlt_GlobalLogStatusType logStatus);</pre>	
Service ID	DLT_SID_SetGlobalLogging	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	logStatus	New status of message logging (DLT_LOGGING_ENABLED: enable message logging, DLT_LOGGING_DISABLED: disable message logging)
Return Value	Result of changing the message logging status	
	DLT_CTRL_OK	Changing the message logging status succeeded
	DLT_CTRL_ERROR	Changing the message logging status failed
Description	This function enables and disables message logging. If message logging is disabled all messages are discarded by the Dlt, independently from the log level or trace status settings.	

5.2.2.3.55. Dlt_SetUseECUID

Purpose	Enable / disable the transmission of the EcuID in message header.
----------------	---

Synopsis	<code>Dlt_CtrlReturnType Dlt_SetUseECUID (uint8 NewStatus);</code>	
Service ID	DLT_SID_SetUseECUID	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	NewStatus	New status of including the EcuID (1: include the EcuID (ON), 0: do not include the EcuID (OFF))
Return Value	Result of changing the status	
	DLT_CTRL_OK	Changing the status succeeded.
	DLT_CTRL_ERROR	Changing the status failed.
Description	This function enables and disables the inclusion of the EcuID in the Dlt message header (the ECUID is attached in the Standard Header).	

5.2.2.3.56. Dlt_SetUseExtendedHeader

Purpose	Enable / disable use of an extended message header.	
Synopsis	<code>Dlt_CtrlReturnType Dlt_SetUseExtendedHeader (uint8 NewStatus);</code>	
Service ID	DLT_SID_SetUseExtendedHeader	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	NewStatus	New status of using extended header (1: use extended header (ON), 0: use standard header (OFF))
Return Value	Result of changing the status	
	DLT_CTRL_OK	Changing the status succeeded
	DLT_CTRL_ERROR	Changing the status failed
Description	This function enables and disables the use of an extended Dlt message header.	

5.2.2.3.57. Dlt_SetUseSessionID

Purpose	Enable / disable SessionID in message header.
----------------	---

Synopsis	<code>Dlt_CtrlReturnType Dlt_SetUseSessionID (uint8 NewStatus);</code>	
Service ID	DLT_SID_SetUseSessionID	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	NewStatus	New status of including the SessionID (1: include the SessionID (ON), 0: do not include the SessionID (OFF))
Return Value	Result of changing the status	
	DLT_CTRL_OK	Changing the status succeeded
	DLT_CTRL_ERROR	Changing the status failed
Description	This function enables and disables the inclusion of the SessionID in the Dlt message header.	

5.2.2.3.58. Dlt_SetVerboseMode

Purpose	Switch to Verbose Mode.	
Synopsis	<code>Dlt_CtrlReturnType Dlt_SetVerboseMode (const Dlt_ApplicationIDType * AppId , const Dlt_ContextIDType * ContextId , Dlt_MessageLogLevelType NewStatus);</code>	
Service ID	DLT_SID_SetVerboseMode	
Sync/Async	Synchronous	
Reentrancy	Non Reentrant	
Parameters (in)	AppId	The application Id for which the verbose mode is set
	ContextId	The context Id for which the verbose mode is set
	NewStatus	New status of verbose mode (1: enable verbose mode (ON), 0: disable verbose mode (OFF))
Return Value	Result of changing the status	
	DLT_CTRL_OK	Changing the status succeeded
	DLT_NOT_SUPPORTED	Verbose mode is not implemented
	DLT_CTRL_ERROR	Changing the status failed
Description	This function switches verbose mode	

5.2.3. Integration notes

5.2.3.1. Exclusive areas

This section describes the exclusive areas used by the `Dlt` module.

5.2.3.1.1. SCHM_DLT_EXCLUSIVE_AREA_MASTER

Protected data structures	All shared data that shall be protected from mutual access.
Recommended locking mechanism	This exclusive area must always be protected by a locking mechanism. The options for locking are described in the <code>EB tresos AutoCore Generic</code> documentation. Refer to the section <code>Mapping exclusive areas in the basic software modules</code> in the <code>Integration notes</code> section for details.

5.2.3.1.2. SCHM_DLT_EXCLUSIVE_AREA_SlaveIndex

Protected data structures	All shared data that shall be protected from mutual access by the exclusive areas defined for it. Each core will have an internal behavior.
Recommended locking mechanism	This exclusive area must always be protected by a locking mechanism. The options for locking are described in the <code>EB tresos AutoCore Generic</code> documentation. Refer to the section <code>Mapping exclusive areas in the basic software modules</code> in the <code>Integration notes</code> section for details.

5.2.3.2. Production errors

Production errors are not reported by the `Dlt` module.

5.2.3.3. Memory mapping

General information about memory mapping is provided in the `EB tresos AutoCore Generic` documentation. Refer to the section `Memory mapping and compiler abstraction` in the `Integration notes` section for details.

The following table provides the list of sections that may be mapped for this module:

Memory section
VAR_INIT_8
VAR_INIT_16
MC_SHARED_VAR_INIT_8
VAR_INIT_32
VAR_INIT_UNSPECIFIED
VAR_CLEARED_8
VAR_CLEARED_16
VAR_CLEARED_32
VAR_CLEARED_UNSPECIFIED
MC_SHARED_VAR_CLEARED_UNSPECIFIED
CONST_8
CONST_16
CONST_32
CONST_UNSPECIFIED
VAR_UNSPECIFIED
CODE
APPL_CODE

5.2.3.4. Integration requirements

WARNING



Integration requirements list is not exhaustive

The following list of integration requirements helps you to integrate your product. However, this list is not exhaustive. You also require information from the user's guide, release notes, and EB tresos AutoCore known issues to successfully integrate your product.

5.2.3.4.1. intgr.Dlt.PDAV

Description	To integrate the DLT module with a Software Component(SW-C), the right ports needs to be defined for the SW-C. The SW-C description shall be built as follows: For each group of ports which belong to one SessionID and shall be handled with one PortDefinedArgumentValue by the Dlt service:
--------------------	---

	<ul style="list-style-type: none"> - For each used SessionID create one SwcServiceDependency as part of the SwcInternalBehavior. - Add the DltUserNeeds to this SwcServiceDependency. - For each included Port add one RoleBasedPortAssignment with a reference to the PortPrototype. - The role of RoleBasedPortAssignment can be left empty. - Create a new PortAPIOption with the value of the SessionID as PortDefinedArgumentValue. - Attach to RoleBasedPortAssignment all PortPrototype elements which shall belong to this SessionID. <p>To create the port defined argument values for DLT, the Tresos plugin DltAsExt is required. The Create Dlt Port Defined Argument Values unattended wizard creates the required ports, based on the SW-C description.</p>
Rationale	The DLT SWS specifies this method to create the port defined arguments values. The DLT module does not know all components from the module configuration that send log messages. The DLT software component description is updated by the Create Dlt Port Defined Argument Values unattended wizard directly in the the Tresos database when the complete project configuration is loaded.

5.2.3.4.2. integr.Dlt.NvMBlockLength

Description	If the NvM blocks are created via Calculate Service Needs Unattended Wizard, the NvMNvBlockLength should be adjusted to the correct size based on the information from the DLT user's guide.
--------------------	--

5.2.3.4.3. integr.Dlt.UniqueApplIdContextId

Description	ApplId/ContextId registration cannot differ only by SessionId. If an ApplId/ContextId tuple is registered from a SW-C with a sessionId, it cannot be registered from another or same SW-C with different sessionId.
Rationale	To have more optimal data handling, the current internal data structures do not offer this flexibility.

5.2.3.4.4. integr.Dlt.TrafficShaping.MinimumThroughput

Description	The minimum limit for traffic shaping is 1kByte/sec.
--------------------	--

Rationale	The configuration parameter DltBandwidthForComModule expects the value in kbit/sec, but in the current implementation, the calculation is based on bytes.
------------------	---

5.2.3.4.5. integr.Dlt.Multicore.CoreInitialization

Description	When basic software distribution support is enabled for Dlt, in order to ensure a consistent initialization state for both Dlt master and Dlt satellite cores, the following initialization sequence must be ensured during the start-up phase of the project: 1. Initialize all Dlt satellite cores 2. Initialize Dlt master core.
Rationale	This sequence is necessary in order to protect the project of inconsistent data storage in the system and invalid run-time data exchange between the cores.

5.2.3.4.6. integr.Dlt.Multicore.Limits

Description	In case of multi-core configuration, the maximum number of possible contexts registered is limited to 4095 and the maximum message length is limited to 8188. These values depend on the architecture on which the stack is configured.
Rationale	When multi-core is enabled, IOC communication is involved between the cores. The above mentioned limits were introduced as a result of the limitations of the IOC communication channel.

5.2.3.4.7. integr.Dlt.Multicore.APIRestriction

Description	In case of multi-core configuration, the control APIs can only be called from the master context. If the control functions are called from the slave context, a negative return value is reported.
Rationale	Run-time variables are only stored in the master core. The data is not replicated on slave cores.

5.2.3.4.8. integr.Dlt.Multicore.CallingContext.MasterCoreOnly

Description	If the Dlt BSW distribution functionality is enabled, the following Dlt APIs should always be called only in the context of a Dlt master instance: - Dlt_ComCopyTxData() - Dlt_ComTxConfirmation() - Dlt_ComCopyRxData() - Dlt_ComRxIndication() - Dlt_
--------------------	---

	<p>MainFunction() - Dlt_IssueWriteRequestToNvM() - Dlt_ComStartOfReception() NvM callbacks: - Dlt_NvMWriteRamBlockToNvMDataSetCbk() - Dlt_NvMWriteRamBlockToNvMNativeCbk() - Dlt_NvMInitDataSetBlockCbk() - Dlt_NvMInitNativeBlockCbk() - Dlt_NvMReadRamBlockFromNvMDataSetCbk() - Dlt_NvMReadRamBlockFromNvMNativeCbk() - Dlt_NvMSingleBlockCallbackDataSet() - Dlt_NvMSingleBlockCallbackNative() Also, the Dlt events which are triggering the following Runnable Entities should be mapped to an Os task which belongs to the same Os core identifier as the Dlt master instance: - Dlt_SetLogLevelRunnableEntity() - Dlt_SetTraceStatusRunnableEntity() - Dlt_SetVerboseModeRunnableEntity()</p>
Rationale	Communication is always processed in the context of the master Dlt instance.

5.2.3.4.9. integr.Dlt.ParameterDescription

Description	In Autosar 4.2 or older version Dlt_RegisterContext() API will not use the input parameters app_description, len_app_description, context_description, len_context_description.
Rationale	To reduce the size of memory footprint, app_description and context_description is ignored in the current implementation.

5.2.3.4.10. integr.Dlt.TaskMapping.LogTraceStatusChangedNotification

Description	In case of multi-core configuration, Rte_Task and Dlt_MainFunction need to be mapped to same core.
Rationale	Dlt_ASR42_SetLogLevel and Dlt_ASR42_SetTraceStatus functions are writing the global variable ContextIdTable.Flags. The same variable is read from Dlt_SetLogLevelRunnableEntity and Dlt_SetTraceStatusRunnableEntity.

5.2.3.4.11. integr.Dlt.SingleTuple.LogChannelTotalNumberLimitation

Description	If only one AppId/ContextId tuple is present in the configuration (DltServiceAPI = AUTOSAR_431), the maximum number of configured log channels cannot exceed 131.
Rationale	The internal handling of the control messages limits the total number of configurable log channels. If the GetLogChannelNames command is sent to the Dlt and only one tuple is present in the configuration, the Dlt will correctly respond with the total number of configured log channels but will not respond with the log channel names beyond 131.

5.2.3.4.12. `intgr.Dlt.Multicore.ContextRegistration`

Description	When basic software distribution support is enabled for Dlt, the exact same context shall not be registered from two different cores.
Rationale	There is no conceivable use case where the exact same context should be registered from two distinct cores which would warrant supporting this feature. Registering the context on two cores succeeds because the cores do not check the masters table before registering, but do send an update to the master afterwards which will fail due to the context being already registered. The second core will have the context registered but no other core will have any knowledge about it and hence, unpredictable behaviour may arise.

5.2.3.4.13. `intgr.Dlt.RtePrototypes.ArrayBaseType`

Description	The definition of the <code>RTE_PTR2ARRAYTYPE_PASSING</code> macro is necessary before Rte-generated header files (<code>Rte_Dlt.h</code>) are included into the project.
Rationale	The Rte provides this macro in order to enforce the usage of the array type instead of the array base type for arrays passed to functions. This maintains consistency with the AUTOSAR specifications (for operations like <code>SetLogChannelAssignment</code>).

5.2.3.4.14. `intgr.Dlt.Multicore.ContextUnregister`

Description	When <code>DltServiceAPI</code> parameter is set to <code>AUTOSAR_431</code> and basic software distribution support is enabled for Dlt, the unregister of a context shall be done on the same core on which it was registered.
Rationale	Information about the tuples registered is kept locally, on every core, with the tuples that are registered on that core. If the unregister API is called from a different core, the tuple will not be found in the local tables.