

ESP32 Wiring Connections

Motor Driver Connections

- 1 GPIO 14 → Left Motor PWM (ENA)
- 2 GPIO 22 → Left Motor Direction (IN1)
- 3 GPIO 13 → Right Motor PWM (ENB)
- 4 GPIO 23 → Right Motor Direction (IN2)
- 5 GND → Motor Driver GND (Common Ground)
- 6 Motor power must be from an external supply

Encoder Connections

- 1 Channel A → GPIO 25
- 2 Channel B → GPIO 26
- 3 VCC → 3.3V
- 4 GND → GND
- 5 Internal pull-ups enabled
- 6 Full quadrature decoding used

Power & Safety Notes

- 1 ESP32 powered via USB / 5V
- 2 Motor driver powered by external battery
- 3 Common ground is mandatory
- 4 Do not power motors from ESP32
- 5 Use shielded encoder wires if noisy