

This page is also available in **2 other languages** [Change language](#)

## LANGUAGE

### FUNCTIONS

#### VARIABLES

#### STRUCTURE

#### LIBRARIES


#### IOT CLOUD API

#### GLOSSARY

The Arduino Reference text is licensed under a [Creative Commons Attribution-Share Alike 3.0 License](#).

Find anything that can be improved? [Suggest corrections and new documentation via GitHub](#).

Doubts on how to use Github? Learn everything you need to know in [this tutorial](#).



Last Revision: 2019/02/21

Last Build: 2021/10/13

[EDIT THIS PAGE](#)

[Reference](#) > [Language](#) > [Functions](#) > [Communication](#) > [Serial](#) > [End](#)

# Serial.end()

## Description

Disables serial communication, allowing the RX and TX pins to be used for general input and output. To re-enable serial communication, call [Serial.begin\(\)](#).

## Syntax

`Serial.end()`

## Parameters

*Serial*: serial port object. See the list of available serial ports for each board on the [Serial main page](#).

## Returns

Nothing

[Help](#)

PROFESSIONAL

EDUCATION

STORE

Search on Arduino.cc

p

HARDWARE

SOFTWARE

CLOUD

DOCUMENTATION

COMMUNITY

BLOG

ABOUT

CONTACT US

Distributors

Careers

Enter your email to sign up

ic

Help