

Scottsdale Building Systems

SmartCard Swap Software

Ensure your SmartCard reader and a valid SmartCard is inserted in the appropriate reader slot on your laptop PC

The following screen will appear when the program is loaded:

SBS Steel Card Administration

Source card

Card ID

Original

Updated

Scottsdale Steel Card

Transfer

Destination card

Card ID

Original

Updated

Read source card

Remove from Source

Transfer to destination

STEP 1 - Click here once card is fully inserted

SBS Steel Card Administration

Source card

Card ID

Original

Updated

Scottsdale Steel Card

Transfer

Destination card

Card ID

Original

Updated

Read source card

Remove from Source

Transfer to destination

This will show the master card ID and the number of metres left on it

STEP 2 - enter metres to be transferred here, then click on **Remove from Source**

SBS Steel Card Administration

Source card

Card ID

Original

Updated

Scottsdale Steel Card

Cardswap

Remove Source and insert destination card

OK

Destination card

Card ID

Original

Updated

Read source card

Remove from Source

Transfer to destination

STEP 3

click here, you will get the above message, put the destination card in and click on OK the metres will be transferred to the destination card

Please note: This software is confidential and may not be copied onto more than one PC. By loading this software onto a computer you agree to these terms and conditions. Failure to observe these terms is in violation of this agreement and may result in prosecution.