

## EMERGENCY – MINOR LEAKAGE

1. Open valve **V107**

2. Close valve **V101** (behind the pump)

3. Turn off pressure regulator **V108** (clockwise!)

