



Installing and Licensing MPLAB[®] XC C Compilers

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

Trademarks

The Microchip name and logo, the Microchip logo, dsPIC, FlashFlex, flexPWR, JukeBlox, KEELOQ, KEELOQ logo, Klear, LANCheck, MediaLB, MOST, MOST logo, MPLAB, OptoLyzer, PIC, PICSTART, PIC³² logo, RightTouch, SpyNIC, SST, SST Logo, SuperFlash and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

The Embedded Control Solutions Company and mTouch are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, BodyCom, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, ECAN, In-Circuit Serial Programming, ICSP, Inter-Chip Connectivity, KlearNet, KlearNet logo, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, RightTouch logo, REAL ICE, SQI, Serial Quad I/O, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademarks of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2012-2015, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-63276-936-7

QUALITY MANAGEMENT SYSTEM
CERTIFIED BY DNV
= ISO/TS 16949 =

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

Table of Contents

Chapter 1. About the Installer and License Manager

1.1 MPLAB XC C Compilers	5
1.2 XC Installer	5

Chapter 2. Installing Your Compiler

2.1 Install a Compiler on a Local Computer	8
2.2 Install a Network Client	9
2.2.1 Network Server/Client Overview	9
2.2.2 Install a Compiler and Connect to the Network Configuration (Client)	10
2.3 Installation Flow	11
2.4 Upgrading the Compiler	20
2.5 Uninstalling the Compiler	20

Chapter 3. Licensing Your Compiler

3.1 Purchasing a License	21
3.2 Acquiring an Evaluation License	21
3.3 Activating a License	22

Index	23
--------------------	-----------

Worldwide Sales and Service	24
--	-----------

XC Installer & License Manager

NOTES:

Chapter 1. About the Installer and License Manager

This chapter introduces the installers and license managers used in conjunction with MPLAB® XC C Compilers. The next chapter discusses how to install your MPLAB XC C Compiler.

- MPLAB XC C Compilers
- XC Installer

1.1 MPLAB XC C COMPILERS

Please see the Microchip website (<http://www.microchip.com/mplabxc>) for more information about available MPLAB XC C compilers and related device support. Each compiler license gives you increased levels of code optimization.

1.2 XC INSTALLER

The GUI installer will install a compiler on your PC or network license server. After the installation, you can license the compiler for use.

Windows 8 Customers - Troubleshooting

If you have trouble running the installer, you can try running in Windows 7 Compatibility mode. To set this mode:

1. Right click on the installer executable.
2. In the File Properties window, click on the Compatibility tab.
3. Under “Compatibility mode”, check the “Run the program in compatibility mode for” box and select “Windows 7”.

XC Installer & License Manager

NOTES:

Chapter 2. Installing Your Compiler

When you install an MPLAB XC C compiler, you are installing an unlicensed compiler. This means that you are running under a FREE license and you have access to the minimum amount of code optimization and support. For greater optimization and support, jump to the licensing sites that are listed near the end of the installation. Acquire a regular or evaluation license, and activate the license.

The following topics describe compiler installation procedures:

- Install a Compiler on a Local Computer
- Install a Network Client
 - Network Server/Client Overview
 - Install a Compiler and Connect to the Network Configuration (Client)
- Installation Flow
- Upgrading the Compiler
- Uninstalling the Compiler

XC Installer & License Manager

2.1 INSTALL A COMPILER ON A LOCAL COMPUTER

The following instructions will guide you through the installation of a compiler for a single user.

When the compiler is installed, you can proceed to get a license. The license can be used for compiler installations on up to three (3) workstations.

Welcome and License Agreement


From the Welcome screen, click **Next** to continue.

Read the license agreement and accept the agreement to proceed. When you accept, **Next** becomes available. Click it to continue.

Installation Type

Do not select anything. Click **Next** to continue.

FIGURE 2-1: INSTALLATION TYPE SCREEN



Continue Installation

To continue installing an MPLAB XC C Compiler, go to the [Installation Directory](#) screen under **Section 2.3 "Installation Flow"**.

2.2 INSTALL A NETWORK CLIENT

The installation of a network client is covered in this document. For details on installing a network server, see the *MPLAB XC Network License Server* document.

2.2.1 Network Server/Client Overview


You may use a computer network to set up a license server and client(s). To do this, use one computer to host the license server and license files. Then, other network computers can contain compilers and license managers that are configured to acquire licenses from the license server.

To install the license server, install the network license and start the server, see the *MPLAB XC Network License Server* document.

To install a license client, follow the steps in the next section. This installation process will ask for details about the network license server. The operating system for the client does not have to be the same one used for the server, but it must be supported.

Once configured, compiler executions on the network license client will connect to the network license server to check out a license. This license will be available for immediate use. However, when the compiler is exited, there is a 60-minute delay before that server license can be used by other clients.

FIGURE 2-2: NETWORK LICENSE CLIENT/SERVER MODEL



2.2.2 Install a Compiler and Connect to the Network Configuration (Client)

When the compiler runs on the network license client, the license manager will check out licenses from the network license server. This section summarizes how the network client compiler is installed.

Welcome and License Agreement

From the Welcome screen, click **Next** to continue.

Read the license agreement and accept the agreement to proceed. When you accept, **Next** becomes available. Click it to continue.

Installation Type

Choose “Configure MPLAB XC C Compiler as a network client.”


Enter information about the network license server here. This information should be provided by your local network administrator.

“Server Name” refers to the IP address or host name of the network license server where licenses are hosted.

“Port Number” is the port that the network server will use to distribute licenses. A default port of 5053 is already filled in. The network license server will always run on this port, unless otherwise specified.

Click **Next** to continue.

FIGURE 2-3: INSTALLATION TYPE SCREEN



Continue Installation

To continue installing a network client from a network license server, go to the [Installation Directory](#) screen under **Section 2.3 “Installation Flow”**.


2.3 INSTALLATION FLOW

The basic flow of compiler installation is described below. Specific installs are referenced to other sections.

Welcome

Launch the compiler installation executable. An “MPLAB Certified” splash screen will appear and then disappear. Then, the Welcome screen will appear. Click **Next** to continue.

FIGURE 2-4: WELCOME SCREEN




License Agreement

Read the license agreement, and accept the agreement, to proceed. When you accept, **Next** becomes available. Click it to continue.

If you do not agree, the installation terminates.

FIGURE 2-5: LICENSE AGREEMENT SCREEN



Detailed Install Screens

The next screens will dictate how your compiler is installed.

The most common install is:

- **Section 2.1 “Install a Compiler on a Local Computer”**

For information about installing on a network, read:

- **Section 2.2.1 “Network Server/Client Overview”**


Return to the specified section in this flow when you have finished.

XC Installer & License Manager

Installation Directory

Enter or browse to a location to install your compiler. It is recommended that you use the default location displayed in the dialog. Click **Next** to continue.

FIGURE 2-6: INSTALLATION DIRECTORY SCREEN




Compiler Settings

You now have the opportunity to select compiler settings. Check any options you need. In general, if this is the first time you are installing this compiler on your machine, you should let the installer modify any path or environmental variables to ensure correct compiler operation.

Click **Next** to continue.

FIGURE 2-7: COMPILER SETTINGS SCREEN



XC Installer & License Manager

Ready to Install and Installing

You are now set up to install the compiler. This is your chance to make changes to the compiler settings by using the **Back** button. If you are ready to install, click **Next** to continue.

The next dialog shows the progress of the install. When it is complete, click **Next** to continue.

FIGURE 2-8: READY TO INSTALL SCREEN





FIGURE 2-9: INSTALLING SCREEN



Licensing Information


A free edition of the compiler (fully functional with minimum optimizations) has now been installed. If you want more code optimizations, you need to license your compiler. You may click one of the links on this screen to:

- Purchase a license
- Get a 60-day-evaluation license of the PRO edition compiler
- Activate a license

For more on licensing, see **Chapter 3. “Licensing Your Compiler”**.

Click **Next** to continue.

FIGURE 2-10: LICENSING INFORMATION SCREEN




Completing Setup

The compiler has now been installed. Click **Finish** to complete the install.

If you wish to make changes, you can run the installer again and update your install.

FIGURE 2-11: COMPLETING SETUP SCREEN



2.4 UPGRADING THE COMPILER

To upgrade your compiler, simply install the new compiler as you installed the previous one, but skip over the “Installation Complete - Licensing Information” screen by clicking “Next”. Since you already have a license, there is no need to activate or obtain a new license.

2.5 UNINSTALLING THE COMPILER

To uninstall the compiler, follow the instructions below.

Launch Uninstaller

Go to the compiler installation directory and launch “Uninstall MPLAB XC C Compiler”. You are asked if you want to uninstall. Click **Yes**.

Uninstalling

The uninstaller removes all the compiler-related files from your system.

Uninstall Complete

When the uninstall is done, it displays an “Uninstallation Complete” message. Click **OK** to finish.

Note: The uninstaller does not remove directory structure or path references.
--

Chapter 3. Licensing Your Compiler

Once you have installed your compiler, you will be presented with the following licensing options:

- Purchasing a License
- Acquiring an Evaluation License
- Activating a License

If you already have a license file (i.e., you have purchased a license from microchipDIRECT), there is no need to activate this file, and you are done.

If you do not have a license file, please continue.

3.1 PURCHASING A LICENSE

To license your installed compiler, click on the link “Click here if you would like to purchase a license” on the installer [Licensing Information](#) screen. The link will direct you to a microchipDIRECT web page where you can select a compiler license to purchase.

If the link in the installation program does not work, copy the following URL into a browser:

<http://www.microchipdirect.com/searchparts.aspx?q=mplab%20xc%20compiler&next=0&resperpage=10&filter=Tools%20and%20Software>

The types of licenses available are:

- Workstation License: This license may be installed on 3 machines for a single user.
- Network Server License: The license must be installed on a License Server and can be shared with any number of users. A Network Server License can only be used by one user at a time, and that user has exclusive use of the license for 60 minutes.

For details on available types and configurations of MPLAB XC C compilers, see:

<http://www.microchip.com/mplabxc/>

3.2 ACQUIRING AN EVALUATION LICENSE

To acquire a license for a 60-day evaluation of the maximum optimizations and support, click on the link “If you would like to get a 60-day-evaluation license, please click here” on the installer “Licensing Information” screen. The link will direct you to a web page where you can acquire a 60-day PRO license.

<http://www.microchip.com/xcdemo/GetDemoLicense.aspx>

3.3 ACTIVATING A LICENSE

If you already have an Activation Code, click on the link “If you have an Activation Code, please click here to activate a license” on the installer [Licensing Information](#) screen. The link will direct you to a web page where you can manually activate your license.

<http://www.microchip.com/xcdemo/GetXCLicense.aspx>

On the web page:

1. You will need your host ID (on the Setup Installation Complete dialog) and your XC Activation key. Enter this information where specified.
2. You may select to either download your license or have it emailed. Choose one of these options and then click **Get XC License**.

To finish license installation:

1. The license information (that you have downloaded or have received via email) is in the form of a Zip file. In either case, unzip the contents to a temporary location.
2. Once unzipped, there are three install script windows: windows.bat, linux.sh, and mac.sh. Run the script that is appropriate for your operating system in a Command window (for a Windows operating system) or a Terminal window (for a Mac OS X or Linux) to install the file.
3. Your compiler license should be installed.

Index

A

Activating a License 22

C

Compiler Installation on a Local Computer 8

Compiler Settings..... 15

E

Evaluation License, Acquiring 21

H

Host Address 10

I

Installing Your Compiler 7

IP Address 10

L

Licensing Your Compiler 21

M

MCC_INCLUDE 15

N

Network Client Compiler Installation 10

P

PATH 15

Port Number..... 10

Purchasing a License..... 21

R

Readme Files 19

S

Server Name 10

U

Uninstalling the Compiler 20

Upgrading the Compiler 20

Worldwide Sales and Service

AMERICAS

Corporate Office
2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7200
Fax: 480-792-7277
Technical Support:
<http://www.microchip.com/support>
Web Address:
www.microchip.com

Atlanta
Duluth, GA
Tel: 678-957-9614
Fax: 678-957-1455

Austin, TX
Tel: 512-257-3370

Boston
Westborough, MA
Tel: 774-760-0087
Fax: 774-760-0088

Chicago
Itasca, IL
Tel: 630-285-0071
Fax: 630-285-0075

Cleveland
Independence, OH
Tel: 216-447-0464
Fax: 216-447-0643

Dallas
Addison, TX
Tel: 972-818-7423
Fax: 972-818-2924

Detroit
Novi, MI
Tel: 248-848-4000

Houston, TX
Tel: 281-894-5983

Indianapolis
Noblesville, IN
Tel: 317-773-8323
Fax: 317-773-5453

Los Angeles
Mission Viejo, CA
Tel: 949-462-9523
Fax: 949-462-9608

New York, NY
Tel: 631-435-6000

San Jose, CA
Tel: 408-735-9110

Canada - Toronto
Tel: 905-673-0699
Fax: 905-673-6509

ASIA/PACIFIC

Asia Pacific Office
Suites 3707-14, 37th Floor
Tower 6, The Gateway
Harbour City, Kowloon
Hong Kong
Tel: 852-2943-5100
Fax: 852-2401-3431

Australia - Sydney
Tel: 61-2-9868-6733
Fax: 61-2-9868-6755

China - Beijing
Tel: 86-10-8569-7000
Fax: 86-10-8528-2104

China - Chengdu
Tel: 86-28-8665-5511
Fax: 86-28-8665-7889

China - Chongqing
Tel: 86-23-8980-9588
Fax: 86-23-8980-9500

China - Hangzhou
Tel: 86-571-8792-8115
Fax: 86-571-8792-8116

China - Hong Kong SAR
Tel: 852-2943-5100
Fax: 852-2401-3431

China - Nanjing
Tel: 86-25-8473-2460
Fax: 86-25-8473-2470

China - Qingdao
Tel: 86-532-8502-7355
Fax: 86-532-8502-7205

China - Shanghai
Tel: 86-21-5407-5533
Fax: 86-21-5407-5066

China - Shenyang
Tel: 86-24-2334-2829
Fax: 86-24-2334-2393

China - Shenzhen
Tel: 86-755-8864-2200
Fax: 86-755-8203-1760

China - Wuhan
Tel: 86-27-5980-5300
Fax: 86-27-5980-5118

China - Xian
Tel: 86-29-8833-7252
Fax: 86-29-8833-7256

China - Xiamen
Tel: 86-592-2388138
Fax: 86-592-2388130

China - Zhuhai
Tel: 86-756-3210040
Fax: 86-756-3210049

ASIA/PACIFIC

India - Bangalore
Tel: 91-80-3090-4444
Fax: 91-80-3090-4123

India - New Delhi
Tel: 91-11-4160-8631
Fax: 91-11-4160-8632

India - Pune
Tel: 91-20-3019-1500

Japan - Osaka
Tel: 81-6-6152-7160
Fax: 81-6-6152-9310

Japan - Tokyo
Tel: 81-3-6880-3770
Fax: 81-3-6880-3771

Korea - Daegu
Tel: 82-53-744-4301
Fax: 82-53-744-4302

Korea - Seoul
Tel: 82-2-554-7200
Fax: 82-2-558-5932 or
82-2-558-5934

Malaysia - Kuala Lumpur
Tel: 60-3-6201-9857
Fax: 60-3-6201-9859

Malaysia - Penang
Tel: 60-4-227-8870
Fax: 60-4-227-4068

Philippines - Manila
Tel: 63-2-634-9065
Fax: 63-2-634-9069

Singapore
Tel: 65-6334-8870
Fax: 65-6334-8850

Taiwan - Hsin Chu
Tel: 886-3-5778-366
Fax: 886-3-5770-955

Taiwan - Kaohsiung
Tel: 886-7-213-7830

Taiwan - Taipei
Tel: 886-2-2508-8600
Fax: 886-2-2508-0102

Thailand - Bangkok
Tel: 66-2-694-1351
Fax: 66-2-694-1350

EUROPE

Austria - Wels
Tel: 43-7242-2244-39
Fax: 43-7242-2244-393

Denmark - Copenhagen
Tel: 45-4450-2828
Fax: 45-4485-2829

France - Paris
Tel: 33-1-69-53-63-20
Fax: 33-1-69-30-90-79

Germany - Dusseldorf
Tel: 49-2129-3766400

Germany - Munich
Tel: 49-89-627-144-0
Fax: 49-89-627-144-44

Germany - Pforzheim
Tel: 49-7231-424750

Italy - Milan
Tel: 39-0331-742611
Fax: 39-0331-466781

Italy - Venice
Tel: 39-049-7625286

Netherlands - Drunen
Tel: 31-416-690399
Fax: 31-416-690340

Poland - Warsaw
Tel: 48-22-3325737

Spain - Madrid
Tel: 34-91-708-08-90
Fax: 34-91-708-08-91

Sweden - Stockholm
Tel: 46-8-5090-4654

UK - Wokingham
Tel: 44-118-921-5800
Fax: 44-118-921-5820