

# Boot Logo



# Agenda

- How to enable boot logo?
- Customize boot logo
- How does boot logo stored in the storage device?
- Notice



# How to enable boot logo?

- Boot logo is only available for videoplayer configuration.
- Otherwise, boot logo is disabled by default.



# Customize boot logo

- Supported Boot logo Format

Format	Resolution
RGBA	1920*1080

- The customized boot logo image can be placed in the "feed" folder.
- Specifying customized image file by setting the option "bootlogo\_file".
- Adjust the "bootlogo\_zone" to appropriate size to prevent from exceeding the storage size reserved for boot logo.



# How does boot logo stored in the storage device?

- There is only one boot logo image stored in the flash device.
- Therefore, the first and second firmware description entries both point to the same storage address.



# Notice

- "burn\_bootlogo" option means that the installer will not do bootlogo burn-in, but the boot logo file still exists in the install.img.
  - Enabling boot logo or not is controlled by the configuration in OpenWRT
  - To truly remove boot logo file from install.img, the "bootlogo\_file" option should leave blank. However, manually doing this might lead to unexpected result. The makefile in OpenWRT will handle this.