

# QUAKE (ESP32) FIRMWARE UPDATE


By connecting to the computer via USB-C and having an internet connection, it is possible to update the firmware (program) loaded on the QUAKE (ESP32) device. The file for the new firmware (XXX.bin) should have already been downloaded from the repository to the computer, ready for use.

## A) DISPOSITION:

Connect the Quake device to the computer using the supplied USB-C cable. Make sure the computer has an internet connection.


## B) ESPWEBTOOL:

Access the online service through the browser: <https://esp.huhn.me/>



## C) CONNECTION:

Press CONNECT and in the dialog window select the USB connection for the paired QUAKE device and press CONNECT:



#### D) NEW FIRMWARE SELECTION:

Press the LAST SELECT box (related to 10000 IMPORTANT DO NOT MAKE A MISTAKE) and select the FW file to upload (XXX.bin) prepared on the computer:

The interface consists of two panels. Each panel has a list of memory addresses: 0x1000, 0x8000, 0xE000, and 0x10000. Each address has a 'SELECT' button and a red trash icon. Below the list are 'RESET' and 'ADD' buttons. The right panel shows the '0x10000' entry selected and labeled 'QUAKE\_INGV\_32.bin'. Below the list are 'RESET' and 'ADD' buttons. Both panels have 'ERASE' and 'PROGRAM' buttons at the bottom.

Output

```
Click Connect to start
Connecting...
Connected successfully.
Try hard reset.
Chip type ESP32
Connected to ESP32
MAC Address: 1C:69:20:95:EB:C0
```

#### E) FW UPGRADE START:

Press the PROGRAM button and confirm, the update will begin and will complete automatically after a few minutes with a success notification on the screen.

#### F) FINAL VERIFICATION:

Disconnect the Quake device from the computer and proceed to restart it (turn it off and on again), the new firmware will be in operation while keeping the previous data configuration.