



Autodesk®
Topobase™

Archive – Technical Training

Autodesk Topobase Administrator



Autodesk®

Disclaimers

- This course was created for Autodesk Topobase 2009. The contents of this course are not intended for other versions of Autodesk Topobase.
- We may make statements regarding planned or future development efforts for our existing or new products and services. These statements are not intended to be a promise or guarantee of future delivery of products, services or features but merely reflect our current plans, which may change. Purchasing decisions should not be made based upon reliance on these statements.
- The Company assumes no obligation to update these forward-looking statements to reflect events that occur or circumstances that exist or change after the date on which they were made.

Chapter Overview

- Chapter teaches you how jobs help manage workflow in a multi-user setting.
- Use *states* to edit, review, and quality-check data.

Topobase Jobs

Chapter Objectives

- By the end of this chapter, you will be able to:
 - Explain how multiple users can edit data.
 - Explain what a job is.
 - Job-enable a document.
 - Create a job template for certain topics and user groups.
 - Review job client functionality.

13.2 What Is a Job?

- Jobs allow you to manage and control editing and updates by multiple users for a feature class.
 - In essence, a job is a long transaction process involving a feature class in Topobase.
 - Its special strength is managing spatial information in multi-user environments.
 - It is based on the Oracle virtual private database.

13.2 What Is a Job? +

- A job enables you to select an area that is being built or modified.
 - Keeps the modifications separate from production data.
 - Enforces an approval process for completed jobs.
- Once completed, all jobs are maintained on a historical basis and can be rolled back to provide a view of your data at any point in time.

13.2.1 States


- Data can only be changed within a job.
 - **Open** job.
 - **Pending** job.
 - **Live** job.

13.3 Defining a Job in the Topobase Administrator

- Before you job-enable any feature class, you should define how to restrict the geographical access for a job.


13.3.1 Preparation for Job Perimeter

- When working with jobs, it is possible to define a perimeter which will set separate working areas.
 - Only features within the perimeter can be changed
 - Useful in an environment where multiple users use the same job template



13.3.2 Enable Jobs for the Document

- Job enabling launches certain routines.



Data Model Administrator

Right-click to open shortcut menus


Help

Name	Caption	Unit	Data Type	Length/Prec.
FID	Feature ID		Number	10
GEOM	Geometry		Geometry	1
AREA	Area of the polygon	square meter	Number	20
BUILDING_NUMBER	Building Number		Varchar2	10
JOB_VERSION	JOB_VERSION		Number	10


The screenshot shows the 'Data Model Administrator' window. On the left is a tree view with the following structure: ATLAND_VER@ordl > Topics > Building > Building Label > Building Number. The 'Building' node is selected. On the right is a table with 5 columns: Name, Caption, Unit, Data Type, and Length/Prec. The table contains 6 rows of attribute data. The 'JOB_VERSION' row is highlighted with a blue border.


13.3.2 Enable Jobs for the Document +

- *Feature Locking*
 - Pessimistic (recommended)
 - Optimistic
- *Perimeter Setting*
 - Set the perimeter configuration



13.3.3 Assigning a Perimeter to Topics

- After the basic definition you can set different buffers and perimeter Feature classes for particular topics.
- Open the **Jobs** section in the Document Settings. Now a new icon called Advanced Settings  is available.




The image shows a software dialog box titled "Advanced Settings" with a dropdown arrow on the left. It contains a table with three columns: "Topic", "Buffer [m]", and "Perimeter Feature Class". The table has four rows of data. The first row, "BUILDING", is highlighted in blue. Each row has a small dropdown arrow in the "Perimeter Feature Class" column.

Topic	Buffer [m]	Perimeter Feature Class
BUILDING	0.005	LM_JOB_PERIMETER
PARCEL	0.005	LM_JOB_PERIMETER
LM_JOB	0	None (No perimeter check)
LANDUSE	0.005	LM_JOB_PERIMETER



13.3.4 Creating a Job Template

- Specifies a selection of job-enabled feature classes which can be processed.
- *A feature class that is not job enabled is a kind of “free agent” that is outside the jobs system. It can be edited in every job, or outside any job, by any user who has permission.*





13.3.4 Creating a Job Template +

- Use Topobase Administrator to define any number of job templates containing any combinations of job enabled feature classes.




10.3.4 Creating a Job Template ++

- Define **passwords** to control when a change from state to state is made:
 - Direction – **F**orward, **B**ackward.
 - Type – **M**erge, **D**elete, do **N**othing.




10.3.2 Creating a Job Template +++



- Passwords:


- Select the transition.
- Click **Select**.

...then manage the password.



13.3.5 Making Settings to Display Job Features


- Display Manager has to be configured to display job data properly.




```
CREATE OR REPLACE VIEW LM_V_BUILDING_JOB
(FID, GEOM, JOB_VERSION,
STATE, JOB_OPERATION_ID, JOB_ID, NAME)
AS
SELECT a.fid, a.geom, a.job_version,
       b.state, b.job_operation_id, b.job_id, c.name
FROM LM_PARCEL a, TB_JOB_VERSION b, TB_JOB c
WHERE a.job_version = b.job_version
AND b.job_id = c.ID
/
```

13.4 Using the Job (Client Functions)

- The client user manages jobs using the Job Toolbar.




- The user selects the jobs and launches the Job Manager window.
- In the job manager, the user is able to launch the Create Job window.



13.4 Using the Job (Client Functions) +


- The user defines a job perimeter .



- The perimeter feature class layer should be loaded in the Display Manager to show the borderline of the Job.
- Now data can be modified inside the Job.

13.4 Using the Job (Client Functions) ++


- In the Job Explorer particular changes could be set Live before the whole Job is finished.



- After completion the status will be changed to Pending.
 - A review status where all users can see the changes in the data
 - The data is read-only

13.4 Using the Job (Client Functions) +++

- Depending on the revision result the Job status can be set back to Open.
- The job status is set to Live to merge the changes of the the job into production data.
- The Historical View shows you - for any passed date - the Live state data .



13.6 Chapter Summary

- You should now be able to:
 - Explain how multiple users can edit data.
 - Explain what a job is.
 - Job-enable a document.
 - Create a job template for certain topics and user groups.
 - Review job client functionality.

Autodesk®