

THORMANG3

THORMANG3 Tutorial

Operating PC



Table of Contents



1. Introduction

1. System Configuration
2. What is OPC(Operating PC)

2. How to set OPC

1. Ubuntu Installation & Network Setting
2. ROS Installation & Environment Setting
3. THORMANG3 OPC Package



3. How to run THORMANG3

1. Connect to THORMANG3
2. Time Synchronization
3. Running THORMANG3
4. Remote Control

1. Introduction



1. System Configuration





2. What is OPC



- **OS**

- Above Ubuntu 14.04 LTS



ubuntu


- **ROS(Robot Operating System)**

- Version : above indigo
- Installation (Desktop-Full)
- Environment setup

ROS

- **ROBOTIS ROS Package**

- ROBOTIS-THORMANG-OPC
- ROBOTIS-THORMANG-msgs
- ROBOTIS-THORMANG-Common
- ROBOTIS-Framework-msgs



THORMANG3



2. What is OPC



- **Additional Package for THORMANG OPC**
 - [humanoid_navigation](#)
 - map-server
 - nav-msgs
 - humanoid-nav-msgs
 - octomap, octomap-msgs, octomap-ros, octomap-server
 - [sbpl](#)
 - [qt_ros](#)

2. How to set OPC



1. Ubuntu Installation



- **Overview**

- The pc for remote control is recommended Ubuntu 16.04 LTS.




ubuntu

- **Installation**

- Using USB


- **Network Setting**

- [WIKI](#)









1. Network Setting



• OPC Network Setting

- Go Network -> Edit connections
- Select Network type and Edit
- Set to Manual and type as following





2. ROS Installation & Environment Setup



- **Overview**

- Version : kinetic

- **Installation(Desktop-Full)**

- Setup your sources.list

```
$ sudo sh -c 'echo "deb http://packages.ros.org/ros/ubuntu $(lsb_release -sc) main" >
/etc/apt/sources.list.d/ros-latest.list'
```

- Set up your keys

```
$ sudo apt-key adv --keyserver hkp://ha.pool.sks-keyservers.net --recv-key
421C365BD9FF1F717815A3895523BAEEB01FA116
```

- Installation

```
$ sudo apt-get update
$ sudo apt-get install ros-kinetic-desktop-full
```

- Initialize rosdep

```
$ sudo rosdep init
$ rosdep update
```

- Getting rosinstall

```
$ sudo apt-get install python-roscpp
```



2. ROS Installation & Environment Setup



- Configuring Your ROS Environment

- Managing Your Environment

- Check

```
$ printenv | grep ROS
```

- Setup

```
$ source /opt/ros/kinetic/setup.bash
```

- Create a ROS Workspace

- Create a catkin workspace

```
$ mkdir -p ~/catkin_ws/src  
$ cd ~/catkin_ws/src  
$ catkin_init_workspace
```

- Build

```
$ cd ~/catkin_ws  
$ catkin_make
```

- Setup

```
$ source ~/catkin_ws/devel/setup.bash
```



2. ROS Installation & Environment Setup



- Environment setup for OPC

- Open '~/.bashrc'

```
$ gedit ~/.bashrc
```

- Append below contents

```
# Set ROS Kinetic
source /opt/ros/kinetic/setup.bash
source ~/catkin_ws/devel/setup.bash

##### Set ROS Network #####
# PPC CORE(10.17.3.35)
export ROS_MASTER_URI=http://10.17.3.35:11311

# local ROS IP
export ROS_IP=10.17.3.100
```

- ROS_MASTER_URI : PPC (10.17.3.35), roscore
- ROS_IP : OPC (10.17.3.100)

- Apply

```
$ source ~/.bashrc
```



3. THORMANG OPC Package



- THORMANG OPC Package : [WIKI](#)
- Additional Package

- [humanoid_navigation](#)

- Dependencies : map-server, nav_msgs, humanoid-nav-msgs, octomap, octomap-msgs, octomap-ros, octomap-server

```
$ sudo apt-get install ros-kinetic-map-server ros-kinetic-nav-msgs ros-kinetic-humanoid-nav-msgs ros-kinetic-octomap ros-kinetic-octomap-msgs ros-kinetic-octomap-ros ros-kinetic-octomap-server
```

- Dependencies : [sbpl](#)

```
$ cd ~/catkin_ws/src
$ git clone https://github.com/sbpl/sbpl.git
$ cd sbpl
$ mkdir build
$ cd build
$ cmake ..
$ make
$ sudo make install
```

- Build

```
$ cd ~/catkin_ws/src
$ git clone https://github.com/AravindaDP/humanoid\_navigation.git
$ cd ~/catkin_ws
$ catkin_make
```

- [qt_ros](#)

```
$ sudo apt-get install ros-kinetic-qt-ros
```



3. THORMANG OPC Package



- **THORMANG OPC Package**

- Download source

```
$ cd ~/catkin_ws/src  
$ git clone https://github.com/ROBOTIS-GIT/ROBOTIS-Framework-msgs.git  
$ git clone https://github.com/ROBOTIS-GIT/ROBOTIS-THORMANG-OPC.git  
$ git clone https://github.com/ROBOTIS-GIT/ROBOTIS-THORMANG-msgs.git  
$ git clone https://github.com/ROBOTIS-GIT/ROBOTIS-THORMANG-Common.git
```

- Build

```
$ cd ~/catkin_ws  
$ catkin_make
```


3. How to run THORMANG3



How to connect to THORMANG3



- Connecting THORMANG3
From your computer go to your LAN settings and set static IP to the same network (Example: 10.17.3.xxx)
- Connection Information
 - 1) MPC (Motion PC) IP : **10.17.3.30**
 - 2) PPC (Perception PC) IP : **10.17.3.35**
 - 3) MPC & PPC user name : **robotis**
 - 4) MPC & PPC password : **111111**






How to connect to THORMANG3



- Example with SSH Client (Windows)
 - 1) Execute SSH client program (ex: PuTTY)
 - 2) Input THORMANG 3 MPC's IP address : **10.17.3.30**
 - 3) Select **SSH** as a connection type and then open it.
 - 4) Input THORMANG 3 MPC's user name : **robotis**
 - 5) Input THORMANG 3 MPC's password : **111111**
- ROBOTIS recommends that users connect via SSH client.





How to connect to THORMANG3



- Example with SSH Client (Ubuntu)
 - 1) Open terminal window
 - 2) Input SSH command with user name and MPC's IP address :
`$ ssh robotis@10.17.3.30`
 - 3) Input THORMANG 3 MPC's password : `111111`

```
robotis@mpc: ~  
thor@thor-OPC:~$ ssh -l robotis 10.17.3.30  
robotis@10.17.3.30's password:  
Welcome to Ubuntu 14.04.3 LTS (GNU/Linux 3.19.0-39-generic x86_64)  
  
* Documentation:  https://help.ubuntu.com/  
  
545 packages can be updated.  
150 updates are security updates.  
  
Last login: Wed Feb 17 13:31:15 2016 from 10.17.3.110  
robotis@mpc:~$
```





How to connect to THORMANG3



- Example with VNC client (Windows)
 - 1) Execute VNC client program (ex: Ultra VNC Viewer)
 - 2) Input THORMANG 3 MPC's IP address : **10.17.3.30**
 - 3) Input THORMANG 3 MPC's password : **111111**

Accessing THORMANG3 MPC via remote desktop may result in slower performance.





AP Server Information



- **Account**

- User : admin
- PW : admin

- **Network**

1. IP : 10.17.3.1
2. Mode : Router
3. Wireless
 - 5G
SSID : THORMANG-SXX-5G
PW : 11111111
 - 2.4G
SSID : THORMANG-SXX
PW : 11111111

- **Mode Description**

- Orange : Router
- Green : Repeater
- Red : AP
- RESET : 10 sec





1. Connection to THORMANG3



- **Connect to the MPC(Motion PC)**


- via ssh
open terminal and type as following (*pw : 111111*)

```
$ ssh robotis@10.17.3.30
```

- **Connect to the PPC(Perception PC)**

- via ssh
open terminal and type as following (*pw : 111111*)

```
$ ssh robotis@10.17.3.35
```





2. Time Synchronization



- Timing Issues
- **MPC : Synchronize time with the PPC**
 - Connect to the MPC
 - Synchronize time
 - If this is the first synchronization, create the script file.

- Create the script file

```
$ gedit ~/timesync
```

- Type below contents

```
#!/home/robotis  
sudo date --set='-2 secs'  
sudo ntpdate 10.17.3.35  
sudo hwclock -w
```

- Add execute permission

```
$ sudo chmod +x ~/timesync
```

- Run the script

```
$ ~/timesync
```



3. Running THORMANG3



- [WIKI](#)
- **Execute the programs on the PPC**
 - **roscore** (ROS_MASTER_URI)
 - Connect to the PPC
 - Launch [roscore](#)

```
$ roscore
```

- **thormang3 sensors**
 - Connect to the PPC
 - Execute [thormang3_sensors.launch](#) file

```
$ roslaunch thormang3_sensors thormang3_sensors.launch
```



3. Running THORMANG3



- Execute the programs on the MPC
 - **thormang3 manager**
 - Connect to the PPC
 - Execute [thormang3_manager.launch](#) file

```
$ roslaunch thormang3_manager thormang3_manager.launch
```




4. Remote Control



- [WIKI](#)
- **OPC : Synchronize time with the PPC**
 - Synchronize time
 - If this is the first synchronization, create the script file.

- Create the script file

```
$ gedit ~/timesync
```

- Type below contents

```
#!/home/robotis  
sudo date --set='-2 secs'  
sudo ntpdate 10.17.3.35  
sudo hwclock -w
```

- Add execute permission

```
$ sudo chmod +x ~/timesync
```

- Execute the script

```
$ ~/timesync
```




4. Remote Control



- **Visualization Tool**

- After running THORMANG3, Run Visualization Tool
 - Open a terminal and Type as following

```
$ roslaunch thormang3_description thormang3_opc.launch
```





4. Remote Control



- **GUI Demo**

- After running THORMANG3, Execute [thormang3_demo](#)
 - Open a terminal and Type as following

```
$ roslaunch thormang3_demo thormang3_demo.launch
```

