



Surveillance Bot Handbook

Contact number: 8217378963

Email: contactus@raaksapphire.com

Surveillance Bot

Step 1:

Components List:

- 1) ESP32CAM
- 2) 4DW kit
- 3) FTDI FT232RL FT232 USB to UART TTL
- 4) Jumper Wires
- 5) Breadboard
- 6) L298 Motor Driver


Step 2:

Assembly Instructions

- **Construct the Bot:** Assemble the **4DW kit** by following the manufacturer's instructions.
- **Mount the ESP32-CAM:** Secure the ESP32-CAM module in a stable position for video streaming.
- **Go Through Raak Sapphire YouTube Channel** Or visit this link: [Surveillance Bot Guide](#)
-

Step 3:

Circuit diagram



Step 4:**Wiring Guide**

- **ESP32-CAM to L298N Motor Driver:** Ensure correct motor control wiring.
- **Motor Driver to Motors:** Connect motor terminals properly.
- **Power Connections:** Verify stable power supply for all components.

Step 5:**Software Setup and Programming**

- **Install the Arduino IDE:** Download and install from the official Arduino website.
- **Load the Code:** Write or paste the provided ESP32-CAM video streaming and motor control code.
- **Upload the Program:** Connect ESP32-CAM via FTDI module, select the correct board, and upload.

Step 6:**Operating the Surveillance**

- **Power On:** After wiring and uploading the code, turn on the bot.
- **Control Movements:** Use a Wi-Fi-based interface or pre-programmed controls to navigate the bot.
- **Live Stream Video:** Access the ESP32-CAM's IP address in a browser to view the real-time video feed.

Troubleshooting

- **Bot Not Moving:** Check motor driver connections and power supply.
- **No Video Feed:** Ensure ESP32-CAM is properly configured and connected to Wi-Fi.
- **Erratic Movements:** Verify wiring, especially motor control connections.

Maintenance and Safety

- Regularly inspect all connections for wear and tear.
- Keep the bot away from water and extreme temperatures.
- Secure all components to prevent loose connections during movement.

+91 8217378963

teamsales@raaksapphire.com

www.raaksapphire.com

28, Service Rd, next to Prashanth Hospital
Towards Electronic city, Bommanahalli,
Bengaluru, Karnataka 560068

**Trusted and Certified By**