

ProStep Vision System

User Manual

Purpose

This document explains how to access and operate the ProStep Vision System as a STEP operator or as the GATE controller.

System Access

The system must be accessed using a desktop or notebook computer at:
<https://prostepvision-system.vercel.app/>

STEP Login

STEP operators must use a valid operator ID (for example: 111220, 111221) and a valid serial number. The corresponding STEP must be selected during login.

GATE Login

The GATE panel is accessed exclusively using ID **222222**. No serial number is required. Select GATE in the step selector.

Real-Time Demonstration

To test the system, open two browser tabs: one logged in as GATE and another as STEP to observe live updates.