

ProStep Vision System

Manual do Usuário

Purpose

This document describes how to access and operate the ProStep Vision System, both as STEP operator and as GATE controller.

System Access

Access the system using a desktop or notebook computer at:
<https://prostepvision-system.vercel.app/>

STEP Access

Operators must log in using a valid STEP operator ID (e.g. 111220, 111221) and a valid serial number. The STEP must be selected according to the operation being performed.

GATE Access

The GATE panel is accessed exclusively using the ID **222222**. No serial number is required. Select GATE in the step selector.

Real-Time Test

For demonstration purposes, open two browser tabs: one logged in as GATE and another as STEP to observe real-time confirmations.