

Reboot

Purpose	Used to restart the Switch.
Syntax	reboot
Description	This command is used to restart the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To restart the Switch:

```
DES-3026:4#reboot
```

Command: reboot

Are you sure want to proceed with the system reboot? (y/n)

reset

Purpose	Used to reset the Switch to the factory default settings.
Syntax	reset {[config system]}
Description	This command is used to restore the Switch's configuration to the default settings assigned from the factory.
Parameters	<p><i>config</i> – If the keyword 'config' is specified, all of the factory default settings are restored on the Switch including the IP address, user accounts, and the Switch history log. The Switch will not save or reboot.</p> <p><i>system</i> – If the keyword 'system' is specified all of the factory default settings are restored on the Switch. The Switch will save and reboot after the settings are changed to default. Rebooting will clear all entries in the Forwarding Data Base.</p> <p>If no parameter is specified, the Switch's current IP address, user accounts, and the Switch history log are not changed. All other parameters are restored to the factory default settings. The Switch will not save or reboot.</p>
Restrictions	Only administrator-level users can issue this command.

Example usage:

To restore all of the Switch's parameters to their default values:

```
DES-3026:4#reset config
```

Command: reset config

Success.

Are you sure you want to proceed with system rest?(y/n)y

Success.

```
DES-3026:4#
```

login

Purpose	Used to log in a user to the Switch's console.
Syntax	login
Description	This command is used to initiate the login procedure. The user will be prompted for his Username and Password.
Parameters	None.
Restrictions	None.

Example usage:

To initiate the login procedure:

DES-3026:4#login

Command: login

UserName:

logout

Purpose	Used to log out a user from the Switch's console.
Syntax	logout
Description	This command terminates the current user's session on the Switch's console.
Parameters	None.
Restrictions	None.

Example usage:

To terminate the current user's console session:

DES-3026:4#logout

ping

Purpose	Used to test the connectivity between network devices.
Syntax	ping <ipaddr> {times <value 1-255>} {timeout <sec 1-99>}
Description	The ping command sends Internet Control Message Protocol (ICMP) echo messages to a remote IP address. The remote IP address will then "echo" or return the message. This is used to confirm connectivity between the Switch and the remote device.
Parameters	<p><i><ipaddr></i> - Specifies the IP address of the host.</p> <p><i>times <value 1-255></i> - The number of individual ICMP echo messages to be sent. The maximum value is 255. The default is 0.</p> <p><i>timeout <sec 1-99></i> - Defines the time-out period while waiting for a response from the remote device. A value of 1 to 99 seconds can be specified. The default is 1 second.</p>

ping

Pinging an IP address without the *times* parameter will ping the target device an infinite amount of times.

Restrictions

Only administrator-level users can issue this command.

Example usage:

To ping the IP address 10.48.74.121 four times:

```
DES-3026:4#ping 10.48.74.121 times 4
```

```
Command: ping 10.48.74.121
```

```
Reply from 10.48.74.121, time<10ms
```

```
Reply from 10.48.74.121, time<10ms
```

```
Reply from 10.48.74.121, time<10ms
```

```
Reply from 10.48.74.121, time<10ms
```

```
Ping statistics for 10.48.74.121
```

```
Packets: Sent =4, Received =4, Lost =0
```

```
DES-3026:4#
```

SPANNING TREE COMMANDS

The Switch supports 802.1d STP and 802.1w Rapid STP. The spanning tree commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config stp	{maxage <value 6-40> hellotime <value 1-10> forwarddelay <value 4-30> priority <value 0-61440> version [rstp stp] txholdcount <value 1-10> fbpdu [enabled disabled] lbd [enabled disabled] lbd_recover_timer [0 <sec 60-1000000>]}
config stp ports	<portlist> {cost [auto <value 1-200000000>] priority <value 0-240> migrate [yes no] edge [true false] p2p [true false auto] state [enabled disabled] lbd [enabled disabled] fbpdu [enabled disabled] }
enable stp	
disable stp	
show stp	
show stp ports	{<portlist>}

Each command is listed, in detail, in the following sections.

config stp

Purpose	Used to setup STP and RSTP on the Switch.
Syntax	config stp {maxage <value 6-40> hellotime <value 1-10> forwarddelay <value 4-30> priority <value 0-61440> version [rstp stp] txholdcount <value 1-10> fbpdu [enabled disabled] lbd [enabled disabled] lbd_recover_timer [0 <sec 60-1000000}]}
Description	This command is used to setup the Spanning Tree Protocol (STP) for the entire switch.
Parameters	<p><i>maxage <value 6-40></i> – The maximum amount of time (in seconds) that the Switch will wait to receive a BPDU packet before reconfiguring STP. The default is 20 seconds.</p> <p><i>hellotime <value 1-10></i> – The time interval between transmission of configuration messages by the root device. The default is 2 seconds.</p> <p><i>forwarddelay <value 4-30></i> – The maximum amount of time (in seconds) that the root device will wait before changing states. The default is 15 seconds.</p> <p><i>priority <value 0-61440></i> – A numerical value between 0 and 61440 that is used in determining the root device, root port, and designated port. The device with the highest priority becomes the root device. The lower the numerical value, the higher the priority. The default is 32,768.</p> <p><i>version [rstp stp]</i> - Select the Spanning Tree Protocol version used for the Switch. For IEEE 802.1d STP select <i>stp</i>. Select <i>rstp</i> for IEEE 802.1w Rapid STP.</p> <p><i>txholdcount <value 1-10></i> - The maximum number of Hello packets transmitted per interval. Default value = 3.</p> <p><i>fbpdu [enabled disabled]</i> – Allows the forwarding of STP BPDU packets from other network devices when STP is disabled on the Switch. The default is enabled.</p> <p><i>lbd [enable disable]</i> – Enabling this feature temporarily block STP on the Switch when a BPDU packet has been looped back to the switch. When the Switch detects its own BPDU packet coming back, it signifies a loop on the network. STP will automatically be blocked and an alert will be sent to the administrator. The LBD STP port will restart (change to discarding state) when the LBD Recover Time times out. The default is enabled.</p> <p><i>lbd_recover_timer [0 <value 60-1000000>]</i> - This field will set the time the STP port will wait before recovering the STP state set. 0 will denote that the LBD will never time out or restart until the administrator personally changes it. The user may also set a time between 60 and 1000000 seconds. The default is 60 seconds.</p>
Restrictions	Only administrator-level users can issue this command.

Example usage:

To configure STP with maxage 18 and hellotime 4:

```
DES-3026:4#config stp maxage 18 hellotime 4
Command: config stp maxage 18 hellotime 4

Success.

DES-3026:4#
```

config stp ports

Purpose	Used to setup STP on the port level.
Syntax	config stp ports <portlist> {cost [auto <value 1-200000000>] priority <value 0-240> migrate [yes no] edge [true false] p2p [true false auto] state [enabled disabled] lbd [enabled disabled]}
Description	This command is used to create and configure STP for a group of ports.
Parameters	<p><portlist> – Specifies a port or range of ports to be configured.</p> <p>cost – This defines a metric that indicates the relative cost of forwarding packets to the specified port list. Port cost can be set automatically or as a metric value. The default value is <i>auto</i>.</p> <ul style="list-style-type: none"> <i>auto</i> – Setting this parameter for the external cost will automatically set the speed for forwarding packets to the specified port(s) in the list for optimal efficiency. Default port cost: 100Mbps port = 200000. Gigabit port = 20000. <value 1-200000000> - Define a value between 1 and 200000000 to determine the external cost. The lower the number, the greater the probability the port will be chosen to forward packets. <p>priority <value 0-240> – Port Priority can be from 0 to 240. The lower the number, the greater the probability the port will be chosen as the Root Port. Default = 128.</p> <p>migrate [yes no] – <i>yes</i> will enable the port to migrate from 802.1d STP status to 802.1w RSTP status. RSTP can coexist with standard STP, however the benefits of RSTP are not realized on a port where an 802.1d network connects to an 802.1w enabled network. Migration should be enabled (<i>yes</i>) on ports connected to network stations or segments that will be upgraded to 802.1w RSTP on all or some portion of the segment.</p> <p>edge [true false] – <i>true</i> designates the port as an edge port. Edge ports cannot create loops, however an edge port can lose edge port status if a topology change creates a potential for a loop. An edge port normally should not receive BPDU packets. If a BPDU packet is received it automatically loses edge port status. <i>false</i> indicates that the port does not have edge port status.</p> <p>p2p [true false auto] – <i>true</i> indicates a point-to-point (P2P) shared link. P2P ports are similar to edge ports however they are restricted in that a P2P port must operate in full-duplex. Like edge ports, P2P ports transition to a forwarding state rapidly thus benefiting from RSTP. A p2p value of <i>false</i> indicates that the port cannot have p2p status. <i>auto</i> allows the port to have p2p status whenever possible and operate as if the p2p status were <i>true</i>. If the port cannot maintain this status (for example if the port is forced to half-duplex operation) the p2p status changes to operate as if the p2p value were <i>false</i>.</p> <p>state [enabled disabled] – Allows STP to be enabled or disabled for the ports specified in the port list. The default is disabled.</p> <p>lbd [enable disable] - Used to enable or disable the loop-back detection function on the Switch for the ports configured above in the <i>config stp</i> command.</p>
Restrictions	Only administrator-level users can issue this command.

Example usage:

To configure STP with path cost 19, priority 15, and state enabled for ports 1-5.

```
DES-3026:4#config stp ports 1-5 cost 19 priority 15 state enabled
Command: config stp ports 1-5 cost 19 priority 15 state enabled

Success.

DES-3026:4#
```

enable stp

Purpose	Used to globally enable STP on the Switch.
Syntax	enable stp
Description	This command allows the Spanning Tree Protocol to be globally enabled on the Switch.
Parameters	None.
Restrictions	Only administrator-level users can issue this command.

Example usage:

To enable STP, globally, on the Switch:

```
DES-3026:4#enable stp
Command: enable stp

Success.

DES-3026:4#
```

disable stp

Purpose	Used to globally disable STP on the Switch.
Syntax	disable stp
Description	This command allows the Spanning Tree Protocol to be globally disabled on the Switch.
Parameters	None.
Restrictions	Only administrator-level users can issue this command.

Example usage:

To disable STP on the Switch:

```
DES-3026:4#disable stp
Command: disable stp

Success.

DES-3026:4#
```

show stp

Purpose	Used to display the Switch's current STP configuration.
Syntax	show stp
Description	This command displays the Switch's current STP configuration.
Parameters	None.
Restrictions	None.

Example usage:

To display the status of STP on the Switch:

Status 1: STP enabled with STP compatible version

```
DES-3026:4#show stp
Command: show stp

STP Status      : Enabled
Max Age         : 20
Hello Time      : 2
Forward Delay   : 15
Priority        : 32768
Default Path Cost : 802.1T
STP Version     : STP compatible
TX Hold Count   : 3
Forwarding BPDU : Enabled
Loopback Detection: Disabled
LBD Recover Time : 60

Designated Root Bridge: 00-54-85-26-05-00
Root Priority    : 4096
Cost to Root    : 200004
Root Port       : 19
Last Topology Change : 6sec
Topology Changes Count: 37
Protocol Specification: 3
Max Age         : 20
Hello Time      : 2
Forward Delay   : 15
Hold Time       : 3
CTRL+C ESC q Quit SPACE n Next Page p Previous Page r Refresh
```


Status 2 : STP disabled

```
Command: show stp

STP Status      : Disabled
Max Age         : 20
Hello Time      : 2
Forward Delay   : 15
Priority         : 32768
Default Path Cost : 802.1T
STP Version     : RSTP
TX Hold Count   : 3
Forwarding BPDU : Enabled
Loopback Detection: Disabled
LBD Recover Time : 60

DES-3026:4#
```

show stp ports

Purpose	Used to display the Switch's current per-port group STP configuration.
Syntax	show stp ports <portlist>
Description	This command displays the Switch's current per-port group STP configuration.
Parameters	<i><portlist></i> – Specifies a port or range of ports to be configured.
Restrictions	None.

Example usage:

To display STP state of all ports, with STP enabled:

DES-3026:4#show stp ports

Command: show stp ports

STP Port Information

Port Index : 1
Connection : Link Down
State : Yes
Cost : *2000000
Priority : 128
LBD : No
Edge : No
P2P : Yes
Status : Disabled
Role : Disabled
Forwarding BPDU : Enabled

CTRL+C ESC q Quit SPACE n Next Page p Previous Page r Refresh

show fdb

Purpose	Used to display the current unicast MAC address forwarding database.
Syntax	show fdb {port <port> vlan <vlan_name 32> mac_address <macaddr> static aging_time}
Description	This command will display the current contents of the Switch's forwarding database.
Parameters	<p><i>port <port></i> – The port number corresponding to the MAC destination address. The Switch will always forward traffic to the specified device through this port.</p> <p><i><vlan_name 32></i> – The name of the VLAN on which the MAC address resides.</p> <p><i><macaddr></i> – The MAC address by which the forwarding table will be viewed.</p> <p><i>static</i> – Displays the static MAC address entries.</p> <p><i>aging_time</i> – Displays the aging time for the MAC address forwarding database.</p>
Restrictions	None.

To display the aging time:

```
DES-3026:4#show fdb aging_time
Command: show fdb aging_time

Unicast MAC Address Aging Time = 300

DES-3026:4#
```

Example usage:

To display unicast MAC address table:

```
DES-3026:4#show fdb
Command: show fdb

Unicast MAC Address Ageing Time = 300

VID  VLAN Name  MAC Address      Port  Type
---  -
1    default    00-00-39-34-66-9A  10    Dynamic
1    default    00-00-51-43-70-00  10    Dynamic
1    default    00-00-5E-00-01-01  10    Dynamic
1    default    00-00-74-60-72-2D  10    Dynamic
1    default    00-00-81-05-00-80  10    Dynamic
1    default    00-00-81-05-02-00  10    Dynamic
1    default    00-00-81-48-70-01  10    Dynamic
1    default    00-00-E2-4F-57-03  10    Dynamic
1    default    00-00-E2-61-53-18  10    Dynamic
1    default    00-00-E2-6B-BC-F6  10    Dynamic
1    default    00-00-E2-7F-6B-53  10    Dynamic
1    default    00-00-E2-82-7D-90  10    Dynamic
1    default    00-00-F8-7C-1C-29  10    Dynamic
1    default    00-01-02-03-04-00  CPU    Self
1    default    00-01-02-03-04-05  10    Dynamic
1    default    00-01-30-10-2C-C7  10    Dynamic
1    default    00-01-30-FA-5F-00  10    Dynamic
1    default    00-02-3F-63-DD-68  10    Dynamic
CTRL+C ESC q Quit SPACE n Next Page ENTER Next Entry a All
```

VLAN COMMANDS

The VLAN commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create vlan	<vlan_name 32> {tag <vlanid 2-4094>}
delete vlan	<vlan_name 32>
config vlan	<vlan_name 32> [{add [tagged untagged] delete] <portlist>}
show vlan	{<vlan_name 32>}

Each command is listed, in detail, in the following sections.

create vlan

Purpose	Used to create a VLAN on the Switch.
Syntax	create vlan <vlan_name 32> {tag <vlanid 2-4094>}
Description	This command allows the creation of a VLAN on the Switch.
Parameters	<p><vlan_name 32> – The name of the VLAN to be created.</p> <p>tag <vlanid 2-4094> – The VLAN ID of the VLAN to be created. Allowed values = 2-4094. VLAN 1 is reserved for the default VLAN set originally on the Switch.</p>
Restrictions	Each VLAN name can be up to 32 characters. Only Administrator-level users can issue this command.

Example usage:

To create a VLAN v1, tag 2:

```
DES-3026:4#create vlan v1 tag 2
Command: create vlan v1 tag 2

Success.

DES-3026:4#
```

delete vlan

Purpose	Used to delete a previously configured VLAN on the Switch.
Syntax	delete vlan <vlan_name 32>
Description	This command will delete a previously configured VLAN on the Switch.
Parameters	<vlan_name 32> – The VLAN name of the VLAN to delete.
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To remove the VLAN v1:

```
DES-3026:4#delete vlan v1
Command: delete vlan v1

Success.

DES-3026:4#
```

config vlan

Purpose	Used to add additional ports to a previously configured VLAN.
Syntax	config vlan <vlan_name 32> {[add [tagged untagged] delete] <portlist>}
Description	This command allows the user to add or delete ports to the port list of a previously configured VLAN. Additional ports may be specified as tagging or untagging. The default is to assign the ports as untagged.
Parameters	<p><vlan_name 32> – The name of the VLAN to which to add ports.</p> <p>add – Specifies to add ports to a previously created vlan.</p> <p>delete – Specifies to delete ports to a previously created vlan.</p> <p>tagged – Specifies the additional ports as tagged.</p> <p>untagged – Specifies the additional ports as untagged.</p> <p><portlist> – A port or range of ports to be added to or deleted from the VLAN.</p>
Restrictions	Only Administrator-level users can issue this command.

Example usage:

To add ports 4 through 8 as tagged ports to the VLAN v1:

```
DES-3026:4#config vlan v1 add tagged 4-8
Command: config vlan v1 add tagged 4-8

Success.

DES-3026:4#
```

show vlan

Purpose	Used to display the current VLAN configuration on the Switch
Syntax	show vlan {<vlan_name 32>}
Description	This command displays summary information about each VLAN including the VLAN ID, VLAN name, the Tagging/Untagging status, and the Member/Non-member status of each port that is a member of the VLAN.
Parameters	<vlan_name 32> – The VLAN name of the VLAN for which to display a summary of settings.
Restrictions	None.

Example usage:

To display the Switch's current VLAN settings:

```
DES-3026:4#show vlan
Command: show vlan

VID           : 1
VLAN Name     : default
VLAN TYPE     : static
Member ports  : 1-26
Static ports  : 1-26
Tagged ports  :
Untagged ports: 1-26

Total Entries : 1

DES-3026:4#
```

BASIC IP COMMANDS

The IP interface commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
config ipif	[System] [{ipaddress <network_address> vlan <vlan_name 32> state [enable disable]} bootp dhcp]
show ipif	

Each command is listed, in detail, in the following sections.

config ipif	
Purpose	Used to configure the System IP interface.
Syntax	config ipif [System] [{ipaddress <network_address> vlan <vlan_name 32> state [enable disable]} bootp dhcp]
Description	This command is used to configure the System IP interface on the Switch.
Parameters	<p><i>System</i> - The IP interface name to be configured. The default IP Interface name on the Switch is "System". All IP interface configurations done will be executed through this interface name.</p> <p><i><network_address></i> – IP address and netmask of the IP interface to be created. The address and mask information may be specified by using the traditional format (for example, 10.1.2.3/255.0.0.0 or in CIDR format, 10.1.2.3/16).</p> <p><i><vlan_name 32></i> – The name of the VLAN corresponding to the System IP interface.</p> <p><i>state [enable disable]</i> – Used to enable or disable the IP interface.</p> <p><i>bootp</i> – Allows the selection of the BOOTP protocol for the assignment of an IP address to the Switch's System IP interface.</p> <p><i>dhcp</i> – Allows the selection of the DHCP protocol for the assignment of an IP address to the Switch's System IP interface.</p>
Restrictions	Only administrator-level users can issue this command.

Example usage:

To configure the IP interface System:

```
DES-3026:4#config ipif System ipaddress 10.48.74.122/8
Command: config ipif System ipaddress 10.48.74.122/8

Success.

DES-3026:4#
```


show ipif

Purpose	Used to display the configuration of an IP interface on the Switch.
Syntax	show ipif
Description	This command will display the configuration of an IP interface on the Switch.
Parameters	None.
Restrictions	None.

Example usage:

To display IP interface settings.

```
DES-3026:4#show ipif
Command: show ipif

IP Interface Settings

Interface Name : System
IP Address    : 10.48.74.122  (MANUAL)
Subnet Mask   : 255.0.0.0
VLAN Name     : default
Admin. State  : Disabled
Link Status   : Link UP
Member Ports  : 1-26

DES-3026:4#
```

ROUTING TABLE COMMANDS

The routing table commands in the Command Line Interface (CLI) are listed (along with the appropriate parameters) in the following table.

Command	Parameters
create iproute	[default] <ipaddr> {<metric 1-65535>}
delete iproute	[default]
show iproute	{<network address>} {static}

Each command is listed, in detail, in the following sections.

create iproute

Purpose	Used to create IP route entries to the Switch's IP routing table.
Syntax	create iproute [default] <ipaddr> {<metric 1-65535>}
Description	This command is used to create a default static IP route entry to the Switch's IP routing table.
Parameters	<p><ipaddr> – The gateway IP address for the next hop router.</p> <p><metric 1-65535> – Allows the entry of a routing protocol metric entry representing the number of routers between the Switch and the IP address above. The default setting is 1.</p>
Restrictions	Only administrator-level users can issue this command.

Example Usage:

To add the default static address 10.48.74.121, with a metric setting of 1, to the routing table:

```
DES-3026:4#create iproute default 10.48.74.121 1
Command: create iproute default 10.48.74.121 1

Success.

DES-3026:4#
```

delete iproute default

Purpose	Used to delete a default IP route entry from the Switch's IP routing table.
Syntax	delete iproute [default]
Description	This command will delete an existing default entry from the Switch's IP routing table.
Parameters	None.
Restrictions	Only administrator-level users can issue this command.

Example usage:

To delete the default IP route 10.53.13.254:

DES-3026:4#delete iproute default 10.53.13.254

Command: delete iproute default 10.53.13.254

Success.

DES-3026:4#

show iproute

Purpose	Used to display the Switch's current IP routing table.
Syntax	show iproute {<network address>} {static}
Description	This command will display the Switch's current IP routing table.
Parameters	<p><i>network address</i> – IP address and netmask of the IP interface that is the destination of the route. The address and mask information may be specified by using the traditional format (for example, 10.1.2.3/255.0.0.0 or in CIDR format, 10.1.2.3/8).</p> <p><i>static</i> - Use this parameter to display static iproute entries.</p>
Restrictions	None.

Example Usage:

To display the contents of the IP routing table:

DES-3026:4#show iproute

Command: show iproute

Routing Table

IP Address/Netmask	Gateway	Interface	Hops	Protocol
-----	-----	-----	----	-----
0.0.0.0	10.1.1.254	System	1	Default
10.0.0.0/8	10.48.74.122	System	1	Local

Total Entries: 2

DES-3026:4#