

DATE: / /

Name: Sandia Tasnim

ID: 21301383

Section: 09

Course: CSE340

1a


Control unit sends different ALU op code for different types of instruction. For example, when it is lw, sw instruction it sends 00, when it is beq it sends 01 and when it is R-type instructions it send 10.

lw R1, 0(R2)

add R1, R1, R2

or R1, R1, R2

and R1, R1, R2



SW \$53, 32 (\$52)

opcode	rs	rt	Address/offset
xxxxxx	\$53	\$52	32
31-26	25-21	20-16	15-0

Pipeline stages

	ee1	ee2	ee3	ee4	ee5	ee6	ee7	ee8	ee9
1. sw R1, 0(R2)	IF	ID	EX	ME	WQ				
2 add R4, R1, R5		IF	ID	EX	ME	WQ			
3. on R6, R4, R7			IF	ID	EX	ME	WQ		
4. and R8, R1, R6				IF	ID	EX	ME	WQ	

Hazard removal using Stall and forwarding

1 sw R1, 0(R2)	IF	ID	EX	ME	WQ				
2. add R4, R1, R5									
3 OR R6, R4, R7									
4. and R8, R1, R6									