

Post Installation Configuration

Table of Contents

Memory Settings.....	1
----------------------	---

Now that you have installed Restcomm SMSC to suit your needs, you can go ahead and configure the Stack to meet your requirements. The User Guide (available along with this Installation Guide) in the *restcomm-ss7-
<version>/ss7/docs* folder will assist you in configuring and managing the Stack. The Shell Management module will enable you to easily configure the Stack using the Command Line Interface (CLI) tool.

Memory Settings

-Xms3072m

Initial heap size, set in megabytes

-Xmx3072m

Maximum heap size, set in megabytes