

SKY DIVER[®]

ATARI[®] GAME PROGRAM[™] INSTRUCTIONS



COMPLETE
GAME PLAY
INSTRUCTIONS

TWO PLAYERS
ONLY

SCORING
SECTION 2

TABLE OF CONTENTS

1. GAME PLAY	1
2. USING THE CONTROLLERS	2
3. CONSOLE CONTROLS	3
4. SCORING	3
5. GAME VARIATIONS	4

NOTE: Always turn the console power switch off when inserting or removing an ATARI® Game Program™ cartridge. This will protect the electronic components and prolong the life of your ATARI Video Computer System™ game.


Manual, Program and Audiovisual © 1978 ATARI, INC.

1. GAME PLAY

Your initial task is to guide the sky diver onto the landing pad. Your ultimate task is to score more points than your opponent. To hit the landing pad and score points you must:

- Release the sky diver from the airplane.
- Open the parachute.
- Control the downward drift of the sky diver.
- Land squarely on the pad at the bottom of the screen.

There are five two-player games in SKY DIVER®. You and your opponent have nine jumps each in which to score points. See the **SCORING** section for details.



Both planes fly across the screen simultaneously, but in opposite directions.

WIND FACTOR

You must contend with a varying wind factor during each jump (except in Games 3 and 4). The "wind sock" at the bottom, center of the screen indicates the direction and the speed of the wind.

If the sock is pointing to the right, the wind is blowing to the right, and conversely for the left. If the sock is hanging loosely, the wind speed is slower than when the sock is flying rigidly and taut.

The wind factor changes between jumps and may vary slightly during a jump.



Wind Blowing to the Left



Wind Blowing to the Right



Fastest Wind



Medium Wind



Slowest Wind



No Wind

2. USING THE CONTROLLERS



Use your Joystick Controllers with this ATARI® Game Program™ cartridge. Be sure the Joystick Controller cables are firmly plugged into the **RIGHT** and **LEFT CONTROLLER** jacks at the back of your ATARI Video Computer System™ game. Hold the Joystick with the red button to your upper left, toward the television screen. See Section 3 of your owner's manual for further details.

The left player uses the left Joystick; the right player uses the right Joystick. You have no control

over the flight of the plane across the screen. Here's how to use your Joystick Controller to operate the sky diver:

- 1 Push the red button on your Joystick Controller to release the sky diver from the plane.
- 2 Pull back on the Joystick (toward yourself) to open the parachute.
- 3 Move the Joystick to the right and to the left to steer the sky diver right or left against the wind.



3. CONSOLE CONTROLS

GAME SELECT SWITCH

Use the **game select** switch to select the game number you wish to play. The game number changes at the top, left side of the screen as you press down the switch.

GAME RESET SWITCH

When you have selected the game number you wish to play, press **game reset** to start the game.

DIFFICULTY SWITCH

Beginning players should start with the **difficulty** switch in the **b** position. In the **a** position, the planes fly significantly faster across the screen, thereby increasing the difficulty.

It is possible for one player to have fast planes (using the **a** position) and the other player to have slow planes (using the **b** position) in the same game.

The difficulty switches have no effect in Game 5. Both planes fly at the faster speed.

TV TYPE SWITCH

Set this switch to color if you have a color television set. Set it to **b-w** if you are playing the game in black and white.

4. SCORING

Here's where to combine nerve and skill to beat your opponent. You only score points when your sky diver lands squarely on the pad with an open parachute.

THE LONGER YOU WAIT TO OPEN THE PARACHUTE, THE MORE POINTS YOU SCORE.

You can score from 0 to 11 points per jump, depending on when you open the chute. There is a point at the bottom of the descent where the parachute can no longer be opened.

If your sky diver hits the ground with an unopened chute, you lose four points.

The maximum score to shoot for in all games is 99. The right and left scores on the screen represent the right and left players, respectively.

During game play the number of jumps remaining is shown at the bottom left corner of the screen.

5. GAME VARIATIONS

Games 1 and 2 are identical with one exception. In **Game 2** the width of each landing pad is smaller, making it more difficult to score points. The landing pads are placed in different spots for each jump.

In **Games 3 and 4** the landing pads move back and forth. There is no wind factor. The landing pads in **Game 4** are smaller in width.

Play "chicken" in **Game 5** with your opponent. There's only one landing pad in the middle of the screen. The first player to land squarely on the pad scores points; the other player receives no points for that jump.

GAME PROGRAM™ CARTRIDGE LIMITED NINETY DAY WARRANTY

ATARI, INC. ("Atari") warrants to the original consumer purchaser that your ATARI® Game Program cartridge is free from any defects in material or workmanship for a period of ninety days from the date of purchase. If any such defect is discovered within the warranty period, Atari's sole obligation will be to replace the cartridge free of charge on receipt of the cartridge (charges prepaid, if mailed or shipped) with proof of date of purchase at either the retail store where the cartridge was purchased or at one of the ATARI Regional Service Centers listed below:

Atari, Inc.
1312 Crossman Ave.
Sunnyvale, CA 94086

Atari, Inc.
5400 Newport Dr.
Suite 1
Rolling Meadows, IL 60008

Atari, Inc.
43 Belmont Dr.
Somerset, NJ 08873

Atari, Inc.
2109 East Division St.
Arlington, TX 76001

This warranty shall not apply if the cartridge (i) has been misused or shows signs of excessive wear; (ii) has been damaged by being used with any products not supplied by ATARI, or (iii) has been damaged by being serviced or modified by anyone other than an ATARI Regional Service Center.

ANY APPLICABLE IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS, ARE HEREBY LIMITED TO NINETY DAYS FROM THE DATE OF PURCHASE. CONSEQUENTIAL OR INCIDENTAL DAMAGES RESULTING FROM A BREACH OF ANY APPLICABLE EXPRESS OR IMPLIED WARRANTIES ARE HEREBY EXCLUDED.

Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitations of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.



A Warner Communications Company 

ATARI, INC., Consumer Division
P.O. Box 427, Sunnyvale, CA 94086