

CONFIDENTIAL

Linux Interface Specification Yocto recipe Start-Up Guide

User's Manual: Software

R-Car V3U/V3H/V3M Series

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.

7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,
Koto-ku, Tokyo 135-0061, Japan

www.renesas.com

Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:
www.renesas.com/contact/.

CONFIDENTIAL

Trademark

- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Arm is a registered trademark of Arm Limited (or its subsidiaries) in the US and/or elsewhere.
- Windows and Windows Media are registered trademarks of Microsoft Corporation in the United States and other countries.
- Other company names and product names mentioned herein are registered trademarks or trademarks of their respective owners.
- Registered trademark and trademark symbols (® and ™) are omitted in this document

CONFIDENTIAL

How to Use This Manual

- **[Readers]**

This manual is intended for engineers who develop products which use the R-Car V3U/V3H/V3M processor.

- **[Purpose]**

This manual is intended to give users an understanding of the functions of the R-Car V3U/V3H/V3M processor device driver and to serve as a reference for developing hardware and software for systems that use this driver.

- **[How to Read This Manual]**

It is assumed that the readers of this manual have general knowledge in the fields of electrical

— Engineering, logic circuits, microcontrollers, and Linux.

→ Read this manual in the order of the CONTENTS.

— To understand the functions of a multimedia processor for R-Car V3U/V3H/V3M

→ See the R-Car V3U/V3H/V3M User's Manual.

— To know the electrical specifications of the multimedia processor for R-Car V3U/V3H/V3M

→ See the R-Car V3U/V3H/V3M Data Sheet.

- **[Conventions]**

The following symbols are used in this manual.

Data significance: Higher digits on the left and lower digits on the right

Note: Footnote for item marked with Note in the text

Caution: Information requiring particular attention

Remark: Supplementary information

Numeric representation: Binary ... xxxx, 0bxxxx, or xxxxB

Decimal ... xxxx

Hexadecimal ... 0xxxxx or xxxxH

Data type: Double word ... 64 bits

Word ... 32 bits

Half word ... 16 bits

Byte ... 8 bits

CONFIDENTIAL

Table of Contents

| | |
|---|----|
| Introduction..... | 1 |
| A flowchart for using this Start Up Guide. | 1 |
| 1. R-Car V3U/V3H/V3M Linux BSP package files..... | 3 |
| 1.1 Reference (R-Car V3U/V3H/V3M)..... | 3 |
| 2. Environmental Requirement | 4 |
| 2.1 Setting of PC equipments..... | 4 |
| 2.2 Setting of board dip switches | 7 |
| 3. Building Instructions on Linux Host PC..... | 19 |
| 3.1 Using build script..... | 19 |
| 3.2 Explanation about build script | 20 |
| 4. Writing boot loaders and u-boot | 22 |
| 5. Confirm starting of U-Boot and Linux | 30 |
| Appendix:..... | 32 |
| How to install TFTP server and NFS server | 32 |
| How to set IP address to Linux Host PC..... | 35 |
| Exporting Toolchains..... | 36 |
| Out-of-tree driver information | 39 |


Introduction

This start-up guide explains R-Car V3U/V3H/V3M Yocto recipe package files, the system environments, the make method of kernel, the operating of U-Boot and so on.

This product R-Car V3U/V3H/V3M Yocto recipe is a basic package to operate built-in Linux and basic middleware on the R-Car V3U/V3H/V3M System Evaluation Board. Please contact Renesas Electronics person who provided this product to you in case of questions.

The meaning of **red** characters is update part from the previous document.

A flowchart for using this Start Up Guide.



(*1) Linux BSP includes the following drivers.

- Display
- DMA Engine
- GPIO
- I2C
- IPMMU
- Kernel Core
- MSIOF
- Power Management
- PWM
- RWDT
- SCIF/HSCIF
- SD/MMC
- U-Boot
- Video Capture
- PCIEC
- CAN-FD
- CMEM
- CMT/TMU
- Memory Manager
- RPC
- UIO
- Ethernet-AVB

(*2) Out-of-tree Kernel drivers: Refer to [Appendix: Out-of-tree driver information](#)

CONFIDENTIAL

1. R-Car V3U/V3H/V3M Linux BSP package files

This Yocto recipe will be taken.

The U-Boot source code from:

<https://github.com/renesas-r-car/u-boot.git>

R-Car V3U/V3H/V3M Linux source code from:

<https://github.com/renesas-r-car/linux-bsp.git>

1.1 Reference (R-Car V3U/V3H/V3M)

| Document | Document name | Version | Date |
|---|---|----------|---------------|
| R-CarV3U Series User's Manual | [R19UH0144EJ0056] R-Car V3U series User's Manual with Image Recognition chapter.pdf | Rev.0.56 | Feb. 05, 2021 |
| R-CarV3U System Evaluation Board FALCON Hardware Manual RTP0RC779A0CPB0010S | e_Falcon_hwman_rev003_1204.pdf | Rev.0.03 | Dec. 04, 2020 |
| R-CarV3U System Evaluation Board FALCON Setup Manual | e_Falcon_suman_rev007_1204.pdf | Rev.0.07 | Dec. 04, 2020 |
| R-Car Series, 3rd Generation User's Manual: Hardware | r19uh0105ej0220-r-car-3rd-generation.pdf | Rev.2.20 | Jun. 30, 2020 |
| R-CarV3H System Evaluation Board Condor-I Setup Manual | e_Condor-I_suman_rev001_0711.pdf | Rev.0.01 | Jul. 11, 2019 |
| R-CarV3H System Evaluation Board Condor Setup Manual | ASOS-C18-009_Condor_suman_rev100_e.pdf | Rev.1.00 | Feb. 28, 2018 |
| R-CarV3M System Evaluation Board Eagle Setup Manual | e_Eagle_suman_rev003_0608.pdf | Rev.003 | Jun. 08, 2017 |
| R-Car V3H Starter Kit HW Manual | R20UT4302ED0100.pdf | Rev.3.00 | Feb. 19, 2021 |
| R-Car V3M Starter Kit HW Manual | REN_r12ut0003ed0230-rcarv3m_MAT_20190124.pdf | Rev.2.30 | Jan. 24, 2019 |

2. Environmental Requirement

2.1 Setting of PC equipments

Host PC and terminal software are necessary for the operation of this product. Furthermore, Ethernet cable is required to use NFS mount function. Please refer to Table 1.

Table 1 R-Car V3U/V3H/V3M Linux BSP Environmental Requirement

| Equipment | Software requirement and explanation | |
|----------------------------------|---|---|
| Linux Host PC | Ubuntu 20.04 LTS (64bit) is recommended as OS. 32bit version is not supported. It is used as compiling and debugging environment. Please refer the following URL https://ubuntu.com/tutorials/install-ubuntu-desktop It can also be used as TFTP server and NFS server. For “How to set IP address to Linux Host PC”, please refer to Appendix | |
| | TFTP server software | It is used when Hyper Flash is written by U-Boot or Image is downloaded. For installing TFTP server, please refer to Appendix |
| | NFS server software | It is used when File system is mounted by NFS. For installing NFS server, please refer to Appendix |
| Windows PC for terminal software | Windows 10 is recommended as OS. It is used as debugging environment. Terminal software and VCP driver are executed. | |
| | Terminal software | Please use following software. 1) Tera Term (Confirmed with Japanese version of Tera Term 4.88 Available at http://sourceforge.jp/projects/ttssh2) |
| | VCP driver | Please install in Windows Host PC. The host PC that connects to the Falcon board requires a USB driver for FT2232H. It can be obtained from the following URL. https://www.ftdichip.com/Drivers/VCP.htm The host PC that connects to the Condor/Condor-I board requires a USB driver for the CP2102N. It can be obtained from the following URL. https://www.silabs.com/products/development-tools/software/usb-to-uart-bridge-vcp-drivers The host PC that connects to Eagle board requires a USB driver for the CP210.2 It can be obtained from the following URL. http://www.silabs.com/products/mcu/Pages/USBtoUARTBridgeVCPDrivers.aspx The host PC that connects to V3H Starter Kit requires FTDI driver, it can be obtained from the following URL. http://www.ftdichip.com/Drivers/D2XX.htm USB become virtual COM port on terminal software. Please connect to: <ul style="list-style-type: none"> • CN10 on V3U System Evaluation Board. • CN11 on V3H/V3M System Evaluation Board. • CN6 on V3H Starter Kit. |

CONFIDENTIAL

Please connect R-Car V3U/V3H/V3M System Evaluation Board, Windows Host PC with terminal software for console and Linux Host PC with TFTP and NFS server as Figure 1 below.

In case of R-Car V3U, Ethernet connector is CN3 on breakout board, serial connector is CN10 on CPU board.

For the Terminal Software on Windows Host PC. Configure the Terminal Software on Windows Host PC as followings. Please refer to Table 1 about the VCP driver for making a USB host connector into a virtual COM port.

[setting value] baud rate 115200, 8bit data, parity none, stop 1 bit, flow control none

Recommended Environment

The following shows a Recommended Environment.




Figure 1. Recommended Environment for R-Car V3U/V3H/V3M Linux BSP

The LAN port on the Linux Host PC should be separated from that connecting to the Internet and that connecting to the system evaluation board. For example, prepare another LAN board or USB-LAN and add LAN port connecting to the system evaluation board.

The LAN port should be able to set a static IP address.

IP address (192.168.0.1):

This is used for IP address of TFTP server and NFS server on Linux Host PC.

U-boot environment variables name is "serverip".

IP address (192.168.0.20):

This is used for IP address of System Evaluation Board.

U-boot environment variables name is "ipaddr".

Ethernet MAC address:

This is used for Ethernet MAC address of the network device on System Evaluation Board.

U-boot environment variables name is "ethaddr".

USB cable:

Connect USB Host connector of Windows PC that is virtual COM port to CN10 of Falcon, CN11 of Condor, Condor-I or Eagle with USB cable for displaying console.

2.2 Setting of board dip switches

The setting of R-Car V3U/V3H/V3M System Evaluation Board's dip switches is shown in the following Table 2, Table 3, Table 4, Table 5.

Note) Please refer each evaluation board 's Setup manual in detail and set the dip switches according to your use case.

Note) We describe **bold character** about Dip switches which are different from the default settings of System Evaluation Board Setup Manual.

For Falcon board, please refer to “R-CarV3U System Evaluation Board Falcon Setup Manual (FALCON_suman_revx.pdf)” and find the picture below.




Figure 1.2.1 Location of Switches on the Falcon CPU Board (Component Side)




Figure 1.4.1 Location of Switches on the Breakout Board (Component Side)

CONFIDENTIAL

Table 2 setting of Dip switches on Falcon board (R-Car V3U Ver.1.0)

| Switch Number | Switch Name | Side (C/S) | Pin1 | Pin2 | Pin3 | Pin4 | Pin5 | Pin6 | Pin7 | Pin8 |
|-------------------------|----------------|------------|---------|--------|---------|------|------|------|------|------|
| Falcon CPU board | | | | | | | | | | |
| SW50*1 | FPGA | C | ON | ON | OFF | ON | OFF | ON | OFF | OFF |
| SW57 | Hyper/SPI | C | | | ✓ | - | - | - | - | - |
| SW13 | SPI/EX-SPI | C | ✓ | - | | - | - | - | - | - |
| SW43 | MMC/SD | C | | ✓ | | - | - | - | - | - |
| SW44 | DSI | C | | ✓ | | - | - | - | - | - |
| SW46 | SOFTSW | C | OFF | OFF | - | - | - | - | - | - |
| SW47 | PUSHSW0 | C | Push SW | - | - | - | - | - | - | - |
| SW48 | PUSHSW1 | C | Push SW | - | - | - | - | - | - | - |
| SW49 | PUSHSW2 | C | Push SW | - | - | - | - | - | - | - |
| SW51 | ACCSW | C | | - | ✓ (OFF) | - | - | - | - | - |
| SW52 | PRESET# | C | Push SW | - | - | - | - | - | - | - |
| SW54 | VDDQ_SDHI | C | | ✓ | | - | - | - | - | - |
| (SW55) | MXBKUP | C | ✓ (OFF) | | - | - | - | - | - | - |
| SW56 | RL78_CRST# | C | Push SW | - | - | - | - | - | - | - |
| (JP1) | PWSTG1 | C | Open | - | - | - | - | - | - | - |
| Breakout board | | | | | | | | | | |
| SW1 | RL78_RST# | C | Push SW | - | - | - | - | - | - | - |
| SW2 | RL78_PUSHSW | C | Push SW | - | - | - | - | - | - | - |
| SW3 | CAN_SILENT | C | | ✓ (ON) | - | - | - | - | - | - |
| SW4 | CAN5/FlexRay_A | C | ON | OFF | - | - | - | - | - | - |
| SW5 | CAN5/FlexRay_B | C | ON | OFF | - | - | - | - | - | - |
| SW8 | EN_FlexRay_A | C | ✓ (OFF) | | - | - | - | - | - | - |
| SW9 | EN_FlexRay_B | C | ✓ (OFF) | | - | - | - | - | - | - |
| JP1 | D12.0V2_A | C | Short | - | - | - | - | - | - | - |
| JP2 | D12.0V2_B | C | Short | - | - | - | - | - | - | - |
| JP5 | D12.0V2_C | C | Short | - | - | - | - | - | - | - |
| JP3 | EX_PWRON | C | Open | - | - | - | - | - | - | - |
| JP4 | D5.0V2 | C | Open | - | - | - | - | - | - | - |

C: Component side of the board, S: Solder side of the board.

*1: Booting is from the SPI flash memory (U6) on the Falcon CPU board or the SPI flash memory connected to the EX-SPI connector (CN3).

Figure 1.2.1 Location of Switches on the Condor-I Board (Component Side)

CONFIDENTIAL

Table 3 setting of Dip switches on Condor-I board (R-Car V3H Ver.2.0)

| Switch Number | Switch Name | Slide (C/S) | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 | Pin 7 | Pin 8 |
|---------------|-------------|-------------|---------|--------|---------|-------|-------|-------|-------|-------|
| SW3 | MODESW-A | C | OFF | ON*1 | ON | OFF | ON | OFF | ON | ON |
| SW20 | MODESW-B | C | OFF | ON | ON | ON | ON | ON | ON | ON |
| SW4 | MODESW-C | C | OFF | ON | ON | ON | ON | ON | OFF | ON |
| SW13 | MODESW-D | C | OFF | OFF | - | - | - | - | - | - |
| SW37 | DBGMODE | C | OFF | OFF | - | - | - | - | - | - |
| SW2 | SOFTSW | C | OFF | OFF | OFF | OFF | - | - | - | - |
| SW5*2 | QSPIO-A | C | ✓ | - | - | - | - | - | - | - |
| SW6*2 | QSPIO-B | C | ✓ | - | - | - | - | - | - | - |
| SW7*2 | QSPIO-C | C | ALL OFF | | | | | - | - | - |
| SW8 | QSPIO-A | C | - | - | ✓ | - | - | - | - | - |
| SW9 | QSPIO-B | C | ALL ON | | | | | - | - | - |
| SW1 | DDRBKUP | C | OFF | OFF | - | - | - | - | - | - |
| SW11 | LVDS-A | C | ON | ON | - | - | - | - | - | - |
| SW12 | LVDS-B | C | - | - | ✓ | - | - | - | - | - |
| SW18 | MIPI-SW | C | ON | ON | - | - | - | - | - | - |
| SW35 | MAX9286 | C | ON | ON | ON | OFF | ON | ON | - | - |
| SW32 | GPIO/CAN | C | - | ✓ (ON) | - | - | - | - | - | - |
| SW14 | PCIe/HSSTP | C | - | ✓ (ON) | - | - | - | - | - | - |
| SW23 | MSIOF-A | C | ✓ | - | - | - | - | - | - | - |
| SW24 | MSIOF-B | C | ✓ | - | - | - | - | - | - | - |
| SW25 | MSIOF-C | C | ✓ | - | - | - | - | - | - | - |
| SW26 | MSIOF-D | C | ✓ | - | - | - | - | - | - | - |
| SW36 | PRESET# | C | Push SW | - | - | - | - | - | - | - |
| SW15 | PUSHSW0 | C | Push SW | - | - | - | - | - | - | - |
| SW16 | PUSHSW1 | C | Push SW | - | - | - | - | - | - | - |
| SW17 | PUSHSW2 | C | Push SW | - | - | - | - | - | - | - |
| SW22 | ACCSW | C | - | - | ✓ (OFF) | - | - | - | - | - |
| SW38 | TRG_PWR | C | ON | OFF | - | - | - | - | - | - |
| SW39 | M0BKUP | C | - | ✓ (ON) | - | - | - | - | - | - |
| JP1 | V_TEST | C | Open | - | - | - | - | - | - | - |
| (JP3) | VDDQ_VIN01 | C | - | - | - | - | - | - | - | - |
| (JP4) | VDDQ_DU | C | - | - | - | - | - | - | - | - |

C: Component side of the board, S: Solder side of the board

*1: SW3 Pin2 ON to boot through ICUMXA, if boot through Cortex-R7 please set SW3 Pin2 OFF.

*2: 512-Mbit SPI flash memory (U6).

For Condor board, please refer to “R-CarV3H System Evaluation Board Condor Setup Manual (ASOS-C18-009_Condor_suman_revx.pdf)” and find the picture below.




Figure 1.2.1 Location of Switches on the Condor Board (Component Side)

CONFIDENTIAL

Table 4 setting of Dip switches on Condor board (R-Car V3H Ver.1.1)

| Switch Number | Switch Name | Slide (C/S) | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 | Pin 7 | Pin 8 |
|---------------|-------------|-------------|------------|--------|---------|-------|-------|-------|-------|-------|
| SW3 | MODESW-A | C | OFF | ON*1 | ON | OFF | ON | OFF | ON | ON |
| SW20 | MODESW-B | C | OFF | ON | ON | ON | ON | ON | ON | ON |
| SW4 | MODESW-C | C | OFF | ON | ON | ON | ON | ON | OFF | ON |
| SW13 | MODESW-D | C | OFF | OFF | - | - | - | - | - | - |
| SW37 | DBGMODE | C | OFF | OFF | - | - | - | - | - | - |
| SW2 | SOFTSW | C | OFF | OFF | OFF | OFF | - | - | - | - |
| SW5*2 | QSPI0-A | C | ✓ | - | - | - | - | - | - | - |
| SW6*2 | QSPI0-B | C | ✓ | - | - | - | - | - | - | - |
| SW7*2 | QSPI0-C | C | ALL OFF | | | | | - | - | - |
| SW8 | QSPI1-A | C | - | - | ✓ | - | - | - | - | - |
| SW9 | QSPI1-B | C | ALL ON | | | | | - | - | - |
| SW1 | DDRBKUP | C | OFF | OFF | - | - | - | - | - | - |
| SW11 | LVDS-A | C | ON | ON | - | - | - | - | - | - |
| SW12 | LVDS-B | C | - | - | ✓ | - | - | - | - | - |
| SW18 | MIPI-SW | C | ON | ON | - | - | - | - | - | - |
| SW35 | MAX9286 | C | ON | ON | ON | OFF | ON | ON | - | - |
| SW32 | GPIO/CAN | C | - | ✓ (ON) | - | - | - | - | - | - |
| SW14 | PCIe/HSSTP | C | - | ✓ (ON) | - | - | - | - | - | - |
| SW23 | MSIOF-A | C | ✓ | - | - | - | - | - | - | - |
| SW24 | MSIOF-B | C | ✓ | - | - | - | - | - | - | - |
| SW25 | MSIOF-C | C | ✓ | - | - | - | - | - | - | - |
| SW26 | MSIOF-D | C | ✓ | - | - | - | - | - | - | - |
| SW36 | PRESET# | C | Push SW | - | - | - | - | - | - | - |
| SW15 | PUSHSW0 | C | Tactile SW | - | - | - | - | - | - | - |
| SW16 | PUSHSW1 | C | Tactile SW | - | - | - | - | - | - | - |
| SW17 | PUSHSW2 | C | Tactile SW | - | - | - | - | - | - | - |
| SW22 | ACCSW | C | - | - | ✓ (OFF) | - | - | - | - | - |
| JP1 | V_TEST | C | Open | - | - | - | - | - | - | - |
| (JP3) | VDDQ_VIN01 | C | - | - | - | - | - | - | - | - |
| (JP4) | VDDQ_DU | C | - | - | - | - | - | - | - | - |


C: Component side of the board, S: Solder side of the board

*1: SW3 Pin2 ON to boot through ICUMXA, if boot through Cortex-R7 please set SW3 Pin2 OFF.

*2: 512-Mbit SPI flash memory (U6).

CONFIDENTIAL

For Eagle board, please refer to “R-CarV3M System Evaluation Board Eagle Setup Manual (Eagle_suman_revx.pdf)” and find the picture below.



CONFIDENTIAL

Table 5 setting of Dip switches on Eagle board (R-Car V3M Ver.2.0)

| Switch Number | Switch Name | Slide (C/S) | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 | Pin 7 | Pin 8 |
|---------------|-------------|-------------|------------|--------|---------|-------|-------|-------|-------|-------|
| SW2 | SOFTSW | C | OFF | OFF | OFF | OFF | - | - | - | - |
| SW3 | MODESW-A | C | OFF*1 | ON | ON | OFF | ON | ON | - | - |
| SW20 | MODESW-B | C | OFF | ON | ON | ON | - | - | - | - |
| SW4 | MODESW-C | C | OFF | ON | ON | ON | ON | ON | - | - |
| SW5*2 | QSPIO-A | C | ✓ | - | | - | - | - | - | - |
| SW6*2 | QSPIO-B | C | ✓ | - | | - | - | - | - | - |
| SW7*2 | QSPIO-C | C | ALL OFF | | | | | - | - | - |
| SW8 | QSPIO-A | C | | - | ✓ | - | - | - | - | - |
| SW9 | QSPIO-B | C | ALL ON | | | | | - | - | - |
| SW10 | PHYAD | C | OFF | OFF | - | - | - | - | - | - |
| SW11 | LVDS-A | C | ON | ON | - | - | - | - | - | - |
| SW12 | LVDS-B | C | | | ✓ | - | - | - | - | - |
| SW15 | TACTSW0 | C | Tactile SW | - | - | - | - | - | - | - |
| SW16 | TACTSW1 | C | Tactile SW | - | - | - | - | - | - | - |
| SW17 | TACTSW2 | C | Tactile SW | - | - | - | - | - | - | - |
| SW18 | MIPI-SW | C | | ✓ (ON) | - | - | - | - | - | - |
| SW22 | ACCSW | C | | - | ✓ (OFF) | - | - | - | - | - |
| SW36 | PRESET# | C | Push SW | - | - | - | - | - | - | - |
| SW31 | DDRBKUP | C | ✓ (OFF) | | - | - | - | - | - | - |
| SW32 | GPIO/CAN | C | ✓ (OFF) | | - | - | - | - | - | - |
| SW35 | MAX9286 | C | ON | ON | ON | OFF | ON | ON | OFF | ON |
| JP1 | V_TEST | C | Open | - | - | - | - | - | - | - |
| (JP3) | VDDQ_VIN01 | C | | - | | - | - | - | - | - |
| (JP40) | VDDQ_DU | C | | - | | - | - | - | - | - |

C: Component side of the board, S: Solder side of the board

*1: Booted through Cortex-R7.

*2: 512-Mbit SPI flash memory (U6). For V3H Starter Kit, please refer to “R-Car V3H Starter Kit HW Manual (R20UT4302ED0100.pdf)”.

CONFIDENTIAL

For V3H Starter Kit, please refer to “R-Car V3H Starter Kit HW Manual (R20UT4302ED0100.pdf)” and find the below picture.




Table 6 V3H Ver.1.1, Ver.2.0 Starter Kit boot source selection

| Switch Number | Switch Name | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 | Pin 7 | Pin 8 |
|---------------|-------------|-------|-------|-------|-------|-------|-------|-------|-------|
| SW4 | MODESW | ON | ON | OFF | ON | OFF | ON | OFF | OFF |

CONFIDENTIAL

For V3M Starter Kit, please refer to “R-Car V3M Starter Kit HW Manual (REN_r12ut0003ed0230-rcarv3m_MAT_20190124.pdf)” and find the below picture.




Table 7 V3M Ver.2.0 Starter Kit boot source selection

| Switch Number | Switch Name | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 | Pin 7 | Pin 8 |
|---------------|-------------|-------|-------|-------|-------|-------|-------|-------|-------|
| SW4 | MODESW | ON | ON | OFF | ON | OFF | OFF | OFF | OFF |

3. Building Instructions on Linux Host PC

3.1 Using build script

You can build BSP by using Yocto Project. Please execute following steps in \${WORK} directory on Linux Host PC. Root filesystem (which includes out of tree kernel modules and OSS tools) by making following instruction is the one for testing current BSP package in Renesas. Please note that Renesas has not been verified with any other build configuration or modified recipes except “rcar-image-adas”.

Note) If you have executed Yocto build before, please remove your build directory (\${WORK}/build) so that future builds happen from a clean environment.

Step 1 installation of required commands

Ubuntu is used as Linux Host PC since Yocto Project Quick Start specifies Ubuntu as one of the distributions. In case of that you can install the required commands as follows.

Please refer to <http://www.yoctoproject.org/docs/current/yocto-project-qs/yocto-project-qs.html> for detail.

Linux Host PC

```
$ sudo apt-get install gawk wget git-core diffstat unzip texinfo gcc-multilib \
build-essential chrpath socat cpio python3 python3-pip python3-pexpect \
xz-utils debianutils iputils-ping python3-git python3-jinja2 libegl1-mesa \
libstdl1.2-dev pylint3 xterm libarchive-zip-perl
```

Step 2 Execute the build script

Renesas provide the build script for users to simplify their build procedure. Please execute the script with following instruction:

Linux Host PC

```
$. /build_yocto.sh <arg1> <arg2>
```

In which

- arg1 is board type, including “condor” or “falcon” or “eagle” or “all”
 - “condor”: all binaries of Condor, Condor-I and Condor Starter Kit will be compiled
 - “eagle”: all binaries of Eagle, Eagle Starter Kit will be compiled
 - “falcon”: all binaries of Falcon will be compiled
 - “all” all binaries will be compiled
- arg2 is “adas”, because ADAS software packages from Renesas is included.

After compiling successfully, the binaries will be created in \${WORK}/build/tmp/deploy/images/\${supported_board}/ directory with the below description:

Root Filesystem: (rcar-image-adas-<v3u/v3x>.tar.bz2)

Image: file named “Image” (For V3U, V3H/V3M)

Device tree binaries:

- r8a77970-eagle.dtb (For Eagle V3M Ver.2.0)
- r8a77970-v3msk.dtb (For SK V3M Ver.2.0)
- r8a77970-v3msk-vbm.dtb (For SK V3M Ver.2.0 and Video Box Mini)
- r8a77980-condor.dtb (For V3H Ver.1.1)

- r8a77980-v3hsk.dtb (For SK V3H Ver.1.1)
- r8a77980-v3hsk-vbm.dtb (For SK V3H Ver.1.1 and Video Box Mini)
- r8a77980-es2-condor.dtb (For Condor-I V3H Ver.2.0)
- r8a77980-es2-condor.dtb (For Condor-I V3H Ver.2.1)
- r8a77980-es2-v3hsk.dtb (For SK V3H Ver.2.0)
- r8a77980-es2-v3hsk-vbm.dtb (For SK V3H Ver.2.0 and Video Box Mini)
- r8a779a0-falcon.dtb (For V3U Ver.1.0)

Uboot

- u-boot-elf-condor.srec (For Condor-I V3H Ver.2.0)
- u-boot-elf-v3hsk.srec (For SK V3H Ver.1.1, Ver.2.0)
- u-boot-elf-eagle.srec (For Eagle V3M)
- u-boot-elf-eagle-function.srec (For Eagle Function board V3M)
- u-boot-elf-v3msk.srec (For SK V3M Ver.2.0)
- u-boot-elf-falcon.srec (For V3U Ver.1.0)

3.2 Explanation about build script

This is the manual step in the build script:

Step 1 download of required files

Required files (poky) are downloaded by git clone.

```
$ cd ${WORK}
$ git clone git://git.yoctoproject.org/poky
$ git clone git://git.openembedded.org/meta-openembedded
$ git clone https://github.com/renesas-rcar/meta-renesas.git
```

Linux Host PC

Step 2 checkout

Please checkout available version of each git clone.

```
$ cd ${WORK}/poky
$ git checkout -b tmp <commit ID>

$ cd ${WORK}/meta-openembedded
$ git checkout -b tmp <commit ID>

$ cd ${WORK}/meta-renesas
$ git checkout -b tmp <commit ID>
```

Linux Host PC

Note) tmp is a temporary name of a local branch. We can use checkout command without branch. Please note that HEAD refers directly to commit (detached HEAD).

In case of BSP + ADAS packages

When you want to use ADAS software packages from Renesas, please execute as following steps.

CONFIDENTIAL

Step 3 execute source command

Please execute source command with oe-init-build-env for setting environment.

```
$ cd ${WORK}  
$ source poky/oe-init-build-env
```

Linux Host PC

Step 4 copy bblayers.conf and local.conf

Please copy configuration files from deliverables.

```
$ cp ${WORK}/meta-renesas/meta-rcar-  
bsp/docs/sample/conf/${supported_board}/poky-gcc/adas/bblayers.conf  
conf/bblayers.conf  
$ cp ${WORK}/meta-renesas/meta-rcar-  
bsp/docs/sample/conf/${supported_board}/poky-gcc/adas/local.conf  
conf/local.conf
```

Linux Host PC

Note) \${supported_board} is the one of the following: falcon, condor, eagle.

Step 5 building with bitbake

Please build as follows. The file system (rcar-image-adas-<v3u/v3x>.tar.bz2) is created in
\${WORK}/build/tmp/deploy/images/\${supported_board}/ directory.

Note) Build by bitbake might need several hours under the influence of Linux Host PC performance and network environment.

Note) The bitbake downloads some package while building. Then the bitbake might stop for network timeout or link error. In this case, please get applicable package in \${WORK}/build/downloads directory whenever build stops by wget command, or please review timeout definitions of package download (wget, etc.) described in
\${WORK}/poky/meta/conf/bitbake.conf.

```
$ cd ${WORK}/build  
$ bitbake rcar-image-adas
```

Linux Host PC

4. Writing boot loaders and u-boot

In detail, please refer Flash writer manual

(RENESAS_RCV3HV3U_ICUMXA_Flash_Writer_Application_Note_vx.pdf,

RENESAS_RCV3M_CR7_Flash_Writer_Application_Note_vx.pdf).

Step 1 Power off target board, and turn to SCIF download mode and writing mode to 512-Mbit SPI flash memory by setting the following switches.

FALCON case:

| Switch Number | Switch Name | Side (C/S) | Pin1 | Pin2 | Pin3 | Pin4 | Pin5 | Pin6 | Pin7 | Pin8 |
|-------------------------|-------------|------------|--------------|------|------|------|------|---------|------|------|
| Falcon CPU board | | | | | | | | | | |
| SW50 | MODESW | C | ALL OFF (*1) | | | | OFF | ON (*2) | OFF | OFF |
| SW13 | SPI/EX-SPI | C | ✓ | - | | - | - | - | - | - |

(*1) SCIF download mode

(*2) Booted through ICUMXA

Condor or Condor-I board case:

| Switch Number | Switch Name | Side (C/S) | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 | Pin 7 | Pin 8 |
|---------------|-------------|------------|--------------|-------|-------|-------|--------------|-------|-------|-------|
| SW3 | MODESW-A | C | OFF (*1) | ON | ON | OFF | ALL OFF (*2) | | | |
| SW5 | QSPIO-A | C | ✓ (*3) | - | | - | - | - | - | - |
| SW6 | QSPIO-B | C | ✓ (*3) | - | | - | - | - | - | - |
| SW7 | QSPIO-C | C | ALL OFF (*3) | | | | | - | - | - |

(*1) Booted through ICUMXA

(*2) SCIF download mode

Eagle board case:

| Switch Number | Switch Name | Slide (C/S) | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 |
|---------------|-------------|-------------|--------------|-------|--------------|-------|-------|-------|
| SW3 | MODESW-A | C | OFF (*1) | ON | ALL OFF (*2) | | | |
| SW5 | QSPIO-A | C | ✓ (*3) | - | | - | - | - |
| SW6 | QSPIO-B | C | ✓ (*3) | - | | - | - | - |
| SW7 | QSPIO-C | C | ALL OFF (*3) | | | | | - |

(*1) Booted through Cortex-R7

(*2) SCIF download mode

(*3) Switch setting is when writing to 512-Mbit SPI flash memory.

CONFIDENTIAL

Starter Kit V3H case:

| Switch Number | Switch Name | Pin 1 | Pin 2 | Pin 3 | Pin 4 | Pin 5 | Pin 6 | Pin 7 | Pin 8 |
|---------------|-------------|-------|-------|-------|-------|-------|-------|-------|-------|
| SW4 | MODESW | OFF | OFF | OFF | OFF | OFF | ON | OFF | OFF |

Starter Kit V3M case:

As it is described in “RENESAS_RCV3M_CR7_Flash_Writer_Application_Note_vx.pdf”, execute 1-5 to set SCIF download mode

with Configuration Tool (V3M_StarterKit_Configurator.exe). Then go to Step4 (4-2).

1. Connect USB Host connector of Windows PC that is virtual COM port to CN9 of Starter Kit V3M with USB cable.
2. Power ON Starter Kit V3M board.
3. Execute the Configuration Tool.
 - Select "On board peripheral configuration Tab > QSPI device > on-board QSPI0".
 - Then press "Write CPLD (volatile)".
 - Select "SOC mode Configuration Tab > MODE setting > Set by this register".
 - and select "SOC mode Configuration Tab > Boot from [MD4/3/2/1] > SCIF0".
 - Then press "Write CPLD (volatile)".
4. Close the Configuration Tool.
5. Activate the Terminal Software on Windows PC.
6. Press the 'RESET'(SW3) on Starter Kit V3M board.

Step 2 Connect cable

Connect USB Host connector of Windows PC that is virtual COM port to CN10 of FALCON board with USB cable for displaying console.

Connect USB Host connector of Windows PC that is virtual COM port to CN11 of Eagle, Condor or Condor-I board with USB cable for displaying console.

Connect USB Host connector of Windows PC that is virtual COM port to CN6 of Starter Kit V3H with USB cable for displaying console.

Step 3 Set the terminal software

Activate the Terminal Software on Windows PC.

[setting value] baud rate 115200, 8bit data, parity none, stop 1 bit, flow control none

Step 4 Run Flash writer tool**(4-1) Power ON target board.**

Terminal software outputs the following log.

```
SCIF Download mode (w/o verification)
(C) Renesas Electronics Corp.
-- Load Program to RT-SRAM -----
please send !
```

Windows PC for terminal software

(4-2) Please drag and drop the following Flash writer tool mot file.

(FALCON board case)

/os/bootloader/(v3u)/(atf or smoni)/ ICUMXA_Flash_writer_SCIF_DUMMY_CERT_EB200000_falcon.mot

(Condor, Condor-I board case) and (Starter Kit V3H case)

/os/bootloader/(v3h1 or v3h2)/(atf or smoni)/ICUMXA_Flash_writer_SCIF_DUMMY_CERT_EB200400_condor.mot

(Eagle board case) and (Starter Kit V3M case)

/os/bootloader/v3m2/(atf or smoni)/AArch32_Flash_writer_SCIF_DUMMY_CERT_E6300400_EAGLE.mot

When the transfer is successful, the following log is output. (The SOC and version will be changed.)

```
Flash writer for R-Car V3U Series V1.15 Sep.15,2020
```

Windows PC for terminal software

About FALCON case, set the following switches to use QSPI Flash with keeping the board power on.

CONFIDENTIAL

| Switch Number | Switch Name | Side (C/S) | Pin1 | Pin2 | Pin3 | Pin4 | Pin5 | Pin6 | Pin7 | Pin8 |
|-------------------------|-------------|------------|------|------|------|------|------|------|------|------|
| Falcon CPU board | | | | | | | | | | |
| SW50 | MODESW | C | ON | ON | OFF | ON | OFF | ON | OFF | OFF |

Step 5 Write data file to the Serial Flash

Write each S-record format images of loaders to the Serial Flash by flashing tool which is transferred on Step4.

(5-1) Writing data

FALCON board case:

Folder path: /os/bootloader/(v3u)/(atf or smoni)

| Filename | Program Top Address | Flash Save Address | Description |
|-------------------------------------|---------------------|--------------------|---------------------------------------|
| bootparam_sa0.srec | H'EB200000 | H'000000 | Loader (Boot parameter) |
| icumxa_loader.srec | H'EB300000 | H'040000 | Loader |
| cert_header_sa17.srec | H'EB200000 | H'440000 | Loader (Certification) |
| dummy_fw.srec | H'EB380000 | H'480000 | Dummy FW (instead of secure firmware) |
| dummy_rtos.srec | H'EB200000 | H'580000 | Dummy RTOS (instead of CR52 main OS) |
| bl31-falcon.srec (or smoni.srec) | H'46400000 | H'680000 | BL31 ATF (or Secure Monitor) |
| u-boot-elf-falcon.srec | H'50000000 | H'780000 | U-boot |

Condor, Condor-I board case:

Folder path: /os/bootloader/(v3h1 or v3h2)/(atf or smoni)/

| Filename | Program Top Address | Flash Save Address | Description |
|-------------------------------------|---------------------|--------------------|---------------------------------------|
| bootparam_sa0.srec | H'EB200000 | H'000000 | Loader (Boot parameter) |
| icumxa_loader.srec | H'EB2D8000 | H'040000 | Loader |
| dummy_fw.srec | H'EB2B4000 | H'0C0000 | Dummy FW (instead of secure firmware) |
| cert_header_sa6.srec | H'EB200000 | H'180000 | Loader (Certification) |
| dummy_rtos.srec | H'EB200000 | H'1C0000 | Dummy RTOS (instead of CR7 main OS) |
| bl31-condor.srec (or smoni.srec) | H'46400000 | H'2C0000 | BL31 ATF (or Secure Monitor) |
| u-boot-elf-condor.srec | H'50000000 | H'840000 | U-boot |

CONFIDENTIAL

Starter Kit V3H case:

Folder path: /os/bootloader/(v3h1 or v3h2)/(atf or smoni)/

| Filename | Program Top Address | Flash Save Address | Description |
|-----------------------|---------------------|--------------------|---------------------------------------|
| bootparam_sa0.srec | H'EB200000 | H'000000 | Loader (Boot parameter) |
| icumxa_loader.srec | H'EB2D8000 | H'040000 | Loader |
| dummy_fw.srec | H'EB2B4000 | H'0C0000 | Dummy FW (instead of secure firmware) |
| cert_header_sa6.srec | H'EB200000 | H'180000 | Loader (Certification) |
| dummy_rtos.srec | H'EB200000 | H'1C0000 | Dummy RTOS (instead of CR7 main OS) |
| bl31-condor.srec (*1) | H'46400000 | H'2C0000 | BL31 ATF (*1) |
| u-boot-elf-v3hsk.srec | H'50000000 | H'840000 | U-boot |

Note: Only “rcar-xos_s240918-axa-1_v1.x.0_release”, use Secure Monitor (smoni.srec))

Eagle board case:

Folder path: /os/bootloader/v3m2/(atf or smoni)/

| Filename | Program Top Address | Flash Save Address | Description |
|------------------------------------|---------------------|--------------------|-------------------------------------|
| bootparam_sa0.srec | H'E6320000 | H'000000 | Loader (Boot parameter) |
| cr7_loader.srec | H'E6304000 | H'040000 | Loader |
| cert_header_sa3.srec | H'E6320000 | H'0C0000 | Loader (Certification) |
| bl31-eagle.srec (or smoni.srec) | H'46400000 | H'2C0000 | BL31 ATF (or Secure Monitor) |
| dummy_rtos.srec | H'42220800 | H'1C0000 | Dummy RTOS (instead of CR7 main OS) |
| u-boot-elf-eagle.srec | H'50000000 | H'840000 | U-boot |

Starter Kit V3M case:

Folder path: /os/bootloader/v3m2/atf/

| Filename | Program Top Address | Flash Save Address | Description |
|-----------------------|---------------------|--------------------|-------------------------------------|
| bootparam_sa0.srec | H'E6320000 | H'000000 | Loader (Boot parameter) |
| cr7_loader_v3msk.srec | H'E6304000 | H'040000 | Loader |
| cert_header_sa3.srec | H'E6320000 | H'0C0000 | Loader (Certification) |
| bl31-eagle.srec | H'46400000 | H'2C0000 | BL31 ATF |
| dummy_rtos.srec | H'42220800 | H'1C0000 | Dummy RTOS (instead of CR7 main OS) |
| u-boot-elf-v3msk.srec | H'50000000 | H'840000 | U-boot |

(5-2) Using xls2 command to write

The following is writing “FALCON bootparam_sa0.srec case” on (5-1) Writing data table.

(a) Input “xls2” command.

```
>xls2
```

Windows PC for terminal software

The following log is output.

```
===== Qspi/HyperFlash writing of Gen3 Board Command =====
```

Windows PC for terminal software

```
Load Program to Spiflash
```

```
Writes to any of SPI address.
```

```
Please select,FlashMemory.
```

```
1 : QspiFlash_512Mbit (U6 : S25FS512S)
```

```
2 : QspiFlash Board (CN3: S25FS512S)
```

```
3 : HyperFlash (U26: S26KS512S)
```

```
Select (1-3)>
```

(b) Select, 512-Mbit SPI flash. The following is FALCON case.

```
Select (1-3)>1
```

Windows PC for terminal software

The following log is output.

```
READ ID OK.
```

Windows PC for terminal software

```
Program Top Address & Qspi/HyperFlash Save Address
```

```
===== Please Input Program Top Address =====
```

```
Please Input : H'
```


CONFIDENTIAL

(c) Input Program Top Address of the target file on (5-1) Writing data table

> EB200000

Windows PC for terminal software

The following log is output.

===== Please Input Qspi/HyperFlash Save Address =====

Windows PC for terminal software

Please Input : H'

(d) Input Qspi/HyperFlash Save Address of the target file on (5-1) Writing data table

> 0

Windows PC for terminal software

The following log is output.

Work RAM(H'50000000-H'53FFFFFF) Clear....

Windows PC for terminal software

please send ! ('.' & CR stop load)

(e) Drag and drop the target file on the table of (5-1) Writing data

The following log is output. ("bootparam_sa0.srec" case)

SPI Data Clear(H'FF) Check :H'00000000-0003FFFF,Clear OK?(y/n)

Windows PC for terminal software

Push "y"key

>y

Windows PC for terminal software

H'00000000-H'00007FFF Erasing.

Windows PC for terminal software

.....Erase Completed

H'00000000-0003FFFF Erasing..Erase Completed

SAVE SPI-FLASH..... complete!

CONFIDENTIAL

(f) Repeat (a)-(e) until you complete writing each S-record format images of loaders

(5-3) After write to images, power off target board.

(5-4) Return the switches which were changed on Step1 to the switches on Chapter.2.2.

5. Confirm starting of U-Boot and Linux

Please refer to 2.2 for dip switch setting then follow the steps below

Step 1 set file system and store kernel image + dtb

```
$ mkdir /export/rfs  
$ cd /export/rfs
```

Linux Host PC

Please store file system (rcar-image-adas-{SoC}.tar.bz2) to /export/rfs directory of NFS server, and extract it as follows.

```
$ sudo tar xvf rcar-image-adas-${SoC}.tar.bz2
```

Linux Host PC

Note) \${SoC} is v3u in case of V3U, v3x in case of V3H/V3M.

Please store kernel Image and device tree binaries (.dtb) to /srv/tftp of TFTP server

Step 2 Set U-Boot environment variables

Please refer to 2.2 for dip switch setting.

Please start U-Boot by board reset. Please set and save environment variable as follows.

```
=> setenv ethaddr xx:xx:xx:xx:xx:xx  
=> setenv ipaddr 192.168.0.20  
=> setenv serverip 192.168.0.1  
=> setenv bootcmd 'tftp 0x48080000 Image;tftp 0x48000000  
<Device_Tree>;booti 0x48080000 - 0x48000000'
```

Windows PC for terminal software

Note) For R-Car V3U (r8a779a0), the <Device_Tree> are as follows:

- r8a779a0-falcon.dtb: for R-Car V3U Ver.1.0 on Falcon board.

For R-Car V3H (r8a77980), the <Device_Tree> are as follows:

- r8a77980-es2-condor.dtb: for R-Car V3H Ver.2.0 on Condor-I board.
- r8a77980-condor.dtb: for R-Car V3H Ver.1.1 on Condor board.
- r8a77980-es2-v3hsk.dtb: for R-Car V3H Ver.2.0 on Starter Kit.
- r8a77980-v3hsk.dtb: for R-Car V3H Ver.1.1 on Starter Kit.

For R-Car V3M (r8a77970), the <Device_Tree> are as follows:

CONFIDENTIAL

- r8a77970-eagle.dtb: for R-Car V3M Ver.2.0 on Eagle board.
- r8a77970-v3msk.dtb: for R-Car V3M Ver.2.0 on Starter Kit board.

Step 3 change the bootargs by U-Boot

To change bootargs which is passed to the kernel in boot sequence, please modify it by “setenv bootargs” command of U-Boot. Below command means mount the root file system as read/write option via NFS server whose server IP is 192.168.0.1, root directory is /export/rfs and the client IP is 192.168.0.20

Windows PC for terminal software

```
=> setenv bootargs 'rw root=/dev/nfs nfsroot=192.168.0.1:/export/rfs  
ip=192.168.0.20 cma=560M'
```

Step 4 save environment variables to save persistent storage

By the "saveenv" command, we do not need to execute Step5-Step7 for next time.

```
=> saveenv
```

Windows PC for terminal software

Step 5 start Linux

After board reset, U-Boot is started. After countdown, Linux boot messages are displayed. Please confirm login prompt after Linux boot messages.

Appendix:

How to install TFTP server and NFS server

How to install TFTP server

Note: make sure you are **connected to the internet**. If there is an error, try `apt update -y` to update your application repository database.

1. Install tftpd-hpa with sudo privilege

```
$ sudo apt install tftpd-hpa -y
```

Linux Host PC

Note: -y flag means to assume yes and silently install, without asking you questions in most cases.

Once the installation is complete, you will be able to download files from the TFTP server.

The default configuration file for tftpd-hpa is /etc/default/tftpd-hpa.

The default root directory where files will be stored is /srv/tftp

If you want to upload to the TFTP server, please continue next step.

2. Edit tftpd-hpa configuration file

```
$ sudo vi /etc/default/tftpd-hpa
```

Linux Host PC

And change the following line to give R/W permission to TFTP_DIRECTORY folder:

[Old] `TFTP_OPTIONS="--secure"`

[New] `TFTP_OPTIONS="--secure --create"`

and save the file and exit the vi editor.

3. Restart the tftpd-hpa Service

To make the changes take effect, the tftpd-hpa service must be restarted. This can be accomplished by performing the following command.

```
$ sudo service tftpd-hpa restart
```

Linux Host PC

At this point you should now have a TFTP server that allows you to both download and upload files.

How to install NFS server

To boot an embedded system over NFS, an NFS server must be available on the local network. First, we need to install the NFS server. Once the server has been installed, export a directory to use as the root filesystem. This is often done using the `/etc/exports` file. This document assumes that the root filesystem for the board will be located at `/export/rfs` on the NFS server.

Note: make sure you are **connected to the internet**. If there is an error, try `apt update -y` to update your application repository database.

1. Install the NFS kernel server package and rpcbind. with sudo privilege

```
$ sudo apt install nfs-kernel-server
$ sudo apt install rpcbind
```

Linux Host PC

This installs additional packages such as keyutils, nfs-common, rpcbind, and other dependencies required for the NFS server to function as expected.

2. Configuring the NFS Server

The NFS server's shares are configured in the `/etc/exports` file. Each share takes a list of option names to configure its behavior. Before configuring the NFS server, the following decisions need to be made (and a list of options created) based on the intended use(s) of the NFS share being created:

- Do NFS clients need the ability to write to the NFS share? If so, it needs to be exported `rw`. Otherwise, export it as `ro`
- If the filesystem will be writeable, is performance or data integrity more important? If performance, `async` will provide more performance at the risk of lost or corrupt data should the NFS server shut down unexpectedly during a write operation. Otherwise, `sync` should be used.
- Is reliability or security more important? If reliability is, use `no_subtree_check`. Otherwise, use `subtree_check`.
- Is user level access control required? If not, getting the NFS server working is much simpler with the `no_root_squash` option.

Here is an example of the `/etc/exports` file that to export the `/export/rfs` directory to all machines, writeable, with reliability and performance options turned on

```
$ sudo vi /etc/exports
```

Linux Host PC

And modify as follow

```
/export/rfs *(rw,async,no_root_squash)
```

3. Notify the NFS server after making any changes to the export file

```
$ exportfs -a
```

Linux Host PC

4. Activate NFSv2

```
$ sudo vi /etc/default/nfs-kernel-server
```

Linux Host PC

And add as follow

```
RPCNFSDOPTS="$RPCNFSDOPTS -v 2"
```

5. Restart the nfs Service

```
$ sudo service nfs-kernel-server restart
```


Linux Host PC

Now users can configure the Client to boot from NFS server.

How to set IP address to Linux Host PC

In this case, we confirm with USB3.0 Gigabit LAN adapter.

1. Open Ubuntu > Settings > Network > USB Ethernet > “Identity” Tab



2. Select target MAC address which can be check with “lsusb” and “ip add” command.
3. Select “IPv4” tab > “IPv4 Method > Manual”.

Set as follows.

| Address | Netmask | Getway |
|-------------|---------------|---------|
| 192.168.0.1 | 255.255.255.0 | 0.0.0.0 |

3. Click “Add” and reboot Linux Host PC.

Exporting Toolchains

Please refer Documents from Yocto Project to export Toolchains such as

<https://www.yoctoproject.org/docs/3.1.3/sdk-manual/sdk-manual.html>.

And please use build target of bitbake as “rcar-image-adas -c populate_sdk” to generate package.

Note) When you use “ld” directly but not via gcc (in case of building Kernel, Driver or U-Boot), please disable LDFLAGS with ‘unset LDFLAGS’. Furthermore, in kernel build, ‘make menuconfig’ occurs error by ncurses. In this case, please set PKG_CONFIG_PATH and disable PKG_CONFIG_SYSROOT_DIR.

Linux Host PC

```
$ export PKG_CONFIG_PATH=$OECORE_NATIVE_SYSROOT/usr/lib/pkgconfig
$ unset PKG_CONFIG_SYSROOT_DIR
```

Note) Please do not use same shell environment to other compilation/debugging purpose (also make menuconfig of linux kernel, e.g.) but cross compilation for R-Car V3U/V3H/V3M which shell environment with “source” command to setup environment variables for the SDK. Because some environment variables for cross compilation interferes execution of other tools on the same shell environment.

Example of instruction:

In following examples, it’s assumed that it’s already extracted and prepared recipe environment such as in the instructions of Section 3 (must done just before execution of bitbake, at least). You may reuse \${WORK}/build while you reuse same configuration after executing bitbake as in Section 3 for this purpose.

Step 1 configure architectures of Host PC which are installed this toolchain

Please modify SDKMACHINE description on \${WORK}/build/conf/local.conf.

On \${WORK}/build/conf/local.conf

```
# SDK target architecture
#
# This variable specifies the architecture to build SDK items for and means
# you can build the SDK packages for architectures other than the machine you are
# running the build on (i.e. building i686 packages on an x86_64 host).
# Supported values are i686 and x86_64
SDKMACHINE ?= "x86_64"
```

Note) 32bit Ubuntu 14.04 is not supported.

Step 2 building toolchain package with bitbake

Linux Host PC

```
$ cd ${WORK}/build
$ bitbake rcar-image-adas -c populate_sdk
$ cp tmp/deploy/sdk/poky-glibc-x86_64-rcar-image-adas-aarch64-${SoC}-
toolchain-3.1.3.sh (shared dir. where able to access from each Host PCs)
```

Note) \${SoC} is v3u in case of V3U, v3x in case of V3H/V3M.

Note) Please perform “bitbake rcar-image-minimal -c populate_sdk” in BSP Only.

Step 3 Install toolchain on each Host PCs

Linux Host PC

```
$ sudo (shared dir. where able to access from each Host PCs)/poky-glibc-x86_64-rcar-image-adas-aarch64-  
-<board name>-toolchain-3.1.3.sh
```

```
[sudo] password for (INSTALL person): (password of your account)  
Enter target directory for SDK (default: /opt/poky/3.1.3): (just a return)  
Extracting SDK...done  
Setting it up...done  
SDK has been successfully set up and is ready to be used.
```

Step 4 setup environment variables for each compilation on each Host PCs

Please setup environment variables as follows or integrate set-up sequence into your build script or Makefile.

Linux Host PC

```
$ cd (Your working directory)  
$ source /opt/poky/3.1.3/environment-setup-aarch64-poky-linux  
$ export LDFLAGS=""  
$ ${CC} (Your source code).c ...
```

Note for generating & using Windows SDK

Please do the following steps to create Windows SDK:

Step 1 prepare meta-mingw

Linux Host PC

```
$ cd ${WORK}  
$ git clone https://git.yoctoproject.org/git/meta-mingw  
$ cd meta-mingw  
$ git checkout -b tmp 524de686205b5d6736661d4532f5f98fee8589b7  
$ cd ${WORK}/build  
$ bitbake-layers add-layer ../meta-mingw/
```

Step 2 edit SDKMACHINE in local.conf

On \${WORK}/build/conf/local.conf

```
SDKMACHINE ?= "x86_64-mingw32"
```

Step 3 building toolchain (Windows SDK) package with bitbake

```
$ bitbake rcar-image-adas -c populate_sdk
```

Linux Host PC

After the build finished, the Windows SDK locates at `${WORK}/build/tmp/deploy/sdk` with the following files:

```
poky-glibc-x86_64-mingw32-rcar-image-adas-aarch64-${SoC}-toolchain-3.1.3.host.manifest
poky-glibc-x86_64-mingw32-rcar-image-adas-aarch64-${SoC}-toolchain-3.1.3.target.manifest
poky-glibc-x86_64-mingw32-rcar-image-adas-aarch64-${SoC}-toolchain-3.1.3.tar.xz (Windows SDK tarball)
poky-glibc-x86_64-mingw32-rcar-image-adas-aarch64-${SoC}-toolchain-3.1.3.testdata.json
```

Note) `${SoC}` is v3u in case of V3U, v3x in case of V3H/V3M.

Step 4 re-zip Windows SDK tarball to fix symlinks broken issue

```
$ windows_sdk="poky-glibc-x86_64-mingw32-rcar-image-adas-aarch64-
${SoC}-toolchain-3.1.3"
$ cd ${WORK}/build/tmp/deploy/sdk
$ tar -xf ${windows_sdk}.tar.xz -C ${windows_sdk}
$ zip -r ${windows_sdk}.zip ${windows_sdk}
```

Linux Host PC

Note) Please do the following steps to generate Windows SDK 7z format:

- 1) unzip Windows SDK zip on Windows PC.
- 2) Re-zip by 7z application.

In Step 1), warnings might occur, because Windows cannot distinguish between file names with upper case and lower case. So, please do not overwrite existing files, if asked.

Step 4 setup environment variables for each compilation on each Host PCs

On Windows cmd:

```
> cd %SDK_PATH%
> environment-setup-aarch64-poky-linux.bat
> %CC% --version
aarch64-poky-linux-gcc (GCC) 9.3.0
Copyright (C) 2019 Free Software Foundation, Inc.
This is free software; see the source for copying conditions. There is NO
warranty; not even for MERCHANTABILITY or FITNESS FOR A PARTICULAR
PURPOSE.
> %CC% <your source code>.c
```

Windows PC

Out-of-tree driver information

Out of tree drivers in **rcar-image-adas-v3x.tar.bz2** are as follows:

- CMEM driver:

/lib/modules/5.4.72-yocto-standard/extra/cmемdrv.ko
/usr/include/linux/cmемdrv.h

- MMNGR driver:

/lib/modules/5.4.72-yocto-standard/extra/mmngr.ko
/lib/modules/5.4.72-yocto-standard/extra/mmngrbuf.ko
/usr/lib/libmmngr.so
/usr/lib/libmmngrbuf.so
/usr/local/include/mmngr_buf_private_cmн.h
/usr/local/include/mmngr_buf_user_private.h
/usr/local/include/mmngr_buf_user_public.h
/usr/local/include/mmngr_private_cmн.h
/usr/local/include/mmngr_public_cmн.h
/usr/local/include/mmngr_user_private.h
/usr/local/include/mmngr_user_public.h

- QoS driver:

/lib/modules/5.4.72-yocto-standard/extra/qos.ko
/usr/lib/libqos.so
/bin/qos_tp
/include/qos_public.h
/include/qos_public_common.h

- CPU RTT driver for xOS1.1:

/lib/modules/5.4.72-yocto-standard/extra/cpurttmod.ko
/usr/local/include/cpurtt_common.h
/usr/local/include/cpurtt_common_userdef.h

- CPU RTT driver for xOS2:

/lib/modules/5.4.72-yocto-standard/extra/cpurttmod2_v3h2.ko
/lib/modules/5.4.72-yocto-standard/extra/cpurttmod2_v3h1.ko
/lib/modules/5.4.72-yocto-standard/extra/cpurttmod2_v3m2.ko
/usr/local/include/cpurttmod2_v3m2/cpurtt_common.h
/usr/local/include/cpurttmod2_v3h1/cpurtt_common.h
/usr/local/include/cpurttmod2_v3h2/cpurtt_common.h

Out of tree drivers in **rcar-image-adas-v3u.tar.bz2** are as follows:

- CMEM driver:

/lib/modules/5.4.72-yocto-standard/extra/cmемdrv.ko
/usr/include/linux/cmемdrv.h

- MMNGR driver:

/lib/modules/5.4.72-yocto-standard/extra/mmngr.ko
/lib/modules/5.4.72-yocto-standard/extra/mmngrbuf.ko

/usr/lib/libmmngr.so
/usr/lib/libmmngrbuf.so
/usr/local/include/mmngr_buf_private_cmn.h
/usr/local/include/mmngr_buf_user_private.h
/usr/local/include/mmngr_buf_user_public.h
/usr/local/include/mmngr_private_cmn.h
/usr/local/include/mmngr_public_cmn.h
/usr/local/include/mmngr_user_private.h
/usr/local/include/mmngr_user_public.h

- QoS driver:

/lib/modules/5.4.72-yocto-standard/extra/qos.ko
/usr/lib/libqos.so
/bin/qos_tp
/include/qos_public.h
/include/qos_public_common.h

CONFIDENTIAL

| REVISION HISTORY | | Linux Interface Specification Yocto recipe Start-Up Guide User's Manual: Software | |
|------------------|---------------|--|---|
| Rev. | Date | Description | |
| | | Page | Summary |
| 4.4.0 | Sep 30, 2020 | — | First Edition for Yocto Recipe Package with YP3.1, based on Start-Up Guide Rev 4.1.0 |
| 4.7.0 | Dec 24, 2020 | — | Added V3H information |
| | | 2 | Updated reference versions Added "R-Car Series, 3rd Generation User's Manual: Hardware Rev.1.50" |
| | | 3 | Table 1 Updated VCP driver information |
| | | 5 | Table 2 Updated setting of Dip switches for V3U Falcon according to "R-CarV3U System Evaluation Board FALCON Setup Manual Rev.0.07" |
| | | 6 | Table 3 Added setting of Dip switches (R-Car V3H Condor-I) |
| | | 7 | Step 1 Updated required packages according to YP3.1.3 |
| | | 8 | Step 3 Updated Commit ID, and the Notice for V3U |
| | | 9-10 | Step 5 Updated path to sample configuration files |
| | | 12-13 | Step 5 Added R-Car V3H device tree information |
| | | 14-15 | Updated SDK information for YP3.1.3 |
| 4.9.0 | Feb 26, 2021 | 5 - 6 | Updated Dip switch setting information |
| | | 8 | Step 3 Updated Commit ID, and the Notice for V3U |
| | | 12 | Step 4 Updated U-Boot Flash Save Address for V3U and V3H |
| | | 13, 15 | Added note for build output of Condor |
| 4.10.0 | Mar 31, 2021 | — | Added V3M information Added Ubuntu version 20.04 LTS |
| | | 2 | Updated reference information |
| | | 3 | Added Eagle board driver information |
| | | 4-8 | 2.2 Added Eagle/Condor dip switch setting. |
| | | 10 | Step 3 Updated Commit ID NOTICE for V3U Added patch "0004-media-rcar-vin-Remove-reset-function.patch" |
| | | 11,12 | Added Eagle board, improved guideline |
| | | 13 | Added "3.3 Creating CRC checksum of root filesystem (*.wic.gz.crc)" |
| | | 17-19 | "6. Exporting Toolchains" Added Windows SDK information |
| 4.11.1 | Apr 27, 2021 | — | Added V3H Starter Kit information |
| | | 10 | Step 3 Updated Commit ID |
| | | 15 | Step 4 Update Flash Save Address of V3U (Falcon board) |
| 4.11.2 | Apr 27, 2021 | 10 | Step 3 Updated Commit ID |
| 4.12.0 | May 28, 2021 | — | Removed "3.3 Creating CRC checksum of root filesystem (*.wic.gz.crc)" Removed Ubuntu 16.04 information |
| | | 9 | Step 1 Added libarchive-zip-perl which provides crc32 command |
| | | 10 | Step 3 Updated Commit ID Remove "0004-media-rcar-vin-Remove-reset-function.patch" |
| 4.13.1 | June 30, 2021 | 2 | Add a flowchart for using this Start Up Guide |
| | | 3 | Article 1.1: Add document name |
| | | 4 | Chapter 2: Add explanation of TFTP server and NFS server, IP address, MAC address |
| | | 7-16 | Add board picture from Set Up guide. |

CONFIDENTIAL

| | | | |
|--------|---------------|--------|---|
| | | 17-19 | Chapter 3: Add flowchart for Yocto build instruction and build script, remove additional VIN driver patch and MAX96712.cfg file |
| | | 22-29 | Chapter 4: Add writing boot loaders and U-boot |
| | | 32-35 | Guideline how to set up TFTP server, NFS server, IP address |
| 4.14.0 | July 30, 2021 | 3 | Add R-Car V3M Starter Kit HW Manual |
| | | 18 | Add setting dip switches for V3M Starter Kit |
| | | 20, 21 | Add V3M Starter Kit device tree and U-boot |
| | | 24 | Update Flash write manual reference |
| | | 26 | Update V3U flash writer name |
| | | 25, 29 | Add writing boot loaders and u-boot for V3M Starter Kit |
| | | 34 | Add device tree for V3M Ver.2.0 on Starter Kit board |
| 4.15.0 | Aug 27, 2021 | 6 | Add internet connection for Linux host PC |
| | | 19 | Add note to use clean build directory |
| | | 20 | Add u-boot-elf-eagle-function.srec (For Eagle Function board V3M) |
| 4.16.0 | Sep 24, 2021 | 1,2 | Update flowchart, add out-of-tree drivers note. |
| | | 19,20 | Add device tree of Starter Kit and Video Box Mini |
| | | 39 | Add information of out-of-tree kernel modules |
| 4.19.0 | Dec 24, 2021 | 31 | Add cma=560M option to bootargs |
| 4.19.1 | Dec 24, 2021 | 20 | Update github urls to https protocol |

CONFIDENTIAL

Linux Interface Specification Yocto recipe Start-Up Guide
User's Manual: Software

Publication Date: February 25, 2022 Rev.4.19.2

Published by: Renesas Electronics Corporation



SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics Corporation

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

Renesas Electronics America Inc. Milpitas Campus

1001 Murphy Ranch Road, Milpitas, CA 95035, U.S.A.
Tel: +1-408-432-8888, Fax: +1-408-434-5351

Renesas Electronics America Inc. San Jose Campus

6024 Silver Creek Valley Road, San Jose, CA 95138, USA
Tel: +1-408-284-8200, Fax: +1-408-284-2775

Renesas Electronics Canada Limited

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3
Tel: +1-905-237-2004

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany
Tel: +49-211-6503-0, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.

Room 101-T01, Floor 1, Building 7, Yard No. 7, 8th Street, Shangdi, Haidian District, Beijing 100085, China
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai 200333, China
Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

Renesas Electronics Hong Kong Limited

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2265-6688, Fax: +852 2886-9022

Renesas Electronics Taiwan Co., Ltd.

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan
Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd.

80 Bendemeer Road, #06-02 Singapore 339949
Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd.

Unit No 3A-1 Level 3A Tower 8 UOA Business Park, No 1 Jalan Pengaturcara U1/51A, Seksyen U1, 40150 Shah Alam, Selangor, Malaysia
Tel: +60-3-5022-1288, Fax: +60-3-5022-1290

Renesas Electronics India Pvt. Ltd.

No.777C, 100 Feet Road, HAL 2nd Stage, Indiranagar, Bangalore 560 038, India
Tel: +91-80-67208700

Renesas Electronics Korea Co., Ltd.

17F, KAMCO Yangjae Tower, 262, Gangnam-daero, Gangnam-gu, Seoul, 06265 Korea
Tel: +82-2-558-3737, Fax: +82-2-558-5338



ルネサスエレクトロニクス株式会社

■営業お問合せ窓口

<http://www.renesas.com>

※営業お問合せ窓口の住所は変更になることがあります。最新情報につきましては、弊社ホームページをご覧ください。

ルネサス エレクトロニクス株式会社 〒135-0061 東京都江東区豊洲3-2-24（豊洲フォレシア）

■技術的なお問合せおよび資料のご請求は下記へどうぞ。
総合お問合せ窓口：<https://www.renesas.com/contact/>

Linux Interface Specification Yocto recipe Start-Up Guide



Renesas Electronics Corporation