




1. Torque series MD8 interface definition



| Pin | Description |
|-----|--------------------|
| 1 | RS232 Transmit(TX) |
| 2 | RS232 Receive(RX) |
| 3 | RS232 Ground |
| 4 | Output A+ |
| 5 | Reserved |
| 6 | Output COM- |
| 7 | Output B+ |
| 8 | Reserved |

When RS232 is used for serial communication, refer to the above pin definition, where pin 1 is the sending end of the dynamometer, which can be connected to the receiving end of the user device RS232; pin 2 is the receiving end of the dynamometer, which can be connected to the sending end of the user device RS232; pin 3 is the GND of the dynamometer RS232, which is connected to the GND of the user device.

There are a variety of MD8 wire options:



2. Baud rate setting

The torque series uses 38400 bps by default, the other Settings are set to stop bit 1, data bit 8, and parity none.

3. Communication command

| Communication command (hexadecimal) | Instruction effect |
|--|---|
| 0x3F | Returns a real-time value |
| 0x50 0x5A 0x00 | Zero clearing, serial return 0x52 0x06 |
| 0x3F 0x43 0x01 | Returns a display value |
| 0x3F 0x43 0x02 | Data is returned continuously at the rate of 10 times per second |
| 0x3F 0x43 0x03 | Data is returned continuously at the rate of 20 times per second |
| 0x3F 0x43 0x04 | Data is returned continuously at the rate of 50 times per second |
| 0x3F 0x43 0x05 | Data is returned continuously at the rate of 100 times per second |
| 0x3F 0x43 0xff | Terminate continuous return instruction |
| 0x53 0x50 0x01 | Set the unit to N.m, serial return 0x52 0x50 0x01 |
| 0x53 0x50 0x02 | Set the unit to N.cm, serial return 0x52 0x50 0x02 |
| 0x53 0x50 0x03 | Set the unit to kgf.m, serial return 0x52 0x50 0x03 |
| 0x53 0x50 0x04 | Set the unit to kgf.cm, serial return 0x52 0x50 0x04 |
| 0x53 0x50 0x05 | Set the unit to lbf.ft, serial return 0x52 0x50 0x05 |
| 0x53 0x50 0x06 | Set the unit to lbf.in, serial return 0x52 0x50 0x06 |
| 0x53 0x50 0x07 | Set the unit to N.mm, serial return 0x52 0x50 0x07 |

The above table is the torque series communication commands, the left side is the command sent by the user device, and the right side is the status of the torque series after receiving the command.

For example, if the user device sends 0x3F, the torque series immediately returns the real-time value of the torque series after receiving the command, and the returned data is in the string format: for example, -2.3456 N.m.

For setting unit instructions, if there is no such unit in the current range, keep the current unit.