



---

# SOFTWARE USER GUIDE FOR RANX50-02 CAT-B O-RUs

---

June 2022

Benetel Ltd, Guinness  
Enterprise Centre, Taylor's  
Lane, Dublin 08 F9FV, Ireland  
+353 1 4100 890  
[support@benetel.com](mailto:support@benetel.com)

# Copyright Information

## **Copyright © 2022 Benetel Ltd. All rights reserved**

This documentation and the information contained herein are the property of Benetel Ltd. This publication may be used, copied, or distributed only in accordance with the terms of the license agreement. Any other use, reproduction, or distribution may occur only upon prior written consent from Benetel Ltd.

## **Disclaimer and Restrictions**

The material in this publication is for information only and is subject to change without notice. This material does not constitute a commitment on the part of Benetel Ltd.

While reasonable efforts have been made in the preparation of this publication to ensure its accuracy, Benetel Ltd. assumes no liability resulting from technical or editorial errors or omissions, or for any damages whatsoever (including, but not limited to, incidental, special, or consequential damages) resulting from the furnishing, performance, or use of the information contained herein.

Benetel Ltd. reserves the right to revise this publication, and to make changes to the content hereof without notice.

The information in this document may be used by customers solely for the use and understanding of Benetel Ltd. products and solutions.

This document is not meant to define an interface between Benetel Ltd. products and any third-party hardware or software.

Benetel Ltd. reserves the right to change the design and implementation used for any of the tables, screens, field names, and so on to enhance its products as it sees fit.

## **Warranties**

THIS INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT.

REFERENCES TO COMPANIES, THEIR SERVICES AND PRODUCTS, ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED. IN NO EVENT SHALL BENETEL LTD. BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER OR NOT ADVISED OF THE POSSIBILITY OF DAMAGE, AND ON ANY THEORY OF LIABILITY, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS INFORMATION.

Descriptions of, or references to, products, services or publications within Benetel Ltd. documentation do not imply endorsement of that product, service, or publication. Benetel Ltd. makes no warranty of any kind with respect to the subject matter included herein, the products listed herein, or the completeness or accuracy of the information. Benetel Ltd. specifically disclaims all warranties, express, implied or otherwise, including without limitation, all warranties of merchantability and fitness for a particular purpose.

## **Trademarks**

Benetel and the Benetel logo, are either registered trademarks or trademarks of Benetel Ltd. These Benetel Ltd. trademarks may not be used in connection with any product or service that does not originate from Benetel Ltd. or in any manner that is likely to cause confusion among customers or in any manner that disparages or discredits Benetel Ltd.

All other product names mentioned herein are trademarks, service marks, registered trademarks, or registered service marks of their respective owners.

## **Compliance with Applicable Laws and Export Control Laws**

Use of the information in this publication is governed by all applicable, EU and local laws. All information available in this publication may also be subject to the laws of the country where you reside.

Benetel Ltd. makes no representation that the content in this manual is appropriate or available for use in other locations.

## *Software User Guide for RANx50-02 CAT-B O-RUs*

This guide outlines the steps necessary to run either the Benetel RAN550 or RAN650 CAT-B O-RUs with Phluido Upper-L1 (UL1).

### **Qualified Personnel**

This guide is for use only by suitably qualified personnel with experience in radio unit deployment and operation. The document provides guidance for such trained personnel but the execution of these two supported modes remains the responsibility of the User with the support of their UL1 and L2/L3 partners

## Contents

1.	Introduction .....	7
2.	Reference Documentation .....	7
3.	Handling Information .....	7
4.	Waste Electrical and Electronic Equipment (WEEE) .....	7
5.	Initial Power-up and O-DU connection .....	8
5.1	Initial O-DU to O-RU connections .....	8
5.2	Sync & Radio Configuration .....	10
5.3	System Configuration Verification .....	12
5.4	O-RU Sync Status – GPS or Ext 1PPS Query .....	14
5.5	O-RU Sync Status – PTP .....	15
5.6	RF Power Adjustment .....	16
5.7	RF Frequency Adjustment.....	16
6.	O-RU Bring Up – Phluido & Effnet Binary Execution Check .....	17
6.1	DU MAC Address configuration .....	17
6.2	Phluido UL1 Execution .....	17
6.3	TestMAC Execution .....	18
6.4	Benetel O-RU Handshake.....	18
6.5	Benetel O-RU Bring Up Complete .....	20
6.6	User Network Configuration .....	20
7.	Appendix 1: EEPROM Configuration .....	21
7.1	EEPROM Parameter Query .....	21
7.2	EEPROM Parameter Write .....	22
7.3	O-RU MAC Address .....	23
7.4	O-RU IP Address.....	24
7.5	O-RU UDP Port Number .....	24
7.6	O-RU ADV IP Checksum .....	24
7.7	O-RU RSP IP Checksum .....	24
7.8	O-RU UPLINK IP Checksum.....	25
7.9	O-DU MAC Address.....	25
7.10	O-DU IP Address.....	25
7.11	O-DU UDP Port Number.....	25
7.12	O-DU IP Checksum .....	26
7.13	O-RU Software Load Query.....	27
7.14	O-RU Sync Status.....	27
7.15	IP Address CheckSum Reference .....	28
7.16	Read & Adjust Tx Frequency Settings .....	29
7.17	Read & Adjust Rx Frequency Settings.....	30
7.18	Read & Adjust Tx1 Attn Settings .....	30
7.19	Read & Adjust Tx3 Attn Settings .....	31
8.	Appendix 2: Sample EEPROM Write .....	32

Table of Figures

Figure 1: Confirmed fronthaul conection between O-RU and O-DU ..... 8

Figure 2: Expected response to “radiocontrol -o G a” ..... 13

Figure 3: Expected response to “radiocontrol -o D s” ..... 13

Figure 4: Expected response to “reportRuStatus” ..... 14

## Personal and Product Safety

### Electrical

The product is designed to operate from a -48 V DC supply and is therefore classified as Safe Extra Low Voltage (SELV) equipment. All structural parts are grounded and all input and outputs have built-in isolation from the network. All input and output ports that connect to external power sources are designed to meet relevant national safety requirements. The product contains hazardous energy levels as defined by EN 60950. Care must be taken when maintaining this equipment as injury to personnel or damage to the equipment could result from mistakes. Maintenance should only be carried out by trained and competent engineers who are familiar with the relevant procedures and instructions.

### Lasers

The product is fitted with optical modules rated as Class 1 radiation-emitting devices under EN 60825-1. During installation, operation, and maintenance, never look into the end of an optical fibre directly or by reflection either with the naked eye or through an optical instrument. Do not operate equipment with exposed fibre connectors-cover these with fibre cables or blanking caps. Do not remove equipment covers during operation unless requested to do so in the documentation. Carry out normal safety precautions when trimming fibres during installation.

### Manual Handling

Care should be taken when handling equipment. Give due consideration to the weight of the equipment, the physical capability of the individual(s) handling the equipment, and movements such as twisting, bending and stooping, which could lead to skeletal and muscular injuries.

### Installation

Installation must be carried out by trained and competent engineers only. All relevant safety measures should be taken to ensure equipment is not connected to live power and transmission sources during installation. Equipment must be correctly installed in order to meet the relevant safety standards and approval conditions. Each power feed to the unit requires a separate fused feed from the provided power supply.

### Maintenance

Maintenance must only be carried out by a suitably trained and competent technician. All safety instructions must be carefully observed at all times. Equipment covers should not be removed while live power and transmission is connected unless in a controlled environment by trained technicians.

### Fire

The RAN650 product is powered from a -48 V DC supply. To protect against fire, the equipment is fused.

### Environment

The product must be operated in an environment with the specified relative humidity and ambient temperature ranges. Keep all liquids away from the equipment as accidental spillage can cause severe damage.

### Cooling

The product is natural convection cooling type.

## Anti-Static Precautions

The circuit boards and other modules in the product are sensitive to and easily damaged by static electricity. If any card or sub-assembly is removed from the unit, the following anti-static precautions must be observed at all times:

- Service personnel must wear anti-static wrist straps.
- Circuit boards and sub-assemblies must be placed on ground conductive mats or in conductive bags.
- All tools must be discharged to ground before use.
- The anti-static wrist strap and cord must be checked at regular intervals for their suitability for use.

## Grounding

To comply with EN 60950, the equipment must be connected to a safety grounding point via a permanent link. Grounding points are located on the product for this purpose. Always connect the ground cable before fitting other cables. The product must remain grounded continuously unless all connections to the power supply and data network are all removed. If equipment is grounded through a cabinet or rack, make sure it is done so properly according to the installation instructions.

## Power Supply Connection

The RAN650 equipment is designed to be powered from a -48 V DC supply.

The RAN550 equipment is designed to be powered from a +12 V DC supply.

## 1. Introduction

This document will guide the user through the bring up of the RAN550 or RAN650 CAT-B O-RU and the execution of the TestMAC Execution & Verification.

### NOTES:

1. For full End to End integration, the User should contact Phluido support and/or the relevant L2/L3 vendors
2. TestMAC Execution requires previous installation of Phluido and Effnet binaries, Benetel does not share these binaries

## 2. Reference Documentation

- [1] RAN650 Install and Bring up Guide Rev 2.0.pdf
- [2] RAN550 Install and Bring up Guide Rev 2.1.pdf

## 3. Handling Information

Handling Guidelines and ESD Warning



**ESD (Electrostatic Discharge) Sensitive Device.**

Charged devices and circuit boards can discharge without detection. Although this product features proprietary protection circuitry, damage may occur on devices subjected to higher energy ESD. Therefore, proper ESD precautions should be taken to avoid performance degradation or loss of functionality.

## 4. Waste Electrical and Electronic Equipment (WEEE)



### Business users in the European Union

For proper treatment, recovery and recycling, this product must be disposed of only in designated collection points. If you wish to discard this product, please contact your supplier for further information.

### Other Countries outside of the EU

If you wish to discard of this product, please contact your local authorities for the correct method of disposal. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.



## 5. Initial Power-up and O-DU connection

Before starting this process it is assumed that the user has read, understood and configured the O-RU according to the relevant Installation and Bring Up Guide; RAN650<sup>[1]</sup> or RAN550<sup>[2]</sup>.

The O-RU automatically starts once power is applied.

The next section details how the user can connect to the O-RU ahead of connecting to the UL1 and L2/L3 layers.

### 5.1 Initial O-DU to O-RU connections

#### 5.1.1 Configuring DU NIC Card and initial SSH connection from O-DU

- The O-RU is configured by default with 10.10.0.100 as a static IP address
- To initiate SSH connection via fronthaul fibre to the O-RU, Benetel recommends setting the IP address of the fronthaul NIC on the DU to 10.10.0.1

```
root@epc:/home/labuser/RAN650-2_SystemTest# ifconfig eno4
eno4: flags=4095<UP,BROADCAST,ST,MULTICAST> mtu 9000
    inet 10.10.0.1 netmask 255.255.255.0 broadcast 10.10.0.255
    ether 00:1e:67:fd:f5:51 txqueuelen 1000 (Ethernet)
    RX packets 3930457399 bytes 10250567817689 (10.2 TB)
    RX errors 2 dropped 0 overruns 0 frame 2
    TX packets 110196831 bytes 426289788008 (426.2 GB)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
```

- Confirm the 10G link status by executing the command *ethtool* on server. Check the highlighted parameters below for the Ethernet NIC the RAN650 is connected to.

```
Settings for p3p2:
Supported ports: [ FIBRE ]
Supported link modes:  1000baseX/Full
                      1000baseSR/Full
Supported pause frame use: Symmetric
Supported auto-negotiation: Yes
Supported FEC modes: Not reported
Advertised link modes: 1000baseX/Full
                      1000baseSR/Full
Advertised pause frame use: No
Advertised auto-negotiation: Yes
Advertised FEC modes: Not reported
Speed: 10000Mb/s
Duplex: Full
Port: FIBRE
PHYAD: 0
Transceiver: internal
Auto-negotiation: off
Supports Wake-on: d
Wake-on: d
Current message level: 0x0000000f (15)
                      drv probe link timer
Link detected: yes
```

Figure 1: Confirmed fronthaul connection between O-RU and O-DU

**Tip:** If unable to establish a fronthaul link as above, then you may need to clear the SSH known hosts on the O-DU. Commands to resolve this are highlighted in yellow below.

This can be required if for example the O-DU was previously connected to O-RU's with the same IP address configured.

```

root@epc:/home/labuser/RAN650-2_SystemTest# ssh root@10.10.0.100
@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@
@    WARNING: REMOTE HOST IDENTIFICATION HAS CHANGED!     @
@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@
IT IS POSSIBLE THAT SOMEONE IS DOING SOMETHING NASTY!
Someone could be eavesdropping on you right now (man-in-the-middle attack)!
It is also possible that a host key has just been changed.
The fingerprint for the ECDSA key sent by the remote host is
SHA256:lkoWj4oLHpdZH9b++4zyzIoGej8+g3Y1bXwWSKWe4r0.
Please contact your system administrator.
Add correct host key in /root/.ssh/known_hosts to get rid of this message.
Offending ECDSA key in /root/.ssh/known_hosts:1
  remove with:
    ssh-keygen -f "/root/.ssh/known_hosts" -R "10.10.0.100"
ECDSA host key for 10.10.0.100 has changed and you have requested strict checking.
Host key verification failed.
root@epc:/home/labuser/RAN650-2_SystemTest#
root@epc:/home/labuser/RAN650-2_SystemTest#
root@epc:/home/labuser/RAN650-2_SystemTest#
root@epc:/home/labuser/RAN650-2_SystemTest#
root@epc:/home/labuser/RAN650-2_SystemTest#
root@epc:/home/labuser/RAN650-2_SystemTest# t#
root@epc:/home/labuser/RAN650-2_SystemTest# t# rm -f /root/.ssh/known_hosts
root@epc:/home/labuser/RAN650-2_SystemTest#
root@epc:/home/labuser/RAN650-2_SystemTest# t#
root@epc:/home/labuser/RAN650-2_SystemTest# t# ssh root@10.10.0.100
The authenticity of host '10.10.0.100 (10.10.0.100)' can't be established.
ECDSA key fingerprint is SHA256:lkoWj4oLHpdZH9b++4zyzIoGej8+g3Y1bXwWSKWe4r0.
Are you sure you want to continue connecting (yes/no)? yes
Warning: Permanently added '10.10.0.100' (ECDSA) to the list of known hosts.
Last login: Fri Feb  7 16:34:13 2020 from 10.10.0.1
root@benetelru:~#
root@benetelru:~#
root@benetelru:~#

```

The user will then be at the Linux prompt of the Benetel O-RU

```
Last login: Fri Feb 7 16:34:13 2020 from 10.10.0.1
root@benetelru:~#
root@benetelru:~#
root@benetelru:~#
root@benetelru:~#
```

The fibre transport link between O-DU and O-RU is now configured.

## 5.2 Sync & Radio Configuration

The O-RU is set to auto configuration mode and will automatically configure the radio to the settings summarised in below on each hard or soft boot up cycle.

**Radio Configuration:** 2 x 2  
**Centre Frequency:** 3751.68MHz  
**RAN550 Deployed Power:** 24dBm  
**RAN650 Deployed Power:** 35dBm  
**RAN550 Frequency Support:** 3300MHz to 3800MHz  
**RAN650 Frequency Support:** 3700MHz to 4200MHz

This boot up process takes approximately 5 minutes to complete.

**WARNING:** The User should not start any U-Plane traffic during this time

**WARNING:** The User should not execute any additional radiocontrol commands during this initialisation period

### 5.2.1 Time Sync Configuration & Verification

The RAN650 O-RU can only be configured for GPS at this time (PTP feature will following in a V0.6.0 release)

The RAN550 O-RU currently supports Ext 1PPS and PTP synchronisation

**IMPORTANT:** The O-RU will not proceed with Radio Initialisation if there is no valid Time Sync connected on boot up.

This can be confirmed by reading the *radio\_status* file in the */tmp/logs* directory:

```
cat /tmp/logs/radio_status
```

The following two screenshots show a passing and failing screenshot of Sync Status, it will attempt the sync three times before exiting to this error:

```
root@benetelru:~# cat /tmp/radio_status
[INFO] Platform: RAN650_B
[INFO] Frequency:
[INFO] Radio bringup begin
[INFO] Waiting for Sync
[ERROR] RU did not synchronize within 3 mins. Exiting radio initialization.
[ERROR] Radio bringup failed with: 0
[INFO] Restting
[INFO] Radio bringup begin
[INFO] Waiting for Sync
[ERROR] RU did not synchronize within 3 mins. Exiting radio initialization.
[ERROR] Radio bringup failed with: 0
[INFO] Restting
[INFO] Radio bringup begin
[INFO] Waiting for Sync
[ERROR] RU did not synchronize within 3 mins. Exiting radio initialization.
[ERROR] Radio bringup failed with: 0
[INFO] Restting
[INFO] Radio bringup begin
[INFO] Waiting for Sync
[ERROR] RU did not synchronize within 3 mins. Exiting radio initialization.
[ERROR] Radio bringup failed with: 0
[ERROR] Un-recoverable system failure detected, reboot required.
root@benetelru:~#
```

```
Every 1.0s: cat /tmp/radio_status
[INFO] Platform: RAN650_B
[INFO] Radio bringup begin
[INFO] Load EEPROM Data
[INFO] Tx1 Attenuation set to 15000 mdB
[INFO] Tx3 Attenuation set to 15410 mdB
[INFO] Operating Frequency set to 3751.680 MHz
[INFO] Waiting for Sync
[INFO] Sync completed
[INFO] Start Radio Configuration
[INFO] Initialize RF IC
[INFO] Disabled CFR for Antenna 1
[INFO] Disabled CFR for Antenna 3
[INFO] Move platform to TDD mode
[INFO] Set CP60 as TDD control master
[INFO] Enable TX on FEM
[INFO] FEM to full MIMO1_3 mode
[INFO] DPD Tx1 configuration
[INFO] DPD Tx3 configuration
[INFO] Set attn at 3751.680 MHz
[INFO] Reg 0xC0366 to 0x3FF
[INFO] Tuning the UE TA to reduce timing_offset
[INFO] The O-RU is ready for System Integration
[INFO] Radio bringup complete
15:54:32 up 3 min, load average: 0.07, 0.17, 0.08
^C
root@benetelru:~#
```

The O-RU sync setting can be checked following boot up by reading the radio\_sync\_status as follows:

```
cat /tmp/logs/radio_sync_status
```

It should outline "RU running in GPS mode" as shown below:

```
root@benetelru:~# cat radio_sync_status
Configuring CP60 for GPS Sync Mode
GPS Settings configured
Syncmon started
RU running in GPS mode, check status with syncmon
```

If this is not seen and it displays PTP Mode selected or some other response, the user should issue the following command and following reboot the O-RU will be configured for GPS Mode as shown in the screenshot

```
setSyncModeGps.sh
```

```
root@benetelru:~# setSyncModeGps.sh
RU Set to use GPS on next reboot. Reboot for this to take effect.
root@benetelru:~#
```

Should the user wish to move from GPS/Ext 1PPs Mode to PTP Mode, they should send the following command:

```
setSyncModePtp.sh
```

```
root@benetelru:~# setSyncModePtp.sh
57 settings written to SMI
RU Set to use PTP on next reboot. Reboot for this to take effect.
root@benetelru:~#
```

### 5.2.2 Radio Configuration

The User can monitor the progress of the boot up sequence by “watching” a *radio status* file created on each boot up in “/tmp/logs” directory.

The command is shown below and the user must wait until the highlighted text in Yellow is achieved before moving to End to End or TestMAC Testing

```
watch -n 1 'cat /tmp/logs/radio_status'
```

```

root@benetelru:~# cat /tmp/logs/radio_status
[INFO] Platform: RAN550_B
[INFO] Radio bringup begin
[INFO] Initialize TDD Pattern
[INFO] Load EEPROM Data
[INFO] Tx1 Attenuation set to 15000 mdB
[INFO] Tx3 Attenuation set to 15410 mdB
[INFO] Operating Frequency set to 3751.680 MHz
[INFO] Waiting for Sync
[INFO] Sync completed
[INFO] Kick off Synchronization of Linux system time to PTP time
[INFO] Start Radio Configuration
[INFO] Initialize RF IC
[INFO] Configure CFR for Antenna 1 (0.54)
[INFO] Configure CFR for Antenna 3 (0.54)
[INFO] Move platform to TDD mode
[INFO] Set CP60 as TDD control master
[INFO] Enable TX on FEM
[INFO] FEM to full MIMO1_3 mode
[INFO] DPD Tx1 configuration
[INFO] DPD Tx3 configuration
[INFO] Set attn at 3751.680 MHz
[INFO] Reg 0xC0366 to 0x3FF
[INFO] Tuning the UE TA to reduce timing_offset
[INFO] Issued handshake command
[INFO] The O-RU is ready for System Integration
[INFO] Radio bringup complete
10:45:54 up 4 min, load average: 0.33, 0.50, 0.26
root@benetelru:~#

```

At this point the radio is configured and the user can move to TestMAC Integration testing as outlined in **Section 6** of this document.

### 5.3 System Configuration Verification

On the either the RAN550 or RAN650 CAT-B, following radio configuration, there are three commands to verify that the radio is configured as required with correct TX power, antenna configuration and frequency and this must be checked by the user ahead of UL1 and Stack execution.

```
- radiocontrol -o G a
```

This command responds with the status of the radio following initialisation

The key parameters, Frequency and ANT1 and ANT3 attenuation settings are highlighted below

**NOTE:** If the response from this command are not in this format, the user should hard power cycle the O-RU. Should this continue to fail, please contact Benetel at [support@benetel.com](mailto:support@benetel.com)

```

root@benetelru:~# radiocontrol -o G a
Benetel radiocontrol Version      : 0.9.4
Madura API Version                : 5.1.0.21
Madura ARM FW version             : 5.1.0.9
Madura ARM DPD FW version         : 5.1.0.9
Madura Stream version             : 8.1.0.1
Madura Product ID                 : 0x84
Madura Device Revision            : 0xb0
Tx1 Attenuation (mdB)              : 15000
Tx2 Attenuation (mdB)              : 40000
Tx3 Attenuation (mdB)              : 15400
Tx4 Attenuation (mdB)              : 40000
PLL1 Frequency (Hz)               : 0
PLL2 Frequency (Hz)               : 3751680000
Front-end Control                  : 0x2aa491
Madura Deframer 0                  : 0x87
Madura Framer 0                   : 0xa
Internal Temperature (degC)        : 57
External Temperature (degC)        : 44.740234
RX1 Power Level (dBFS)             : -60.500000
RX2 Power Level (dBFS)             : -60.750000
RX3 Power Level (dBFS)             : -60.750000
RX4 Power Level (dBFS)             : -60.750000
ORX1 Peak/Mean Power Level (dBFS)  : -20.866970/-31.124148
ORX2 Peak/Mean Power Level (dBFS)  : -inf/-inf
ORX3 Peak/Mean Power Level (dBFS)  : -22.232338/-32.404635
ORX4 Peak/Mean Power Level (dBFS)  : -inf/-inf

```

Figure 2: Expected response to “radiocontrol -o G a”

#### - radiocontrol -o D s

This command responds with the status of each of the active transmitters of the O-RU. As this deployment is only ANT1 and ANT3, we only reference the responses for these antenna’s.

Again the key parameters are highlighted below in the screenshot

**ExtPath Delay** reading should be either 154, 155, 156 or 157 for the active ANT1 and ANT3 antenna’s

```

root@benetelru:~# radiocontrol -o D s
Report DPD status

TX1
ExtPathDelay.fifoDelay : 157
ExtPathDelay.interpolationIndex : 0

dpdErrorCode: 13324
dpdPercentComplete: 0
dpdPerformanceMetric: 0
dpdIterCount: 231
dpdUpdateCount: 0
dpdSyncStatus: 1
dpdModelTable: 0
dpdDirectEvm: 0.000000
dpdIndirectEvm: 0.000000
dpdSelectError: 0.000000
dpdIndirectError: 0.000000
dpdErrorStatus0 (metrics:actions): 0:0
dpdErrorStatus1 (metrics:actions): 0:0
dpdPersistentErrorStatus0 (metrics:actions): 0:0
dpdPersistentErrorStatus1 (metrics:actions): 0:0
reservedPM: 0
reservedTP: 0
reservedPR: 0

```

```

TX3
ExtPathDelay.fifoDelay : 156
ExtPathDelay.interpolationIndex : 10

dpdErrorCode: 13324
dpdPercentComplete: 0
dpdPerformanceMetric: 0
dpdIterCount: 195
dpdUpdateCount: 0
dpdSyncStatus: 1
dpdModelTable: 0
dpdDirectEvm: 0.000000
dpdIndirectEvm: 0.000000
dpdSelectError: 0.000000
dpdIndirectError: 0.000000
dpdErrorStatus0 (metrics:actions): 0:0
dpdErrorStatus1 (metrics:actions): 0:0
dpdPersistentErrorStatus0 (metrics:actions): 0:0
dpdPersistentErrorStatus1 (metrics:actions): 0:0
reservedPM: 0
reservedTP: 0
reservedPR: 0

```

Figure 3: Expected response to “radiocontrol -o D s”

#### - reportRuStatus

This command queries the system and provides feedback which should be shared with your Benetel support engineer. The register description in the response provides an indication of the status.



```

root@benetelru:~# reportRuStatus

[INFO] Sync status is:
Register 0xc0367, Value : 0x1
-----

[INFO] RU Status information is:
Register 0xc0306, Value : 0xf71802
-----

[INFO] Fill level of Reception Window is:
Register 0xc0308, Value : 0x8e17
-----

[INFO] Packet Count is:
Register 0xc0311, Value : 0x56f49
-----

=====
RU Status Register description:
=====
[31:24] Payload Format field value when an invalid detection is made
[23:20] Symbol Index 0 counter to delay fronthaul processing (increments every 10.24 secs)
[19] same as bit [9]
[18] set to 1 if handshake is successful
[17] set to 1 when settling time (fronthaul) has completed
[16] set to 1 when first Symbol Index 0 is captured
[15] Sticky Alarm: set to 1 if payload format is invalid
[14] Sticky Alarm: set to 1 if Symbol Index Sequence Error has been detected (out-of-order packets)
[13] Sticky Alarm: set to 1 if a truncated symbol arrives from DU
[12] reserved
[11] set to 1 if DU MAC address is correct
[10] reserved
[9] toggles HIGH if Symbol Index Sequence Error (live, toggling)
[8] reserved
[7:4] reserved
[3:2] reserved
[1] Sticky Alarm: set to 1 if Reception Window Buffer is empty
[0] Sticky Alarm: set to 1 if Reception Window Buffer is full

```

Figure 4: Expected response to “reportRuStatus”

## 5.4 O-RU Sync Status – GPS or Ext 1PPS Query

If the user is running in either RAN650 GPS mode or in RAN550 Ext 1PP mode, they query the sync status of the O-RU by sending the following command:

```
syncmon
```

This will respond with a script that will update every second with a sync status.

To exit you must send Ctrl-C

For RAN650 GPS deployment, the key parameter is CLK5 and for the RAN550 Ext 1PPS Deployment, the key parameter is CLK6 Ext 1PPS Live:

- **CLK5 GPS LIVE or CLK6 EXT 1PPS LIVE:**
  - **LOS + No Activity**  
The system cannot detect the Input GPS/1PPS signal to the O-RU
  - **OK**  
The system successfully detects the Input GPS/1PPS Signal to the O-RU  
Note: This must be the case to allow for DPLL3 to move off FREERUN Mode
- **DPLL3:**
  - **FREERUN:**  
There is no lock state detected

- **ACQUIRING LOCK:**  
The system is in the process of moving from Freerun to Locked
- **LOCKED:**  
The system has achieved GPS/1PPS lock
- **HOLDOVER:**  
The system has lost GPS/1PPS sync and has moved to holdover mode

```

root@benetelru:~# syncmon

DPLL0 State (SyncE/Ethernet clock): LOCKED
DPLL1 State (FPGA clocks): FREERUN
DPLL2 State (FPGA clocks): FREERUN
DPLL3 State (RF/PTP clock): LOCKED

CLK0 SyncE LIVE: OK
CLK0 SyncE STICKY: LOS + No Activity

CLK2 10MHz LIVE: LOS + No Activity
CLK2 10MHz STICKY: LOS + No Activity

CLK5 GPS LIVE: OK
CLK5 GPS STICKY: LOS and Frequency Offset

CLK6 EXT 1PPS LIVE: LOS and Frequency Offset
CLK6 EXT 1PPS STICKY: LOS and Frequency Offset

```

## 5.5 O-RU Sync Status – PTP

If supported, the User can query the PTP sync status of the O-RU by sending the following command:

```
cat /var/log/pcm4l
```

Successful PTP lock can be seen by validating the Freq and Time locker status as highlighted below:

```

root@benetelru:~# tail -f /var/log/pcm4l
RE::SyncAnalysis: 2020-02-07 15:52:22 094138500 ns [2, Supervisor] (3066) L0 state: 'Frequency Locked' to 'Time Locked' Event: 'L0 time locked'.
RE::Debug: 2020-02-07 15:52:22 095260800 ns [2, Supervisor] Enter time locked state
RE::Debug: 2020-02-07 15:52:22 095759320 ns [2, Supervisor] Tracker#0:
RE::Debug: 2020-02-07 15:52:22 096483600 ns [2, Supervisor] Current reference master: Yes
RE::Debug: 2020-02-07 15:52:22 096939040 ns [2, Supervisor] Freq locked: Yes
RE::Debug: 2020-02-07 15:52:22 097620460 ns [2, Supervisor] Time locked: Yes
RE::Debug: 2020-02-07 15:52:22 098091440 ns [2, Supervisor]
RE::SyncAnalysis: 2020-02-07 15:52:23 710058420 ns [3, Tracker#0] (3044) DL packet rate (3.61) is different from the nominal rate (16.00).
RE::SyncAnalysis: 2020-02-07 15:52:28 650094280 ns [3, Tracker#0] (3240) offset: 0.5 ns delay: 131.5 ns

```



## 5.6 RF Power Adjustment

The user can adjust the output power of each of the transmitters using the following steps.

### RAN650 Configuration:

The Tx Attn settings are stored in EEPROM and loaded from there. These can be read manually by the user by issuing the following commands for the Transmitters in use, i.e. Tx1 and Tx3:

```
read_tx1_attn
```

```
read_tx3_attn
```

Both will return the attenuation stored in EEPROM for the O-RU you are working with, e.g. 15000mdB

The user can also read the existing Transmitter attenuation settings using the “*radiocontrol -o G a*” and this will report Tx1/2/3/4 settings.

For Example: *Tx1 Attn (mdB) 13000*

To adjust this power for the transmitter the user must edit the attenuation setting.

- For increasing the power the attenuation must be reduced
- For decreasing the power, the attenuation must be increased

### For Example:

- RAN650 is autoconfigured to operate at 35dBm as an outdoor O-RU
- When you read the Tx1 attenuation, this is reported as 11500mdB
- If you wish to decrease the output power by 5dB to 30dBm, you must increase the Tx1 attenuation by 5000mdB using the following command:

```
radiocontrol -o A 16500 1
```

- This will adjust the power for Tx1 only
- For other transmitters please use the following command format:

```
Tx1: radiocontrol -o A 16500 1
```

```
Tx2: radiocontrol -o A 16500 2
```

```
Tx3: radiocontrol -o A 16500 4
```

```
Tx4: radiocontrol -o A 16500 8
```

## 5.7 RF Frequency Adjustment

The Tx and Rx Frequencies are stored in EEPROM and loaded from there. This can be read manually by the user by issuing the following command and the response will be in MHz:

```
read_default_tx_frequency
```

The user should reference Section 7.16 and 7.15 to modify the operating frequency of the O-RU.

## 6. O-RU Bring Up – Phluido & Effnet Binary Execution Check

This section outlines the step procedure to successfully bring up the O-RU system and initiate execution of the Phluido UL1 and the Effnet TestMAC.

*Please note for detailed information on Phluido and Effnet execution please contact the companies directly. Benetel cannot debug Phluido and Effnet integration.*

For the purposes of this execution the following are assumed:

- The Benetel O-RU is powered on and the User has verified the Radio Configuration steps outlined in this document
- The DU server hosting the UL1/TestMAC software is powered on and available for SSH connection
- There is a 10GbE fibre connection between the Benetel O-RU and the a 10GbE NIC card on the DU server

### 6.1 DU MAC Address configuration

- The O-RU needs to know the MAC Address of the 10GbE NIC card in the DU Server and this needs to be set.
- This is stored in the EEPROM of the unit and this can be queried as summarised in Section 7.9 later in this document

### 6.2 Phluido UL1 Execution

The user should have the following files available from Phluido for this integration:

*PhluidoL1\_NR*; this is the UL1 binary file

*PhluidoL1\_NR.cfg*; this is the configuration file which you should refer to Phluido documents

From experience, Benetel recommends the creation of a script on the DU server to assist with the execution of this application every time we wish to start the Phluido UL1,

e.g. *run.sh* script

```
sudo ifconfig eno4 10.10.0.1 netmask 255.255.255.0 mtu 9000  
./PhluidoL1_NR PhluidoL1_NR.cfg
```

This ensures:

- Configuration of the NIC is correct and as expected by the Phluido UL1
- The MTU size is set correctly for the deployment
- Successful Execution of the UL1 application against the Phluido configuration file (*PhluidoL1\_NR.cfg*)

When the user executes the “run.sh” script on the O-DU the response should be as outlined below:

```

root@oai-epc:/home/labuser/phluid: apult_du# ./run.sh
Reading configuration from config file "PhluidoL1_NR.cfg"...
*****
* Phluido 5G-NR virtualized L1 implementation
*
* Copyright (c) 2014-2020 Phluido Inc.
* All rights reserved.
*
* The User shall not, and shall not permit others to:
* - integrate Phluido Software within its own products;
* - mass produce products that are designed, developed or derived from Phluido Software;
* - sell products which use Phluido Software;
* - modify, correct, adapt, translate, enhance or otherwise prepare derivative works or
* improvements to Phluido Software;
* - rent, lease, lend, sell, sublicense, assign, distribute, publish, transfer or otherwise
* make available the PHLUIDO Solution or any portion thereof to any third party;
* - reverse engineer, disassemble and/or decompile Phluido Software.
*
* THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS'' AND ANY EXPRESS OR IMPLIED WARRANTIES,
* INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A
* PARTICULAR PURPOSE ARE DISCLAIMED.
* IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL,
* EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF
* SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
* HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR
* TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS
* SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.
*
*****

Copyright information already accepted on 2021-03-11, 20:47:40.
Starting Phluido 5G-NR L1 software...
  PHAPI version      = 0.5 (12/10/2020)
  L1 SW version      = 0.8.1
  L1 SW internal rev = r3852
Parsed configuration parameters:
  LogLevel_verbose = INFORMATIVE
  LicenseKey       = FE23-D713-0586-1D80-8C0F-D500-F292-4017
  bbuFronthaulServerMode = 1
  targetRecvSymbolDelay = 70
  prachDecodeMode      = 2
  maxNumPdschLayers    = 1
  maxNumPuschLayers    = 1

```

This confirms a successful connection between the O-RU and the UL1 and allows for the TestMAC to be executed in the next section

## 6.3 TestMAC Execution

The user should have the following files available for this integration:

`testMAC_5msTDD_3751680khz_2tx`; this is the testMAC binary file

This is executed and responds as shown below:

```

root@oai-epc:/home/labuser/phluido_binaries_2021/digital_catapult_du# ./testMAC_5msTDD_3751680khz_2tx
Starting Phluido 5G-NR TestMAC
Creating output file "TestMAC_NR.output.txt"
Initializing message passing interface "Phluido5GL1_0"
Sending CONFIG message to Layer 1
Received CONFIG-ACK from Layer 1
  API version      = 0.5
  L1 SW version    = 0.3852
  numULHarqBuffers = 1024
Sending START-REQUEST to Layer 1
Received START-RESPONSE from Layer 1

```

## 6.4 Benetel O-RU Handshake

There are now two methods of handshaking depending on the release you are working with.

This can be checked as follows:

`cat /etc/benetel-rootfs-version`

If the response is V0.5.1 or greater, you should follow the steps outlined in 6.4.1 and if it is less than that, you should follow the steps in 6.4.2

## 6.4.1 Benetel O-RU Handshake

This is the new handshake procedure between the O-RU and UL1.

Instead of the user executing a handshake command from the O-RU, the O-RU will now be transmitting Handshake Msg#1 packets every sec and waiting for the O-DU to respond.

This can be seen in the screenshot below, ahead of any UL1/TestMAC execution.

```

root@epc:/home/labuser/RAN650-2_SystemTest# tcpdump -C 2 -xx -i eno4 | grep 44000 -A6
tcpdump: verbose output suppressed, use -v or -vv for full protocol decode
listening on eno4, link-type EN10MB (Ethernet), capture size 262144 bytes
13:38:51.006766 IP 10.10.0.2.44000 > epc.44000: UDP, length 20
0x0000: 001e 67fd f551 70b3 d5e1 516e 0800 4500
0x0010: 0030 0000 4000 4011 26a7 0a0a 0002 0a0a
0x0020: 0001 abe0 abe0 001c 0000 0100 0000 0100
0x0030: 0000 1400 0000 0200 0000 0100 0000 0000
13:38:51.006802 IP epc > 10.10.0.2: ICMP: epc udp port 44000 unreachable, length 56
0x0000: 0200 5e01 0101 001e 67fd f551 0800 45c0
0x0010: 004c 9572 0000 4001 d068 0a0a 0001 0a0a
0x0020: 0002 0303 8c1f 0000 0000 4500 0030 0000
0x0030: 4000 4011 26a7 0a0a 0002 0a0a 0001 abe0
0x0040: abe0 001c 0000 0100 0000 0100 0000 1400
0x0050: 0000 0200 0000 0100 0000
13:38:52.006795 IP 10.10.0.2.44000 > epc.44000: UDP, length 20
0x0000: 001e 67fd f551 70b3 d5e1 516e 0800 4500
0x0010: 0030 0000 4000 4011 26a7 0a0a 0002 0a0a
0x0020: 0001 abe0 abe0 001c 0000 0100 0000 0100
0x0030: 0000 1400 0000 0200 0000 0100 0000 0000
13:38:52.006841 IP epc > 10.10.0.2: ICMP: epc udp port 44000 unreachable, length 56
0x0000: 0200 5e01 0101 001e 67fd f551 0800 45c0
0x0010: 004c 95fc 0000 4001 cfde 0a0a 0001 0a0a
0x0020: 0002 0303 8c1f 0000 0000 4500 0030 0000
0x0030: 4000 4011 26a7 0a0a 0002 0a0a 0001 abe0
0x0040: abe0 001c 0000 0100 0000 0100 0000 1400
0x0050: 0000 0200 0000 0100 0000
13:38:53.006827 IP 10.10.0.2.44000 > epc.44000: UDP, length 20
0x0000: 001e 67fd f551 70b3 d5e1 516e 0800 4500
0x0010: 0030 0000 4000 4011 26a7 0a0a 0002 0a0a
0x0020: 0001 abe0 abe0 001c 0000 0100 0000 0100
0x0030: 0000 1400 0000 0200 0000 0100 0000 0000
13:38:53.006868 IP epc > 10.10.0.2: ICMP: epc udp port 44000 unreachable, length 56
0x0000: 0200 5e01 0101 001e 67fd f551 0800 45c0
0x0010: 004c 9677 0000 4001 cf63 0a0a 0001 0a0a
0x0020: 0002 0303 8c1f 0000 0000 4500 0030 0000
0x0030: 4000 4011 26a7 0a0a 0002 0a0a 0001 abe0
0x0040: abe0 001c 0000 0100 0000 0100 0000 1400
0x0050: 0000 0200 0000 0100 0000
13:38:54.006834 IP 10.10.0.2.44000 > epc.44000: UDP, length 20
0x0000: 001e 67fd f551 70b3 d5e1 516e 0800 4500
0x0010: 0030 0000 4000 4011 26a7 0a0a 0002 0a0a
0x0020: 0001 abe0 abe0 001c 0000 0100 0000 0100
0x0030: 0000 1400 0000 0200 0000 0100 0000 0000
13:38:54.006869 IP epc > 10.10.0.2: ICMP: epc udp port 44000 unreachable, length 56
0x0000: 0200 5e01 0101 001e 67fd f551 0800 45c0
0x0010: 004c 96ab 0000 4001 cf2f 0a0a 0001 0a0a
0x0020: 0002 0303 8c1f 0000 0000 4500 0030 0000
0x0030: 4000 4011 26a7 0a0a 0002 0a0a 0001 abe0
0x0040: abe0 001c 0000 0100 0000 0100 0000 1400
0x0050: 0000 0200 0000 0100 0000

```

Once the UL1 and TestMAC are run, the “System is Live” will appear immediately.

## 6.4.2 Benetel O-RU Handshake

This is the original process where the user manually issues the handshaking commands once the UL1/TestMAC are started.

Having configured the DU MAC address and starting the UL1/TestMAC applications, the -Benetel O-RU needs a reset command sent to the FPGA to create the link to the system.

This is achieved by executing the “handshake” script installed on the Benetel O-RU as shown below.

```

root@benetelru:~# handshake

***** WARNING!!! Ensure DU MAC address is correct or handshake will fail!!! *****
***** WARNING!!! Ensure L1 and L2 are running or handshake will fail!!! *****

[INFO] Handshake is running...
[INFO] Handshake has completed... system should be live within 30 seconds if DU MAC address is correct!

root@benetelru:~#

```

## 6.5 Benetel O-RU Bring Up Complete

The Effnet TestMAC console will show the system as live after approximately 20-30 secs in the case of the RAN650-2V0.5 or earlier but immediately in the case of RAN650-2V0.5.1 and beyond.

At this point the system is successfully brought up.

```
Starting Phluido 5G-NR TestMAC
Creating output file "TestMAC_NR.output.txt"
Initializing message passing interface "Phluido5GL1_0"
Sending CONFIG message to Layer 1
Received CONFIG-ACK from Layer 1
    API version      = 0.5
    L1 SW version    = 0.3852
    numULHarqBuffers = 1024
Sending START-REQUEST to Layer 1
Received START-RESPONSE from Layer 1
Received ADDED-RU from Layer 1
    numTxAntennas    = 2
    numRxAntennas    = 1
Phluido System is now live
```

**THIS COMPLETES THE SYSTEM BRING-UP & UE CAN BE CONNECTED**

**Contact your integration partner for next steps**

## 6.6 User Network Configuration

As the user integrates the O-RU with their O-DU, the following steps must be completed.

1. O-DU IP address set in EEPROM (see section 7 of this guide for instructions).
2. O-RU Control IP address set in EEPROM (section 7). This address must be on the same subnet as the O-DU IP address.
3. O-RU and O-DU UDP ports set in EEPROM (section 7).
4. O-RU ADV, RSP and UPLINK checksums calculated according to the new IP addresses (see section 7.16).
5. O-RU ADV, RSP and UPLINK checksums set in EEPROM (section 7).
6. Reboot O-RU.
7. Edit the *run.sh* script to use updated O-DU IP address (see section 6.2)
8. Edit Phluido configuration file (*PhluidoL1\_NR.cfg*) so that the *bbuFronthaulServerAddr* aligns to the updated O-DU IP address. If UDP ports have been modified, *bbuFronthaulServerPort* in the Phluido configuration file must also be modified.
9. Complete the O-RU bring-up according to section 6.

## 7. Appendix 1: EEPROM Configuration

The RAN550 and RAN650 utilises the addition of the EEPROM as a storage device for the parameters summarised below.

- O-RU MAC Address
- O-RU IP Address
- O-RU UDP Port Number
- O-RU ADV Checksum
- O-RU RSP Checksum
- O-RU UPLINK Checksum
  
- O-DU MAC Address
- O-DU IP Address
- O-DU UDP Port Number
- O-DU IP Checksum

This section of the document will explain the settings for these parameters and how the user needs to configure them.

### 7.1 EEPROM Parameter Query

The O-RU has an application in `/usr/bin` which allows the user to read/write from the EEPROM, this is call `eeprog_cp60`

The parameter/variable will be stored in either ASCII or HEX format and there is a slight difference in the query command for each:

#### ASCII Format

```
eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -r 0:6
```

- This will return the EEPROM entry in ASCII from address 0 for a total of 6 bytes

#### HEX Format

```
eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -x -r 0:6
```

- This will return the EEPROM entry in HEX from address 0 for a total of 6 bytes

The only parameters outside the additional “-x” for the HEX format that the User should be changing is the address and length at the end, currently set to 0:6

- 0: Represents the start address in decimal
- 6: Represents the number of bytes to read in decimal

**Example:** Reading O-RU MAC Address, which is in HEX format as outlined in Section 8.3 below

- This O-RU Mac address is 70:B3:D5:E1:51:E0

```
root@benetelru:~# eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -x -r 0:6
0000| 70 b3 d5 e1 51 e0
```

## 7.2 EEPROM Parameter Write

The O-RU has an application in */usr/bin* which allows the user to read/write from the EEPROM, this is call *eeprog\_cp60*

While the parameter/variable will be stored in either ASCII or HEX format, there is no difference in how the User should writes the settings to the EEPROM:

### EEPROM Write Format

- *eeprog\_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x00:0x01:0x72*

**0x00:** Represents the address where the byte should be written to

**0x01:** Represents the number of bytes to write, this is always 0x01

**0x72:** Represents the new value of the EEPROM location

**Example:** Writing the O-RU MAC Address, which is in HEX format as outlined in Section 8.3 below

- This new O-RU Mac address is 72:B3:D3:E1:52:E0
- The following six commands would then be sent to the O-RU to configure this:

```
echo -n "0-0057" > /sys/bus/i2c/devices/0-0057/driver/unbind
registercontrol -w 0xC036B -x 0x88000088
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x00:0x01:0x72
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x01:0x01:0xB3
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x02:0x01:0xD3
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x03:0x01:0xE1
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x04:0x01:0x52
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x05:0x01:0xE0
```



```
registercontrol -w 0xC036B -x 0x88000488
```

- The writing is verified by querying the settings:  
`eeprog_cp60 -q -f -x -16 /dev/i2c-0 0x57 -x -r 0:6`

```
root@benetelru:~# echo -n "0-0057" > /sys/bus/i2c/devices/0-0057/driver/unbind
root@benetelru:~# registercontrol -w 0xC036B -x 0x88000488
root@benetelru:~# eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x00:0x01:0x72
eeprog 0.7.6, a 24Cxx EEPROM reader/writer
Benetel T3K EEPROM Application 1.0.1
Copyright (c) 2003-2004 by Stefano Barbato - All rights reserved.
Bus: /dev/i2c-0, Address: 0x57, Mode: 16bit
Writing value 0x72 at address 0x0 for size 0x1
.

root@benetelru:~# eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x01:0x01:0xB3
eeprog 0.7.6, a 24Cxx EEPROM reader/writer
Benetel T3K EEPROM Application 1.0.1
Copyright (c) 2003-2004 by Stefano Barbato - All rights reserved.
Bus: /dev/i2c-0, Address: 0x57, Mode: 16bit
Writing value 0xb3 at address 0x1 for size 0x1
.

root@benetelru:~# eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x02:0x01:0xD3
eeprog 0.7.6, a 24Cxx EEPROM reader/writer
Benetel T3K EEPROM Application 1.0.1
Copyright (c) 2003-2004 by Stefano Barbato - All rights reserved.
Bus: /dev/i2c-0, Address: 0x57, Mode: 16bit
Writing value 0xd3 at address 0x2 for size 0x1
.

root@benetelru:~# eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x03:0x01:0xE1
eeprog 0.7.6, a 24Cxx EEPROM reader/writer
Benetel T3K EEPROM Application 1.0.1
Copyright (c) 2003-2004 by Stefano Barbato - All rights reserved.
Bus: /dev/i2c-0, Address: 0x57, Mode: 16bit
Writing value 0xe1 at address 0x3 for size 0x1
.

root@benetelru:~# eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x04:0x01:0x52
eeprog 0.7.6, a 24Cxx EEPROM reader/writer
Benetel T3K EEPROM Application 1.0.1
Copyright (c) 2003-2004 by Stefano Barbato - All rights reserved.
Bus: /dev/i2c-0, Address: 0x57, Mode: 16bit
Writing value 0x52 at address 0x4 for size 0x1
.

root@benetelru:~# eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x05:0x01:0xE0
eeprog 0.7.6, a 24Cxx EEPROM reader/writer
Benetel T3K EEPROM Application 1.0.1
Copyright (c) 2003-2004 by Stefano Barbato - All rights reserved.
Bus: /dev/i2c-0, Address: 0x57, Mode: 16bit
Writing value 0xe0 at address 0x5 for size 0x1
.

root@benetelru:~# registercontrol -w 0xC036B -x 0x88000488
root@benetelru:~# eeprog_cp60 -q -f -x -16 /dev/i2c-0 0x57 -x -r 0:6

0000| 72 00 d3 e1 52 e0
```

### 7.3 O-RU MAC Address

**EEPROM Start Address:** 0x00 [0 decimal]  
**EEPROM Storage Size:** 6 bytes  
**EEPROM Format:** HEX  
*Example: 72:B3:D3:E1:52:E0*



**Query Command:** `eeprog_cp60 -q -f -x -16 /dev/i2c-0 0x57 -x -r 0:6`

## 7.4 O-RU IP Address

**EEPROM Start Address:** 0x12 [18 decimal]

**EEPROM Storage Size:** 4 bytes

**EEPROM Format:** HEX

*Example:* 0A:0A:00:64, which equates to 10.10.0.100

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -x -r 18:4`

## 7.5 O-RU UDP Port Number

**EEPROM Start Address:** 0x16 [22 decimal]

**EEPROM Storage Size:** 2 bytes

**EEPROM Format:** HEX

*Example:* 0xABE0

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -x -r 22:2`

## 7.6 O-RU ADV IP Checksum

**EEPROM Start Address:** 0x18 [24 decimal]

**EEPROM Storage Size:** 2 bytes

**EEPROM Format:** HEX

*Example:* 0x2645

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -x -r 24:2`

## 7.7 O-RU RSP IP Checksum

**EEPROM Start Address:** 0x50E [1294 decimal]

**EEPROM Storage Size:** 2 bytes

**EEPROM Format:** HEX

*Example: 0x264D*

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -x -r 1294:2`

## 7.8 O-RU UPLINK IP Checksum

**EEPROM Start Address:** 0x510 [1296 decimal]

**EEPROM Storage Size:** 2 bytes

**EEPROM Format:** HEX

*Example: 0x1C59*

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -x -r 1296:2`

## 7.9 O-DU MAC Address

**EEPROM Start Address:** 0x1A [26 decimal]

**EEPROM Storage Size:** 6 bytes

**EEPROM Format:** HEX

*Example: 00:7D:93:02:BB:FE*

**Query Command:** `eeprog_cp60 -q -f -x -16 /dev/i2c-0 0x57 -x -r 26:6`

## 7.10 O-DU IP Address

**EEPROM Start Address:** 0x20 [32 decimal]

**EEPROM Storage Size:** 4 bytes

**EEPROM Format:** HEX

*Example: 0A:0A:00:01, which equates to 10.10.0.1*

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -x -r 32:4`

## 7.11 O-DU UDP Port Number

**EEPROM Start Address:** 0x24 [36 decimal]  
**EEPROM Storage Size:** 2 bytes  
**EEPROM Format:** HEX  
*Example: 0xABE0*

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -x -r 36:2`

## 7.12 O-DU IP Checksum

**EEPROM Start Address:** 0x26 [38 decimal]  
**EEPROM Storage Size:** 2 bytes  
**EEPROM Format:** HEX  
*Example: 0x264D*

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -x -r 38:2`

### 7.13 O-RU Software Load Query

The User can query the software installed on the O-RU by sending the command:

*cat /etc/benetel-rootfs-version*

```
root@benetelru:~# cat /etc/benetel-rootfs-version
RAN650-2V0.4
root@benetelru:~#
```

### 7.14 O-RU Sync Status

The User can query the sync status of the O-RU by sending the command:

*syncmon*

This will respond with a script that will update every second with a sync status.

To exit you much send Ctrl-C

For RAN650 GPS deployment, the key parameter is CLK5 and for the RAN550 Ext 1PPS Deployment, the key parameter is CLK6 Ext 1PPS Live:

- **CLK5 GPS LIVE or CLK6 EXT 1PPS LIVE:**
  - **LOS + No Activity**  
The system cannot detect the Input GPS/1PPS signal to the O-RU
  - **OK**  
The system successfully detects the Input GPS/1PPS Signal to the O-RU  
Note: This must be the case to allow for DPLL3 to move off FREERUN Mode
- **DPLL3:**
  - **FREERUN:**  
There is no lock state detected
  - **ACQUIRING LOCK:**  
The system is in the process of moving from Freerun to Locked
  - **LOCKED:**  
The system has achieved GPS/1PPS lock
  - **HOLDOVER:**  
The system has lost GPS/1PPS sync and has moved to holdover mode

```
root@benetelru:~# syncmon
DPLL0 State (SyncE/Ethernet clock): LOCKED
DPLL1 State (FPGA clocks): FREERUN
DPLL2 State (FPGA clocks): FREERUN
DPLL3 State (RF/PTP clock): LOCKED

CLK0 SyncE LIVE: OK
CLK0 SyncE STICKY: LOS + No Activity

CLK2 10MHz LIVE: LOS + No Activity
CLK2 10MHz STICKY: LOS + No Activity

CLK5 GPS LIVE: OK
CLK5 GPS STICKY: LOS and Frequency Offset

CLK6 EXT 1PPS LIVE: LOS and Frequency Offset
CLK6 EXT 1PPS STICKY: LOS and Frequency Offset
```

## 7.15 IP Address CheckSum Reference

As outlined in the sections on Checksum above, with the assign IP addresses for the O-DU and O-RU, the correct checksum needs to be set.

Checksums can be calculated using the following website: <http://www.n-cg.net/hec.htm>

**O-RU RSP IP CHECKSUM --> 0010 0110 0100 1101 --> 0x264D**

### IPv4 Header Error Checksum Calculator

The following fields are fixed

- Type = 4
- Header length = 5 32-bit words
- No options

Type of service	0	(in decimal)
Total Length	40	
Identifier	0	
Don't Fragment	<input checked="" type="checkbox"/>	(check if set)
More Fragments	<input type="checkbox"/>	
Fragment Offset	0	(byte offset / 8)
TTL	64	
Protocol	17	
Source	10.10.0.1	(xxx.xxx.xxx.xxx)
Destination	10.10.0.100	

HEC 0010 0110 0100 1101

**O-RU ADV IP CHECKSUM --> 0010 0110 0100 0101 --> 0x2645**

### IPv4 Header Error Checksum Calculator

The following fields are fixed

- Type = 4
- Header length = 5 32-bit words
- No options

Type of service	0	(in decimal)
Total Length	48	
Identifier	0	
Don't Fragment	<input checked="" type="checkbox"/>	(check if set)
More Fragments	<input type="checkbox"/>	
Fragment Offset	0	(byte offset / 8)
TTL	64	
Protocol	17	
Source	10.10.0.1	(xxx.xxx.xxx.xxx)
Destination	10.10.0.100	

HEC 0010 0110 0100 0101

**O-RU UPLINK IP CHECKSUM** --> 0001 1100 0101 1001 --> **0x1C59**

#### IPv4 Header Error Checksum Calculator

The following fields are fixed

- Type = 4
- Header length = 5 32-bit words
- No options

Type of service	<input type="text" value="0"/>	(in decimal)
Total Length	<input type="text" value="2580"/>	
Identifier	<input type="text" value="0"/>	
Don't Fragment	<input checked="" type="checkbox"/>	(check if set)
More Fragments	<input type="checkbox"/>	
Fragment Offset	<input type="text" value="0"/>	(byte offset / 8)
TTL	<input type="text" value="64"/>	
Protocol	<input type="text" value="17"/>	
Source	<input type="text" value="10.10.0.1"/>	(xxx.xxx.xxx.xxx)
Destination	<input type="text" value="10.10.0.100"/>	

HEC:

**O-DU IP CHECKSUM** --> 0010 0110 0100 1101 --> **0x264D**

#### IPv4 Header Error Checksum Calculator

The following fields are fixed

- Type = 4
- Header length = 5 32-bit words
- No options

Type of service	<input type="text" value="0"/>	(in decimal)
Total Length	<input type="text" value="40"/>	
Identifier	<input type="text" value="0"/>	
Don't Fragment	<input checked="" type="checkbox"/>	(check if set)
More Fragments	<input type="checkbox"/>	
Fragment Offset	<input type="text" value="0"/>	(byte offset / 8)
TTL	<input type="text" value="64"/>	
Protocol	<input type="text" value="17"/>	
Source	<input type="text" value="10.10.0.1"/>	(xxx.xxx.xxx.xxx)
Destination	<input type="text" value="10.10.0.100"/>	

HEC:

## 7.16 Read & Adjust Tx Frequency Settings

**EEPROM Start Address:** 0x174 [372 decimal]

**EEPROM Storage Size:** 8 bytes

**EEPROM Format:** ASCII

Default: 3751.680

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -r 372:8`

```
root@benetelru:/# eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -r 372:8
3751.680root@benetelru:/#
```

**Write Commands:**

```
registercontrol -w 0xC036B -x 0x88000088
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x174:0x01:0x33
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x175:0x01:0x37
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x176:0x01:0x35
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x177:0x01:0x31
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x178:0x01:0x2E
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x179:0x01:0x36
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x17A:0x01:0x38
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x17B:0x01:0x30
registercontrol -w 0xC036B -x 0x880000488
```

## 7.17 Read & Adjust Rx Frequency Settings

**EEPROM Start Address:** 0x17C [380 decimal]

**EEPROM Storage Size:** 8 bytes

**EEPROM Format:** ASCII

*Default: 3751.680*

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -r 380:8`

```
root@benetelru:~# eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -r 380:8
3751.680root@benetelru:~#
```

**Write Commands:**

```
registercontrol -w 0xC036B -x 0x88000088
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x17C:0x01:0x33
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x17D:0x01:0x37
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x17E:0x01:0x35
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x17F:0x01:0x31
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x180:0x01:0x2E
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x181:0x01:0x36
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x182:0x01:0x38
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x183:0x01:0x30
registercontrol -w 0xC036B -x 0x880000488
```

## 7.18 Read & Adjust Tx1 Attn Settings

Following on from the power adjustment outlined in **RF Power Adjustment**, the user can stored the new

**EEPROM Start Address:** 0x30C [780 decimal]

**EEPROM Storage Size:** 5 bytes

**EEPROM Format:** ASCII representing mdB RF Power

*Example: 15000*

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -r 780:5`

```
root@benetelru:/# eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -r 780:5
15000root@benetelru:/#
```

**Write Commands:**

```

registercontrol -w 0xC036B -x 0x88000088
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x30C:0x01:0x31
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x30D:0x01:0x35
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x30E:0x01:0x30
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x30F:0x01:0x30
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x311:0x01:0x30
registercontrol -w 0xC036B -x 0x88000488

```

### 7.19 Read & Adjust Tx3 Attn Settings

Following on from the power adjustment outlined in **RF Power Adjustment**, the user can stored the new

**EEPROM Start Address:** 0x424 [1060 decimal]  
**EEPROM Storage Size:** 5 bytes  
**EEPROM Format:** ASCII representing mdB RF Power  
*Example:* 15000

**Query Command:** `eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -r 1060:5`

```

root@benetelru:/# eeprog_cp60 -q -f -16 /dev/i2c-0 0x57 -r 780:5
15000root@benetelru:/#

```

**Write Commands:**

```

registercontrol -w 0xC036B -x 0x88000088
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x424:0x01:0x31
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x425:0x01:0x35
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x426:0x01:0x30
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x427:0x01:0x30
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x428:0x01:0x30
registercontrol -w 0xC036B -x 0x88000488

```



## 8. Appendix 2: Sample EEPROM Write

This appendix provides sample commands to set O-DU MAC address, IP addresses and checksums in the EEPROM. These values can be edited as needed.

*# Setup EEPROM comms*

```
echo -n "0-0057" > /sys/bus/i2c/devices/0-0057/driver/unbind  
registercontrol -w 0xC036B -x 0x88000088
```

*# Program the O-DU MAC Address - 6c:b3:11:08:a4:e0*

```
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x1A:0x01:0x6C  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x1B:0x01:0xB3  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x1C:0x01:0x11  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x1D:0x01:0x08  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x1E:0x01:0xA4  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x1F:0x01:0xE0
```

*# Program the O-DU IP Address - 10.10.0.1*

```
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x20:0x01:0x0A  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x21:0x01:0x0A  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x22:0x01:0x00  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x23:0x01:0x01
```

*# Program the O-RU Control IP Address - 10.10.0.100*

```
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x12:0x01:0x0A  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x13:0x01:0x0A  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x14:0x01:0x00  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x15:0x01:0x64
```

*# Program the O-DU UDP Port - 0xABE0*

```
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x24:0x01:0xAB  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x25:0x01:0xE0
```

*# Program the O-RU UDP Port - 0xABE0*

```
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x16:0x01:0xAB  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x17:0x01:0xE0
```

*# Program the O-RU RSP IP Checksum - 0x264D*

```
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x50E:0x01:0x26  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x50F:0x01:0x4D
```

*# Program the O-RU ADV IP Checksum - 0x2645*

```
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x18:0x01:0x26  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x19:0x01:0x45
```

*# Program the O-RU Uplink Checksum - 0x1C59*

```
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x510:0x01:0x1C  
eeprog_cp60 -f -x -16 /dev/i2c-0 0x57 -w 0x511:0x01:0x59
```

*# Confirm settings and close EEPROM comms*

```
benetel_read_ru_eeprom.sh  
registercontrol -w 0xC036B -x 0x88000088
```