

## PROCEDURE

### 1.INSPECT ENGINE OIL PRESSURE SWITCH ASSEMBLY

83530

- a. Disconnect the engine oil pressure switch connector.
- b. Start the engine.
- c. Measure the resistance according to the value(s) in the table below.

**Standard Resistance:**

Tester Connection	Condition	Specified Condition
1 - Body ground	Engine stopped	Below 1 $\Omega$
	Engine idling	10 k $\Omega$ or higher

If the result is not as specified, replace the engine oil pressure switch assembly.

- d. Connect the engine oil pressure switch connector.