

## PROCEDURE

### 1.INSPECT KNOCK SENSOR

89615

- a. Measure the resistance according to the value(s) in the table below.

**Standard Resistance:**

Tester Connection	Condition	Specified Condition
1 - 2	20°C (68°F)	120 to 280 kΩ

If the result is not as specified, replace the knock sensor.