


Exploded view diagram of the front suspension assembly. Components and quantities shown include:

- Upper control arm assembly (labeled \*6 and \*5).
- Lower control arm assembly (labeled \*4 and \*3).
- Steering knuckle (labeled \*1 and \*2).
- Various bolts and nuts (labeled 30 (306, 22) x 6, 44 (449, 32) 40 (408, 30)\*, 40 (408, 30), and \*11).
- Other components (labeled \*7, \*8, \*9, and \*10).

*1	AIR FUEL RATIO SENSOR (for Bank 1 Sensor 1)	*2	AIR FUEL RATIO SENSOR (for Bank 2 Sensor 1)
*3	EXHAUST MANIFOLD SUB-ASSEMBLY LH	*4	EXHAUST MANIFOLD SUB-ASSEMBLY RH
*5	FRONT FENDER APRON SEAL LH	*6	FRONT FENDER APRON SEAL RH
*7	HEATED OXYGEN SENSOR (for Bank 1 Sensor 2)	*8	HEATED OXYGEN SENSOR (for Bank 2 Sensor 2)
*9	NO. 1 MANIFOLD STAY	*10	NO. 2 MANIFOLD STAY
*11	GASKET	-	-
	Specified torque: N*m (kgf*cm, ft.*lbf)	*	For use with SST
•	N*m (kgf*cm, ft.*lbf): Specified torque	-	-