


## PROCEDURE

## 1.INSPECT CLUTCH DISC ASSEMBLY

31250

**NOTICE:**


When replacing the clutch disc assembly, make sure to perform an inspection of the flywheel sub-assembly and clutch cover assembly.



Using a vernier caliper, measure the rivet depth.

**Minimum rivet depth:**  
**0.3 mm (0.0119 in.)**

If the result is less than the minimum, replace the clutch disc assembly.




Using a dial indicator, check the clutch disc runout.

**Maximum runout:**  
**1.0 mm (0.0394 in.)**

If the runout exceeds the maximum, replace the clutch disc assembly.

## 2.INSPECT CLUTCH COVER ASSEMBLY

31210



Using a vernier caliper, inspect the diaphragm spring for the depth and width of wear.


**Maximum width:**

**6.0 mm (0.236 in.)**

**Maximum depth:**

**0.5 mm (0.0197 in.)**

If the result exceeds the maximum, replace the clutch cover assembly.




Perform a visual inspection of the clutch cover assembly.

i. Inspect for hair cracks or scratches extending from the center outwards, or discoloration.

ii. Inspect for hair cracks in a circular pattern, discoloration or excessive wear.  
If there is any damage, replace the clutch cover assembly.

### 3.INSPECT FLYWHEEL SUB-ASSEMBLY

13405




Using a dial indicator, inspect the flywheel runout.

**Maximum runout:**

**0.1 mm (0.00393 in.)**

If the runout exceeds the maximum, replace the flywheel sub-assembly.



Perform a visual inspection of the flywheel sub-assembly.

- i. Inspect for hair cracks or scratches extending from the center outwards, or discoloration.
- ii. Inspect for hair cracks in a circular pattern, discoloration or excessive wear.  
If there is any damage, replace the flywheel sub-assembly.

#### 4.INSPECT CLUTCH RELEASE BEARING ASSEMBLY

**31230**




Turn the release bearing by hand while applying force in the axial direction.

**HINT:**

The bearing is permanently lubricated and requires no cleaning or lubrication.  
Replace the clutch release bearing assembly as necessary.

#### 5.INSPECT INPUT SHAFT BEARING

**33311W**



Turn the bearing by hand while applying rotational force and check that the bearing rotates smoothly.

If the bearing sticks or a considerable amount of resistance is felt, replace the input shaft bearing.

**HINT:**


The bearing is permanently lubricated and requires no cleaning or lubrication.



## 6.REPLACE INPUT SHAFT BEARING

33311W

a.




Using SST, remove the input shaft bearing.

**SST**

**09303-35011**

b.



Using SST and a hammer, install a new input shaft bearing.

**SST**

**09304-12012**

**HINT:**

After assembling the input shaft bearing to the engine side, make sure that it rotates smoothly.