


## 1GR-FE ENGINE CONTROL AIR FUEL RATIO SENSOR INSPECTION

## PROCEDURE

## 1.INSPECT AIR FUEL RATIO SENSOR

89467B



*A	for Bank 1
*B	for Bank 2
*a	Component without harness connected (Air Fuel Ratio Sensor)

- a. Measure the resistance according to the value(s) in the table below.

**Standard Resistance (for Bank 1):**

Tester Connection	Condition	Specified Condition
1 (HT1A) - 2 (+B)	20°C (68°F)	1.8 to 3.4 $\Omega$
1 (HT1A) - 4 (A1A-)	Always	10 k $\Omega$ or higher

**Standard Resistance (for Bank 2):**

Tester Connection	Condition	Specified Condition
1 (HT2A) - 2 (+B)	20°C (68°F)	1.8 to 3.4 $\Omega$
1 (HT2A) - 4 (A2A-)	Always	10 k $\Omega$ or higher

If the result is not as specified, replace the air fuel ratio sensor.