


PROCEDURE

1.INSTALL CLUTCH ACCUMULATOR ASSEMBLY

31490

a.




Install the clutch accumulator assembly with the 2 bolts.

Torque:

10 N*m (102 kgf*cm, 7 ft.*lbf)

b.



*a	Torque Wrench Fulcrum Length
----	------------------------------

Using a union nut wrench, connect the 2 flexible hose tubes.

Torque:

Specified tightening torque : 15.2 N*m (155 kgf*cm, 11 ft.*lbf)

HINT:

- Calculate the torque wrench reading when changing the fulcrum length of the torque wrench.
Click here[General>INTRODUCTION>REPAIR INSTRUCTION>PRECAUTION](#)
- When using a union nut wrench (fulcrum length of 22 mm (0.8661 in.)) + torque wrench (fulcrum length of 300 mm (11.811 in.)): 14.2 N*m (145 kgf*cm, 10 ft.*lbf)

2.FILL RESERVOIR WITH BRAKE FLUID



3.BLEED CLUTCH LINE

[Click here](#)Drivetrain>CLUTCH>CLUTCH SYSTEM>BLEEDING



4.CHECK BRAKE FLUID LEVEL IN RESERVOIR

[Click here](#)Drivetrain>CLUTCH>CLUTCH SYSTEM>BLEEDING



5.CHECK FOR CLUTCH FLUID LEAK